Hardware manual ACS880-11 drives







You can find manuals and other product documents in PDF format on the Internet. See section *Document library on the Internet* on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representativeThe codes below open an online listing of the manuals applicable to the product



ACS880-11 manuals

Hardware manual

ACS880-11 drives

Table of contents



1. Safety instructions



4. Mechanical installation



6. Electrical installation -**IEC**



7. Electrical installation -USA



Table of contents

| 1. Safety instructions | |
|--|--|
| Contents of this chapter Use of warnings and notes in this manual General safety in installation, start-up and maintenance Electrical safety in installation, start-up and maintenance Precautions before electrical work Additional instructions and notes Grounding Additional instructions for permanent magnet motor drives Safety in installation, start-up and maintenance General safety in operation | . 13 . 14 . 16 . 17 . 18 . 19 |
| 2. Introduction to the manual | |
| Contents of this chapter Applicability Target audience Purpose of the manual Categorization by frame (size) Quick installation and commissioning flowchart Terms and abbreviations Related documents | . 21 . 21 . 21 . 21 . 22 |
| 3. Operation principle and hardware description | |
| Contents of this chapter | . 28 . 29 . 30 . 34 |
| Type designation label | |
| Type designation label | |



5. Planning the electrical installation

| Contents of this chapter |
|---|
| Selecting the supply disconnecting device |
| European Union |
| North American Market |
| Other regions |
| Checking the compatibility of the motor and drive |
| Protecting the motor insulation and bearings |
| Requirements table |
| Additional requirements for ABB motors of types other than M2_, M3_, M4_, HX_ and |
| AM |
| Additional requirements for ABB high-output and IP23 motors |
| Additional requirements for non-ABB high-output and IP23 motors |
| Additional data for calculating the rise time and peak line-to-line voltage 50 |
| Additional note for sine filters 6 |
| Selecting the power cables |
| General rules 6 |
| Typical power cable sizes |
| Alternative power cable types |
| Recommended power cable types |
| Power cable types for limited use |
| Not allowed power cable types |
| Motor cable shield |
| Additional US requirements 64 |
| Conduit |
| Armored cable / shielded power cable |
| Selecting the control cables |
| Shielding |
| Signals in separate cables |
| Signals allowed to be run in the same cable |
| Relay cable |
| Control panel cable |
| Drive composer PC tool cable |
| Routing the cables |
| General rules |
| Separate control cable ducts |
| Continuous motor cable shield or enclosure for equipment on the motor cable |
| Implementing thermal overload and short-circuit protection |
| Protecting the drive and input power cable in short-circuits |
| Protecting the drive and input power cable in short-circuits |
| Protecting the drive and the input power and motor cables against thermal overload 69 |
| Protecting the motor against thermal overload |
| Protecting the drive against ground faults |
| |
| Residual current device compatibility |
| |
| Implementing the Safe torque off function |
| Implementing the safety functions provided with the FSO safety functions module (options +Q972) |
| and +Q973) |
| Declaration of Conformity |
| Implementing the ATEX-certified Safe motor disconnection function (option +Q971) 7 |



| Implementing the undervoltage control (power-loss ride-through) | |
|--|---------|
| Using a safety switch between the drive and the motor | |
| Protecting the contacts of relay outputs | |
| Implementing a motor temperature sensor connection | |
| Drive I/O, I/O extension and encoder interface modules | |
| Drive 1/O, 1/O extension and encoder interface modules | /4 |
| 6. Electrical installation – IEC | |
| Contents of this chapter | 77 |
| Warnings | |
| Required tools | |
| Grounding the motor cable shield at the motor end | |
| Checking the insulation of the assembly | |
| Drive | |
| Input power cable | |
| Motor and motor cable | |
| Checking the compatibility with IT (ungrounded) and corner-grounded delta systems | |
| EMC filter option +E202 | |
| Ground-to-phase varistor | 80 |
| TT systems | |
| Identifying different types of electrical power systems | |
| Disconnecting internal EMC filter (option +E202) and ground-to-phase varistor – fran | |
| 84 | 116 113 |
| Disconnecting internal EMC filter (option +E202) and ground-to-phase varistor – fran | me R6 |
| 85 | |
| Disconnecting internal EMC filter and ground-to-phase varistor –frame R8 | 86 |
| Connecting the power cables | |
| Connection diagram | 87 |
| Connection procedure | 88 |
| R8 power cable connection if you detach the connectors | 97 |
| Connecting the control cables | |
| Default I/O connection digram | 100 |
| Notes: | |
| Jumpers and switches | |
| Al1 and Al2 as Pt100, Pt1000, PTC and KTY84 sensor inputs (XAI, XAO) | |
| External power supply for the control unit (XPOW) | |
| Drive-to-drive link (XD2D) | |
| DIIL input (XD24:1) | |
| DI6 (XDI:6) as PTC sensor input | |
| Safe torque off (XSTO) | |
| Safety functions module connection (X12) | |
| | |
| Installing option modules | |
| Wiring option modules | |
| Installation of safety functions modules | |
| Installation procedure into Slot 2 | |
| Installation procedure into slot 2 | |
| Reinstalling cover(s) | |
| | |



8 Table of contents

| Connecting a PC | |
|--|--|
| 7. Electrical installation – USA | |
| Warnings | 119 119 119 1119 1120 121 121 132 133 |
| Jumpers and switches | 134 135 135 136 137 137 137 142 142 142 |
| | 145 145 145 |
| 9. Start-up | |
| Contents of this chapter | |
| 10. Maintenance and hardware diagnostics | |
| Contents of this chapter | 149 150 |



| Heatsink | |
|--|-----|
| Fans | |
| Replacing the main cooling fan, frame R3 | |
| Replacing the main cooling fan, frame R6 | |
| Replacing the main cooling fan, frame R8 | |
| Replacing the auxiliary cooling fan, IP55 (UL Type 12) frame R3 | |
| Replacing the auxiliary cooling fan, frame R6 | |
| Replacing the auxiliary cooling fan, frame R8 | 157 |
| Replacing the second auxiliary cooling fan IP55 (UL Type 12), frame R8 | 158 |
| Capacitors | |
| Reforming the capacitors | 160 |
| Memory unit | |
| Replacing the memory unit | |
| Replacing the control unit battery | |
| Control panel | |
| Cleaning the control panel | |
| Replacing the battery in the control panel | |
| LEDs | |
| | |
| Drive LEDs | |
| Control panel LEDs | 163 |
| | |
| 11. Technical data | |
| Contents of this chapter | 165 |
| Ratings | |
| IEC ratings | |
| UL (NEC) ratings | |
| | |
| Definitions | |
| Sizing | |
| Derating | |
| Ambient temperature derating, IP21 (UL Type 1) | |
| Ambient temperature derating, IP55 (UL Type 12) | |
| Ambient temperature derating in table format | |
| Deratings for special settings in the drive control program | |
| Ex motor, sine filter, low noise | |
| High speed mode | |
| Altitude derating | |
| Fuses (IEC) | |
| aR fuses | 176 |
| Fuses (UL) | 178 |
| Dimensions, weights and free space requirements | 179 |
| Free space requirements | 179 |
| Losses, cooling data and noise | |
| Terminal and entry data for the power cables | |
| IEC | |
| UL | |
| UL listed cable lugs and tools | |
| Terminal and entry data for the control cables | |
| IEC | |
| US | |
| | |
| Electrical power network specification | 183 |



10 Table of contents

| Voltage (U1) | 183 |
|--|-----|
| Motor connection data | 184 |
| Control unit (ZCU-12) connection data | 185 |
| Efficiency | 189 |
| Degree of protection | 189 |
| Materials | 189 |
| Applicable standards | 191 |
| Ambient conditions | 192 |
| CE marking | 193 |
| Compliance with the European Low Voltage Directive | 193 |
| Compliance with the European EMC Directive | 193 |
| Compliance with the European ROHS II Directive | 194 |
| Compliance with the European WEEE Directive | 194 |
| Compliance with the European Machinery Directive | 194 |
| Declaration of conformity | 195 |
| Compliance with the EN 61800-3:2004 + A1:2012 | 197 |
| Definitions | 197 |
| Category C2 | 197 |
| Category C3 | 198 |
| Category C4 | |
| UL marking | |
| UL checklist | |
| China RoHS marking | |
| EAC marking | |
| Disclaimers | |
| General disclaimer | |
| Cybersecurity disclaimer | 201 |
| 12. Dimension drawings | |
| - | |
| Contents of this chapter | |
| R3, IP21 (UL Type 1) | |
| R3 – Option +B056 (IP55, UL Type 12) | |
| R6, IP21 (UL Type 1) | |
| R6 – Option +B054 (IP55, UL Type 12) | |
| R6 – Option +B056 (IP55, UL Type 12) | 208 |
| R8 – Option +B056 (IP55, UL Type 12) | 211 |
| 13. Safe torque off function | |
| To our to que en function | |
| What this chapter contains | 213 |
| Description | |
| Compliance with the European Machinery Directive | |
| Wiring | |
| Single drive (internal power supply) | 215 |
| Multiple drives (internal power supply) | |
| Multiple drives (external power supply) | |
| Wiring examples | |
| Activation switch | |
| Cable types and lengths | |
| Operation principle | 218 |

| Start-up including acceptance test Competence Acceptance test reports Acceptance test procedure Use Maintenance Competence Fault tracing Safety data (SIL, PL) Abbreviations | 219 219 219 221 221 222 222 223 |
|---|--|
| 14. Common mode, du/dt and sine filters | |
| What this chapter contains Common mode filters When is a common mode filter needed? du/dt filters When is a du/dt filter needed? du/dt filter types Description, installation and technical data of the NOCH filters Sine filters Selecting a sine filter for the drive Definitions | 225 225 225 225 226 226 226 226 |
| Derating | |
| i di dici ililorinadon | |
| Product and service inquiries Product training Providing feedback on ABB Drives manuals Document library on the Internet | 229 229 |







Safety instructions

Contents of this chapter

This chapter contains the safety instructions which you must obey when you install and operate the drive and do maintenance on the drive. If you ignore the safety instructions, injury, death or damage can occur.



Use of warnings and notes in this manual

Warnings tell you about conditions which can cause injury or death, or damage to the equipment. They also tell you how to prevent the danger. Notes draw attention to a particular condition or fact, or give information on a subject.

The manual uses these warning symbols:



Electricity warning tells about hazards from electricity which can cause injury or death, or damage to the equipment.



General warning tells about conditions, other than those caused by electricity, which can cause injury or death, or damage to the equipment.




Electrostatic sensitive devices warning tells you about the risk of electrostatic discharge which can cause damage to the equipment.

These instructions are for all personnel that install the drive and do maintenance work on it



WARNING! Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Use safety shoes with a metal toe cap to avoid foot injury. Wear protective gloves and long sleeves. Some parts have sharp edges.
- Handle the drive carefully.
 - Lift the drive with a lifting device. Use the lifting eyes of the drive.
 - Do not tilt the drive. The drive is heavy and its center of gravity is high. It will
 overturn easily.





- Beware of hot surfaces. Some parts, such as heatsinks of power semiconductors, remain hot for a while after disconnection of the electrical supply.
- Keep the drive in its package or protect it from dust and metal shavings from drilling and grinding until you install it. Protect the installed drive against dust and metal shavings. Electrically conductive debris inside the drive can cause damage or malfunction.
- Vacuum clean the area below the drive before the start-up to prevent the drive cooling fan from drawing the dust inside the drive.
- Do not cover the air inlet and outlet when the drive runs.
- Make sure that there is sufficient cooling. See sections Examining the installation site on page 42 and Losses, cooling data and noise on page 180 for more information.
- Before you connect voltage to the drive, make sure that the drive covers are on.
 Keep the covers on during the operation.
- Before you adjust the drive operation limits, make sure that the motor and all driven equipment can operate throughout the set operation limits.
- Before you activate the automatic fault reset or automatic restart functions of the drive control program, make sure that no dangerous situations can occur. These

functions reset the drive automatically and continue operation after a fault or supply break. If these functions are activated, the installation must be clearly marked as defined in IEC/EN 61800-5-1, subclause 6.5.3, for example, "THIS MACHINE STARTS AUTOMATICALLY".

- The maximum number of drive power-ups is five in ten minutes. Too frequent power-ups can damage the charging circuit of the DC capacitors.
- Make sure that any safety circuits (for example, emergency stop and Safe torque off) are validated at start-up. For the Safe torque off, see chapter Safe torque off function page 213. For other safety functions, see their separate instructions...

Note:

- If you select an external source for the start command and it is on, the drive will start immediately after fault reset unless you configure the drive for pulse start. See the firmware manual.
- Depending on the wiring and parametrization of the drive, the stop key on the control panel may not stop the drive.
- Only authorized persons are allowed to repair a malfunctioning drive.



Electrical safety in installation, start-up and maintenance

Precautions before electrical work

These warnings are for all personnel who do work on the drive, motor cable or motor.

WARNING! Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do electrical installation or maintenance work. Go through these steps before you begin any installation or maintenance work.

- 1. Clearly identify the work location.
- Disconnect all possible voltage sources. Lock and tag.
 - Open the main disconnector at the power supply of the drive.
 - Make sure that reconnection is not possible.
 - Disconnect any external power sources from the control circuits.
 - After you disconnect the drive, always wait for 5 minutes to let the intermediate circuit capacitors discharge before you continue.



- 3. Protect any other energized parts in the work location against contact.
- Take special precautions when close to bare conductors.
- Measure that the installation is de-energized.
 - Use a multimeter with an impedance of at least 1 Mohm.
 - Make sure that the voltage between the drive input power terminals (L1, L2, L3) and the grounding terminal (PE) is close to 0 V.
 - Make sure that the voltage between the drive DC terminals (UDC+ and UDC-) and the grounding terminal (PE) is close to 0 V.
- 6. Install temporary grounding as required by the local regulations.
- 7. Ask for a permit to work from the person in control of the electrical installation work.

Additional instructions and notes



WARNING! Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Do not install a drive with option +E202 on an IT (ungrounded) system, TT system or a corner-grounded delta system without disconnecting the filter and/or the varistor screws according to the instructions given in section When to disconnect EMC filter (option +E202) or ground-to-phase varistor on page 81.
- Do not do insulation or voltage withstand tests on the drive or drive modules.

Note:

- The motor cable terminals of the drive are at a dangerous voltage when the input power is on, regardless of whether the motor is running or not.
- The DC terminals (UDC+, UDC-) are at a dangerous voltage.
- External wiring can supply dangerous voltages to the terminals of relay outputs (XRO1, XRO2 and XRO3).
- The Safe torque off function does not remove the voltage from the main and auxiliary circuits. The function is not effective against deliberate sabotage or misuse.





WARNING! Use a grounding wrist band when you handle the printed circuit boards. Do not touch the boards unnecessarily. The boards contain components sensitive to electrostatic discharge.

Grounding

These instructions are for all personnel who are responsible for the electrical installation, including the grounding of the drive.

WARNING! Obey these instructions. If you ignore them, injury or death, or equipment malfunction can occur, and electromagnetic interference can increase.

- If you are not a qualified electrical professional, do not do grounding work.
- Always ground the drive, the motor and adjoining equipment to the protective earth (PE) bus of the power supply. This is necessary for the personnel safety.
 Proper grounding also reduces electromagnetic emission and interference.
- In a multiple-drive installation, connect each drive separately to the protective earth (PE) bus of the power supply.
- Make sure that the conductivity of the protective earth (PE) conductors is sufficient. See section Selecting the power cables on page 61. Obey the local regulations.
- Connect the power cable shields to the protective earth (PE) terminals of the drive.
- Make a 360° grounding of the power and control cable shields at the cable entries to suppress electromagnetic disturbances.

Note:

- You can use power cable shields as grounding conductors only when their conductivity is sufficient.
- Standard IEC/EN 61800-5-1 (section 4.3.5.5.2.) requires that as the normal touch current of the drive is higher than 3.5 mA AC or 10 mA DC, you must use a fixed protective earth (PE) connection. In addition.
 - install a second protective earth conductor of the same cross-sectional area as the original protective earthing conductor.

or

install a protective earth conductor with a cross-section of at least 10 mm² Cu or 16 mm² AI,

or

 install a device which automatically disconnects the supply if the protective earth conductor breaks.



Additional instructions for permanent magnet motor drives

Safety in installation, start-up and maintenance

These are additional warnings concerning permanent magnet motor drives. The other safety instructions in this chapter are also valid.



WARNING! Obey these instructions. If you ignore them, injury or death and damage to the equipment can occur.

 Do not work on a drive when a rotating permanent magnet motor is connected to it. A rotating permanent magnet motor energizes the drive including its input power terminals.

Before installation, start-up and maintenance work on the drive:

- Stop the motor.
- Disconnect the motor from the drive with a safety switch or by other means.
- If you cannot disconnect the motor, make sure that the motor cannot rotate during work. Make sure that no other system, like hydraulic crawling drives, can rotate the motor directly or through any mechanical connection like felt, nip, rope, etc.
- Measure that the installation is de-energized.
 - Use a multimeter with an impedance of at least 1 Mohm.
 - Make sure that the voltage between the drive output terminals (T1/U, T2/V, T3/W) and the grounding (PE) busbar is close to 0 V.
 - Make sure that the voltage between the drive input power terminals (L1, L2, L3) and the grounding (PE) busbar is close to 0 V.
 - Make sure that the voltage between the drive DC terminals (UDC+, UDC-) and the grounding (PE) terminal is close to 0 V.
- Install temporary grounding to the drive output terminals (T1/U, T2/V, T3/W). Connect the output terminals together as well as to the PE.

Start-up and operation:

Make sure that the operator cannot run the motor over the rated speed. Motor overspeed causes overvoltage that can damage or destroy the capacitors in the intermediate circuit of the drive.



General safety in operation

These instructions are for all personnel that operate the drive.



WARNING! Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Do not control the motor with the disconnector at the drive power supply; instead, use the control panel start and stop keys or commands through the I/O terminals of the drive.
- · Give a stop command to the drive before you reset a fault. If you have an external source for the start command and the start is on, the drive will start immediately after the fault reset, unless you configure the drive for pulse start. See the firmware manual.
- Before you activate automatic fault reset functions of the drive control program, make sure that no dangerous situations can occur. These functions reset the drive automatically and continue operation after a fault.

Note: When the control location is not set to Local, the stop key on the control panel will not stop the drive.



Additional instruction for DC connection



WARNING! Do not connect the drive DC link to a common DC system. The drive will get damaged.



Introduction to the manual

Contents of this chapter

The chapter describes applicability, target audience and purpose of this manual. It describes the contents of this manual and refers to a list of related manuals for more information. The chapter also contains a flowchart of steps for checking the delivery. installing and commissioning the drive. The flowchart refers to chapters/sections in this manual.

Applicability

The manual applies to the ACS880-11 drives.

Target audience

The reader is expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

The manual is written for readers worldwide. Both SI and imperial units are shown. Special US instructions for installations in the United States are given.


Purpose of the manual

This manual provides information needed for planning the installation, installing, and servicing the drive.

Categorization by frame (size)

The drive is manufactured in frames. Some instructions and other information which only concern certain frames are marked with the symbol of the frame, for example R3. The frame is marked on the type designation label attached to the drive, see section Type designation label on page 36.

Quick installation and commissioning flowchart



Terms and abbreviations

| Term/abbreviation | Explanation |
|-------------------|---|
| ACX-AP-x | Assistant control panel, advanced operator keypad for communication with the drive. |
| Control board | Circuit board in which the control program runs. |
| Capacitor bank | See DC link capacitors. |

| Term/abbreviation | Explanation | |
|----------------------|--|--|
| DC link | DC circuit between rectifier and inverter | |
| DC link capacitors | Energy storage which stabilizes the intermediate circuit DC voltage | |
| DPMP-01 | Control panel mounting platform (flush) | |
| DPMP-02 | Control panel mounting platform (surface) | |
| Drive | Frequency converter for controlling AC motors | |
| EMC | Electromagnetic compatibility | |
| EFB | Embedded fieldbus | |
| FAIO-01 | Optional analog I/O extension module | |
| FCAN-01 | Optional CANopen adapter module | |
| FCNA-01 | ControlNet adapter module | |
| FDIO-01 | Optional digital /O extension module | |
| FECA-01 | Optional EtherCAT adapter module | |
| FENA-21 | Optional Ethernet adapter module for EtherNet/IP, Modbus TCP and PROFINET IO protocols | |
| FEPL-02 | Optional Ethernet POWERLINK adapter module | |
| FIO-01 | Optional digital I/O extension module | |
| FIO-11 | Optional analog I/O extension module | |
| FPBA-01 | Optional PROFIBUS DP adapter module | |
| FSO-12 | Optional functional safety module | |
| FSO-21 | Optional functional safety module | |
| Frame (size) | Refers to drive physical size, for example R3. The type designation label attached to the drive shows the frame of the drive, see section <i>Type designation key</i> on page 37. | |
| I/O | Input/Output | |
| IGBT | Insulated gate bipolar transistor | |
| Intermediate circuit | See DC link. | |
| Inverter | Converts direct current and voltage to alternating current and voltage. | |
| NETA-21 | Remote monitoring tool | |
| Network control | With fieldbus protocols based on the Common Industrial Protocol (CIP TM), such as DeviceNet and Ethernet/IP, denotes the control of the drive using the Net Ctrl and Net Ref objects of the ODVA AC/DC Drive Profile. For more information, see www.odva.org , and the following manuals: | |
| | FDNA-01 DeviceNet adapter module user's manual (3AFE68573360 [English]), and FENA-01/-11/-21 Ethernet adapter module user's manual (3AUA0000093568 [English]). | |
| Parameter | User-adjustable operation instruction to the drive, or signal measured or calculated by the drive | |
| PLC | Programmable logic controller | |

| Term/abbreviation | Explanation |
|--|---|
| PROFIBUS, PROFIBUS DP, PROFINET IO | Registered trademarks of PI - PROFIBUS & PROFINET International |
| PTC | Positive temperature coefficient (PTC) refers to materials that experience an increase in electrical resistance when their temperature is raised. |
| R3, R6, R8 | Frame (size) |
| Rectifier | Converts alternating current and voltage to direct current and voltage. |
| STO | Safe torque off. See chapter Safe torque off function on page 213. |

Related documents

| Drive manuals and guides | Code (English) |
|--|---------------------|
| ACS880 primary control program firmware manual | 3AUA0000085967 |
| Quick start-up guide for ACS880 drives with primary | 3AUA0000098062 |
| control program | |
| ACS880-11 hardware manual | 3AXD50000045932 |
| ACS880-11 quick installation guide | 3AXD50000048138 |
| ACX-AP-x assistant control panels user's manual | 3AUA0000085685 |
| | |
| Option manuals and guides | |
| ACS880 drive module frames R1 to R9 for cabinet | 3AUA0000145446 |
| installation (options +P940 and +P944) supplement | |
| Flange mounting kit installation supplement | 3AXD50000019100 |
| Flange mounting kit quick installation guide for | 3AXD50000181506 |
| ACS880-11, ACS880-31, ACH580-31 and ACQ580- 31 frame R3 | |
| | 3AXD50000133611 |
| Flange mounting kit quick installation guide for ACS880-11, ACS880-31, ACH580-31 and ACQ580- | 3AAD30000133011 |
| 31 frames R6 and R8 | |
| Common mode filter kit for frames R7 and R8 (option | 3XD50000015179 |
| +E208) installation guide | |
| UK gland plate (+H358) installation guide for ACS880- | 3AXD50000110711 |
| 11, ACS880-31, ACH580-31and ACQ580-31 | |
| ACS880 ATEX-certified Safe disconnection function | 3AUA0000132231 |
| application guide | 0.4.5.5.00.4.5.5.00 |
| FCAN-01 CANopen adapter module user's manual | 3AFE68615500 |
| FCNA-01 ControlNet adapter module user's manual | 3AUA0000141650 |
| FDNA-01 DeviceNet™ adapter module user's manual | 3AFE68573360 |
| FECA-01 EtherCAT adapter module user's manual | 3AUA0000068940 |
| FENA-01/-11/-21 Ethernet adapter module user's | 3AUA0000093568 |
| manual | 241140000122527 |
| FEPL-02 Ethernet POWERLINK adapter module user's manual | 3AUA0000123527 |
| FPBA-01 PROFIBUS DP adapter module user's | 3AFE68573271 |
| manual | 0/11 2000/02/1 |
| FPTC-02 ATEX-certified thermistor relay module, Ex II | 3AXD50000027782 |
| (2) GD (+L537+Q971) for ACS880 drives user's | |
| manual | |
| FSCA-01 RS-485 adapter module user's manual | 3AUA0000109533 |
| FSO-12 safety functions module user's manual | 3AXD50000015612 |
| FSO-21 safety functions module user's manual | 3AXD50000015614 |
| | |

Tool and maintenance manuals and guides

| Drive composer PC tool user's manual | 3AUA0000094606 |
|--|----------------|
| Converter module capacitor reforming instructions | 3BFE64059629 |
| NETA-21 remote monitoring tool user's manual | 3AUA0000096939 |
| NETA-21 remote monitoring tool installation and start- up guide | 3AUA0000096881 |
| | |

Operation principle and hardware description

Contents of this chapter


This chapter briefly describes the operation principle, layout, type designation label and type designation information. It also shows a general diagram of power connections and control interfaces.

Operation principle

The ACS880-11 is a four-quadrant drive for controlling asynchronous AC induction motors, AC induction servomotors, permanent magnet motors and synchronous reluctance motors.

The drive includes a line-side converter and a motor-side converter. The parameters and signals for both converters are combined into one primary user program.

The figure below shows the simplified main circuit diagram of the drive.




The line-side converter rectifies three phase AC current to direct current for the intermediate DC link of the drive. The intermediate DC link further supplies the motorside converter that runs the motor.

Both converters consist of six insulated gate bipolar transistors (IGBT) with free wheeling diodes. The content of AC voltage and current harmonics is low. The LCL filter suppresses the harmonics further.

The line-side converter can transfer energy from the electrical power system to the drive DC link and vice versa. Thus the drive can operate the motor in all four quadrants (speed, torque). The figure below visualizes the operation of the fourquadrant drive. In quadrants I and III, the drive operates in the motoring mode and


takes energy from the power system. In quadrants II and IV, the drive operates in generating mode, and regenerates energy back to the power system.




The line-side and motor-side converters have their own control programs. The parameters of both programs can be viewed and changed using a control panel.

Layout

The layout of the drive is shown below.




| 1 | Lifting holes (2 pcs in frame R3, 6 pcs in frames R6 and R8) | 5 | Front cover |
|---|--|---|--|
| 2 | Control panel | 6 | Control panel behind the control panel cover |
| 3 | Heatsink | 7 | Hood in frames R6 and R8. |
| 4 | Mounting points (4 pieces) | - | - |




The main cooling fan is at the top of the drive in frame R3 and at the bottom in frames R6 and R8.

The layout of external control connection terminals of the drive is shown below.




Overview of power and control connections

The logical diagram below shows the power connections and control interfaces of the drive.



Control panel

To remove the control panel, press the retaining clip at the top (1a) and pull it forward from the top edge (1b).








To reinstall the control panel, put the bottom of the container in position (1a), press the retaining clip at the top (1b) and push the control panel in at the top edge (1c).



For the use of the control panel, see the firmware manual and ACX-AP-x assistant control panels user's manual (3AUA0000085685 [English]).


Type designation label

The type designation label includes IEC and UL (NEC) ratings, appropriate markings and the type designation and serial number, which allow identification of each drive. The type designation label is located on the left side of the drive. An example label is shown below.



Type designation key

The type designation contains information on the specifications and configuration of the drive. You find the type designation on the type designation label attached to the drive. The first digits from the left express the basic configuration, for example, ACS880-11-025A-3. The optional selections are given after that, separated by plus signs, for example, +K454. The main selections are described below. Not all selections are available for all types.



| | CODE | DESCRIPTION | | | |
|---|---------------------------|---|--|--|--|
| | Basic codes | | | | |
| 1 | ACS880 | Product series | | | |
| | 11 | Regenerative wall-mounted drive. When no options are selected: IP21 (UL type 1), cable entry from bottom, ACS-AP-W Assistant control panel with a bluetooth interface, no EMC filter, Primary control program, Safe torque-off, coated boards, multilingual quick guides. | | | |
| 2 | Size | | | | |
| | XXXX | Refer to the rating table, page 169 | | | |
| 3 | Voltage ra | ting | | | |
| | 3 | 380415 V. This is indicated in the type designation label as typical input voltage level $3\!\!\sim\!400$ V AC. | | | |
| | 5 | 380500 V. This is indicated in the type designation label as typical input voltage levels $3\sim400/480/500$ V AC. | | | |
| 4 | Option codes (plus codes) | | | | |
| | Degree of | protection | | | |
| | B056 | IP55 (UL Type 12) | | | |
| | Constructi | ion | | | |
| | C135 | Flange mounting kit | | | |
| | H358 | UK gland plate | | | |
| | P940 | Drive without front covers and bottom plate for cabinet mounting. Includes control panel. | | | |
| | Filters | | | | |
| | E200 | EMC filter for 2nd environment, TN (grounded) system, category C3 | | | |
| | E201 | EMC filter for 2nd environment, IT (ungrounded) system, category C3 | | | |
| | E202 | EMC filter for first environment TN (grounded) system, category C2 | | | |
| | E208 | Common mode filter | | | |

| CODE | DESCRIPTION | | |
|-------------------|--|--|--|
| Control pa | inel | | |
| 0J400 | No control panel. Includes integrated panel holder cover. With + P940 panel holder cover is not included | | |
| J424 | Blank control panel cover (no control panel) | | |
| J425 | ACS-AP-I Assistant control panel | | |
| I/O (one sl | ot available for I/O options) | | |
| L500 | FIO-11 analog I/O extension module | | |
| L501 | FIO-01 digital I/O extension module | | |
| L502 | FEN-31 HTL incremental encoder interface module | | |
| L503 | FDCO-01 optical DDCS communication adapter module | | |
| L508 | FDCO-02 optical DDCS communication adapter module | | |
| L516 | FEN-21 resolver interface module | | |
| L517 | FEN-01 TTL incremental encoder interface module | | |
| L525 | FAIO-01 analog I/O extension module | | |
| L536 | FPTC-01 thermistor protection module | | |
| L537 | FPTC-02 ATEX certified thermistor protection module. Requires option Q971. | | |
| Safety | | | |
| Q971 | ATEX certified safe disconnection function, EX II (2) GD. Sold only with option L357. | | |
| Q972 | Safety functions module FSO-21 Not with Q973. | | |
| Q973 | Safety functions module FSO-12 Not with Q972. | | |
| Q982 | FSPS-21 safety functions fieldbus module. PROFIsafe safety communication. | | |
| Fieldbus adapters | | | |
| K451 | FDNA-01 DeviceNet™ | | |
| K454 | FPBA-01 PROFIBUS DP | | |
| K457 | FCAN-01 CANopen | | |
| K458 | FSCA-01 RS-485 adapter module | | |
| K462 | FCNA-01 ControlNet™ adapter module | | |
| K469 | FECA-01 EtherCAT | | |
| K470 | FEPL-02 Ethernet POWERLINK | | |
| K473 | FENA-11 Ethernet (EtherNet/IP™, Modbus/TCP, PROFINET) | | |
| K475 | FENA-21 2-port Ethernet (EtherNet/IP™, Modbus/TCP, PROFINET) | | |
| K487 | FENA-11 with preloaded EtherNet/IP | | |
| K488 | FENA-11 with preloaded Modbus/TCP | | |
| K489 | FENA-11 with preloaded PROFINET | | |
| K490 | FENA-21 with preloaded EtherNet/IP | | |
| K491 | FENA-21 with preloaded Modbus/TCP | | |

| K492 | FENA-21 with preloaded PROFINET | | |
|--------------|--|--|--|
| | Full set of printed manuals in selected language. Note: The delivered manual set may include manuals in English if the translation is not available. | | |
| R700 | English | | |
| R701 | German | | |
| R702 | Italian | | |
| R703 | Dutch | | |
| R704 | Danish | | |
| R705 | Swedish | | |
| R706 | Finnish | | |
| R707 French | | | |
| R708 | Spanish | | |
| R709 | Portuguese (Portugal) | | |
| R711 | Russian | | |
| R712 | Chinese | | |
| R714 | Turkish | | |
| Specialities | | | |
| P904 | Extended warranty | | |
| P940 | Drive without front covers and bottom plate. Includes panel holder and cable between panel holder and control unit. IP20 (UL type 0) | | |
| P931 | Extended warranty 36 months | | |
| P932 | Extended warranty 60 months | | |

3AXD10000382217



Mechanical installation


Contents of this chapter


The chapter tells how to check the installation site, unpack, check the delivery and install the drive mechanically.

For mechanical installation of flange mounted drives (options +P940 and P944), see

Safety

WARNING! Frame R6 and R8: Lift the drive with a lifting device. Use the lifting eyes of the drive. Do not tilt the drive. The drive is heavy and its center of gravity is high. An overturning drive can cause physical injury.







Examining the installation site


The drive must be installed on the wall. There are three alternative ways to install it:


- · vertically alone. Do not install the drive upside down
- vertically side by side
- horizontally alone, IP21 (UL Type 1) only.

Note 1: The vibration specification in section Ambient conditions on page 192 may not be fulfilled.

Note 2: IP21 (UL Type 1) construction only meets IP20 (UL Type Open) in horizontal orientation.









Check the installation site:

- The installation site is sufficiently ventilated or cooled to remove heat from the drive. See section Losses, cooling data and noise on page 180.
- The operation conditions of the drive meet the specifications given in section Ambient conditions on page 192.
- The wall is as close to vertical as possible, of non-flammable material and strong enough to carry the weight of the drive.
- The floor/material below the installation is non-flammable.
- There is enough free space above and below the drive to enable cooling air flow, service and maintenance. See the required free space tables for each of the different mounting alignments on page 42.

Required tools

To install the drive mechanically, you need the following tools:

- drill with suitable bits
- screwdriver and/or wrench with a set of suitable bits (as appropriate for the installation hardware used)
- tape measure, if you will not be using the provided mounting template.

Moving the drive

Move the drive in its transport package to the installation site. Use a pallet truck when you move a heavy drive package.




· Remove the tray (3) and sleeve (4). · Remove the cover protecting film.


Lift the drive.


Unpacking and examining delivery

The figure below shows the drive package with its contents. Examine that all items are present and there are no signs of damage. Read the data on the type designation label of the drive to make sure that the drive is of the correct type. See section Type designation label on page 36.









- 7 Cardboard sleeve
 - 8 Outer box
 - Pallet 9
 - 10 Drive with factory installed options

To unpack:

2 3

5

- · Cut the straps (5).
- Remove the outer box (4) and cardboard sleeve (7).
- Open the VCI bag (3).

Accessories

PET straps


VCI bag

• Undo the attaching screws (a, b).

Mounting template

Lift the drive.








| | * | | |
|---|---|----|---------------------------------------|
| 1 | Printed quick guides and manuals, multilingual residual voltage warning sticker, Manuals CD | 8 | Cardboard sleeve |
| 2 | Accessories | 9 | Outer box |
| 3 | VCI bag | 10 | Cardboard insert |
| 4 | Bubble wrap | 11 | UL Type 12 hood |
| 5 | Mounting template | 12 | Pallet |
| 6 | PET straps | 13 | Drive with factory installed options. |
| 7 | Plastic bag | - | - |

To unpack:

- Cut the straps (6).
- Remove the outer box (9) and cardboard sleeve (8).
- Remove the VCI bag (3).
- Undo the attaching screws (a, b).
- · Lift the drive.



- Printed quick guides and manuals, 1 multilingual residual voltage warning sticker, Manuals CD
- 2 VCI bag
- 3 Mounting template
- 4 PET straps
- 5 Plastic bag
- 6 Packing bracket


- Tray
- 8 Cardboard sleeve
- 9 Plywood support
- 10 Pallet
- 11, 12 Screw
- 13 Drive with factory installed options

To unpack:

- · Cut the straps (4).
- Remove the tray (7) and cardboard sleeve (8).
- Open the VCI bag (2).
- · Undo the attaching screws (a, b).
- Lift the drive.







| 1 | Printed quick guides and manuals |
|---|----------------------------------|
| | multilingual residual voltage |
| | warning sticker, Manuals CD |

- 2 VCI bag
- 3 Bubble wrap
- 4 Mounting template
- 5 PET straps
- 6 Plastic bag
- 7 Packing bracket

8 Tray


- Cardboard sleeve 9
- 10 Not included
- 11 Plywood support
- 12 Pallet
- 13 UL Type 12 hood
- Drive with factory installed options. 14

To unpack:


- · Cut the straps (5).
- Remove the tray (8) and cardboard sleeve (9).
- · Remove the VCI bag (2).
- Undo the attaching screws (a, b).
- · Lift the drive.

Installing the drive

- 1. Mark the hole locations using the mounting template included in the package.
- 2. Drill the mounting holes.
- 3. Insert anchors or plugs into the holes and start the screws or bolts into the anchors or plugs. Drive the screws or bolts long enough into the wall to make them carry the weight of the drive.
- 4. Position the drive onto the bolts on the wall. For R6 and R8 with option +B056 (UL Type 12), see also step 6.
- 5. Tighten the bolts in the wall securely.



6. Frames R6 and R8 with option +B056 (UL Type 12) installation: Install the hood on top of the drive before you tighten the upper fastening bolts. Place the vertical edge of the hood in between the wall and the drive back plate. Then, tighten the bolts to fasten the hood on its place.



Flange mounting (option +C135)

Instructions for flange mounting are delivered with the flange mounting kit: See Flange mounting kit quick installation guide for frame R3 (3AXD50000133208 [English] or Flange mounting kit guick installation guide for frames R6 and R8 (3AXD50000133611 [English]. For more information on flange mounting, see Flange mounting kit installation supplement (3AXD50000019100 [English]).

Cabinet installation (option +P940)

See ACS880 drive module frames R1 to R9 for cabinet installation (options +P940 and +P944) supplement (3AUA0000145446 [English]).

Planning the electrical installation

Contents of this chapter

This chapter contains instructions for planning the electrical installation of the drive, for example, for checking the compatibility of the motor and drive, selecting cables, protections and cable routing.

Note: The installation must always be designed and made according to applicable local laws and regulations. The manufacturer does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by the manufacturer are not followed, the drive may experience problems that the warranty does not cover.

Selecting the supply disconnecting device

Install a hand-operated input disconnecting device between the AC power source and the drive. The disconnecting device must be of a type that can be locked to the open position for installation and maintenance work.

European Union

To meet the European Union Directives, according to standard EN 60204-1, Safety of *Machinery*, the disconnecting device must be one of the following types:

- switch-disconnector of utilization category AC-23B (EN 60947-3)
- disconnector that has an auxiliary contact that in all cases causes switching devices to break the load circuit before the opening of the main contacts of the disconnector (EN 60947-3)
- circuit breaker suitable for isolation in accordance with EN 60947-2.

North American Market

The disconnecting device must conform to the applicable local safety regulations.

Other regions

The disconnecting device must conform to the applicable local safety regulations.

Checking the compatibility of the motor and drive

Use an asynchronous AC induction motor, permanent magnet synchronous motor, AC induction servomotor or synchronous reluctance motor with the drive. Several induction motors can be connected to the drive at a time but only one permanent magnet motor.

Check that the motor and the drive are compatible. See the section *Ratings* on page 165.

Ensure that the motor withstands the maximum peak voltage in the motor terminals. See the Requirements table on page 55. For basics of protecting the motor insulation and bearings in drive systems, refer to section Protecting the motor insulation and bearings on page 54.

Note:

- Consult the motor manufacturer before using a motor the nominal voltage of which differs from the AC line voltage connected to the drive input.
- The voltage peaks at the motor terminals are relative to the supply voltage of the drive, not the drive output voltage.
- If the motor and drive are not of the same size, consider the following operation limits of the drive control program:
 - motor nominal voltage range 1/6 ... 2 · U_N
 - motor nominal current range 1/6 ... 2 \cdot $I_{\rm N}$ of the drive in DTC control and $0 \dots 2 \cdot I_N$ in scalar control. The control mode is selected by a drive parameter.

Protecting the motor insulation and bearings

The drive employs modern IGBT inverter technology. Regardless of frequency, the drive output comprises pulses of approximately the drive DC bus voltage with a very short rise time. The pulse voltage can almost double at the motor terminals, depending on the attenuation and reflection properties of the motor cable and the terminals. This can cause additional stress on the motor and motor cable insulation.

Modern variable speed drives with their fast rising voltage pulses and high switching frequencies can generate current pulses that flow through the motor bearings. This can gradually erode the bearing races and rolling elements.

Optional du/dt filters protect motor insulation system and reduce bearing currents. Optional common mode filters mainly reduce bearing currents. Insulated N-end (nondrive end) bearings protect the motor bearings.

Requirements table

The following table shows how to select the motor insulation system and when an optional drive du/dt and common mode filters and insulated N-end (non-drive end) motor bearings are required. Ignoring the requirements or improper installation may shorten motor life or damage the motor bearings and voids the warranty.

| Motor Nominal AC supply | | | Requirement for | | |
|--|--|------------------------------------|---|--|--|
| type | voltage | Motor insulation | insulation insulated N-end motor bearings | | |
| | | system | P _N < 100 kW and frame size < IEC 315 | 100 kW ≤ P _N < 350 kW or IEC 315 ≤ frame size < IEC 400 | |
| | | | P _N < 134 hp and frame size < NEMA 500 | 134 hp ≤ <i>P</i> _N < 469 hp or NEMA 500 ≤ frame size ≤ NEMA 580 | |
| ABB moto | ors | | | | |
| Random- | <i>U</i> _N ≤ 500 V | Standard | - | + N | |
| wound M2_,M3_ | $500 \text{ V} < U_{\text{N}} \le 600 \text{ V}$ | Standard | + du/dt | + du/dt + N | |
| and M4 | | or | or | | |
| _ | | Reinforced | - | + N | |
| | $600 \text{ V} < U_{\text{N}} \le 690 \text{ V}$ (cable length \le 150 m) | Reinforced | + du/dt | + du/dt + N | |
| | $600 \text{ V} < U_{\text{N}} \le 690 \text{ V}$ (cable length > 150 m) | Reinforced | - | + N | |
| Form- wound HX_ and AM_ | 380 V < U _N ≤ 690 V | Standard | n.a. | + N + CMF | |
| Old* form- wound HX_ and modular | 380 V < U _N ≤ 690 V | Check with the motor manufacturer. | + du/dt with volta CMF | ges over 500 V + N + | |
| Random- | 0 V < <i>U</i> _N ≤ 500 V | Enamelled | + N + CMF | | |
| wound HX_ and AM_ ** | 500 V < U _N ≤ 690 V | wire with fiber glass taping | + du/dt + N + CM | F | |

| Motor | Nominal AC supply | | Requiremer | nt for | |
|--------------------|--------------------------------|--|---|---|--|
| type | voltage | Motor insulation | ABB du/dt and common mode filters, insulated N-end motor bearings | | |
| | | system | P _N < 100 kW and frame size < IEC 315 | $100 \text{ kW} \leq P_{\text{N}} < 350 \text{ kW}$ or $IEC 315 \leq \text{frame size} <$ $IEC 400$ | |
| | | | P _N < 134 hp and frame size < NEMA 500 | 134 hp ≤ <i>P</i> _N < 469 hp or NEMA 500 ≤ frame size ≤ NEMA 580 | |
| HDP | Consult the motor mar | nufacturer. | | | |
| Non-ABB | | | 1 | | |
| Random- wound | <i>U</i> _N ≤ 420 V | Standard: $\hat{U}_{LL} = 1300 \text{ V}$ | - | + N or CMF | |
| and form- wound | 420 V < U _N ≤ 500 V | Standard: $\hat{U}_{LL} = 1300 \text{ V}$ | + du/dt | + du/dt + (N or CMF) | |
| | | or | | | |
| | | Reinforced: \hat{U}_{LL} = 1600 V, 0.2 microsecond rise time | - | + N or CMF | |
| | 500 V < U _N ≤ 600 V | Reinforced: \hat{U}_{LL} = 1600 V | + du/dt | + du/dt + (N or CMF) | |
| | | or | | | |
| | | Reinforced: \hat{U}_{LL} = 1800 V | - | + N or CMF | |
| | 600 V < U _N ≤ 690 V | Reinforced: \hat{U}_{LL} = 1800 V | + du/dt | + du/dt + N | |
| | | Reinforced: \hat{U}_{LL} = 2000 V, 0.3 microsecond rise time *** | - | N + CMF | |

manufactured before 1.1.1998

For motors manufactured before 1.1.1998, check for additional instructions with the motor manufacturer.

If the intermediate DC circuit voltage of the drive is increased from the nominal level by resistor braking, check with the motor manufacturer if additional output filters are needed in the applied drive operation range.

The abbreviations used in the table are defined below.

| Abbr. | Definition |
|-----------------|---|
| U_{N} | Nominal AC line voltage |
| Û _{LL} | Peak line-to-line voltage at motor terminals which the motor insulation must withstand |
| P_{N} | Motor nominal power |
| du/dt | du/dt filter at the output of the drive. Available from ABB as an optional add-on kit. |
| CMF | Common mode filter. Depending on the drive type, CMF is available from ABB as an optional add-on kit. |
| N | N-end bearing: insulated motor non-drive end bearing |
| n.a. | Motors of this power range are not available as standard units. Consult the motor manufacturer. |

Additional requirements for explosion-safe (EX) motors

If you will use an explosion-safe (EX) motor, follow the rules in the requirements table above. In addition, consult the motor manufacturer for any further requirements.

Additional requirements for ABB motors of types other than M2_, M3_, M4_, HX and AM

Use the selection criteria given for non-ABB motors.

Additional requirements for the braking applications

When the motor brakes the machinery, the intermediate circuit DC voltage of the drive increases, the effect being similar to increasing the motor supply voltage by up to 20 percent. Consider this voltage increase when specifying the motor insulation requirements if the motor will be braking a large part of its operation time.

Example: Motor insulation requirement for a 400 V AC line voltage application must be selected as if the drive were supplied with 480 V.

Additional requirements for ABB high-output and IP23 motors

The rated output power of high output motors is higher than what is stated for the particular frame size in EN 50347 (2001). This table shows the requirements for ABB random-wound motor series (for example, M3AA, M3AP and M3BP).

| Nominal mains | Requirement for | | | | |
|--------------------------------|--|--------------------------------|---|--------------------------------|--|
| voltage (AC line voltage) | Motor ABB du/dt and common mode filters, insulation end motor bearings | | | , | |
| | system | <i>P</i> _N < 100 kW | 100 kW <u>< P_N < 200 kW</u> | <i>P</i> _N ≥ 200 kW | |
| | | P _N < 140 hp | 140 hp <u><</u> <i>P</i> _N < 268 hp | <i>P</i> _N ≥ 268 hp | |
| <i>U</i> _N ≤ 500 V | Standard | - | + N | + N + CMF | |
| 500 V < U _N ≤ 600 V | Standard | + du/dt | + du/dt + N | + du/dt + N + CMF | |
| | or | | | | |
| | Reinforced | - | + N | + N + CMF | |
| 600 V < U _N ≤ 690 V | Reinforced | + du/dt | + du/dt + N | + du/dt + N + CMF | |

Additional requirements for non-ABB high-output and IP23 motors

The rated output power of high output motors is higher than what is stated for the particular frame size in EN 50347 (2001). The table below shows the requirements for random-wound and form-wound non-ABB motors.

| Nominal AC line | Requirement for | | | |
|-------------------------------|-----------------------------------|--|--|--|
| voltage | Motor insulation system | ABB du/dt filter, insulated N-end bearing and ABB common mode filter | | |
| | | P _N < 100 kW or frame size < IEC 315 | 100 kW ≤ P _N < 350 kW or IEC 315 ≤ frame size < IEC 400 | |
| | | P _N < 134 hp or frame size < NEMA 500 | 134 hp ≤ <i>P</i> _N < 469 hp or NEMA 500 ≤ frame size ≤ NEMA 580 | |
| <i>U</i> _N ≤ 420 V | Standard: \hat{U}_{LL} = 1300 V | + N or CMF | + N + CMF | |


| Nominal AC line | Requirement for | | | |
|--|---|---|--|--|
| voltage | Motor insulation ABB du/dt filter, insulated N-end bearing and ABB common mode filter | | | |
| | system | P _N < 100 kW or frame size < IEC 315 | 100 kW $\leq P_{\rm N}$ < 350 kW or IEC 315 \leq frame size < IEC 400 | |
| | | P _N < 134 hp or frame size < NEMA 500 | 134 hp ≤ <i>P</i> _N < 469 hp or NEMA 500 ≤ frame size ≤ NEMA 580 | |
| $420 \text{ V} < U_{\text{N}} \le 500 \text{ V}$ | Standard: Û _{LL} = 1300 V | + du/dt + (N or CMF) | + du/dt + N + CMF | |
| | or | | | |
| | Reinforced: \hat{U}_{LL} = 1600 V, 0.2 microsecond rise time | + N or CMF | + N + CMF | |
| 500 V < U _N ≤ 600 V | Reinforced: \hat{U}_{LL} = 1600 V | + du/dt + (N or CMF) | + du/dt + N + CMF | |
| | or | | | |
| | Reinforced: \hat{U}_{LL} = 1800 V | + N or CMF | + N + CMF | |
| $600 \text{ V} < U_{\text{N}} \le 690 \text{ V}$ | Reinforced: \hat{U}_{LL} = 1800 V | + du/dt + N | + du/dt + N + CMF | |
| | Reinforced: \hat{U}_{LL} = 2000 V, 0.3 microsecond rise time *** | N + CMF | N + CMF | |

If the intermediate DC circuit voltage of the drive is increased from the nominal level by resistor braking, check with the motor manufacturer if additional output filters are needed in the applied drive operation range.

Additional data for calculating the rise time and peak line-to-line voltage

If you need to calculate the actual peak voltage and voltage rise time considering the actual cable length, proceed as follows:

- Peak line-to line voltage: Read the relative \hat{U}_{11}/U_{N} value from the appropriate diagram below and multiply it by the nominal supply voltage (U_N) .
- Voltage rise time: Read the relative values \hat{U}_{11}/U_N and $(du/dt)/U_N$ from the appropriate diagram below. Multiply the values by the nominal supply voltage (U_N) and substitute into equation $t = 0.8 \cdot \hat{U}_{LL}/(du/dt)$.



Additional note for sine filters

Sine filters protect the motor insulation system. Therefore, du/dt filter can be replaced with a sine filter. The peak phase-to-phase voltage with the sine filter is approximately $1.5 \cdot U_{\rm N}$.

Selecting the power cables

General rules

Select the input power and motor cables according to local regulations:

- The input power and the motor cables must be able to carry the corresponding load currents. See section *Ratings* (page 165) for the rated currents.
- The cable must be rated for at least 70 °C (90 °C for IP55 [UL Type 12]) maximum permissible temperature of conductor in continuous use. For US, see Additional US requirements, page 64.
- The conductivity of the PE conductor must be sufficient, see the table on page 62.
- 600 V AC cable is accepted for up to 500 V AC.

To comply with the EMC requirements of the CE mark, use one of the approved cable types in section Recommended power cable types on page 63.

Symmetrical shielded cable reduces electromagnetic emission of the whole drive system as well as the stress on motor insulation, bearing currents and wear.

The protective conductor must always have an adequate conductivity. Unless local wiring regulations state otherwise, the cross-sectional area of the protective conductor must agree with the conditions that require automatic disconnection of the supply required in 411.3.2. of IEC 60364-4-41:2005 and be capable of withstanding the prospective fault current during the disconnection time of the protective device. The cross-sectional area of the protective conductor can either be selected from the table below or calculated according to 543.1 of IEC 60364-5-54. This table shows the minimum cross-sectional area related to the phase conductor size according to IEC 61800-5-1 when the phase conductor and the protective conductor are made of the same metal. If this is not so, the cross-sectional area of the protective earthing

conductor shall be determined in a manner which produces a conductance equivalent to that which results from the application of this table.

| Cross-sectional area of the phase conductors S (mm²) | Minimum cross-sectional area of the corresponding protective conductor $S_p (\mathrm{mm}^2)$ |
|--|---|
| S <u>≤</u> 16 | S |
| 16 < S <u><</u> 35 | 16 |
| 35 < S | S/2 |

Typical power cable sizes

The table below gives copper cable types with concentric copper shield for the drives with nominal current.

| Type ACS880 | Frame | IEC ¹⁾ | | UL ⁴⁾ | |
|---|-------|-------------------|-----------------------------|------------------|--------------------------------|
| ACS880 -11- | size | Cu cable type | Al cable type ²⁾ | Cu cable type | Al cable type ³⁾ |
| | | mm ² | mm ² | AWG/kcmil | AWG/kcmil |
| | | IEC | (1) | US ⁴⁾ | |
| 3-phase U _N = 400 V (380415 V) | | | | | |
| 09A4-3 | R3 | 3×1.5 | - | 14 | - |
| 12A6-3 | R3 | 3×1.5 | - | 14 | - |
| 017A-3 | R3 | 3×6 | - | 10 | - |
| 025A-3 | R3 | 3×6 | - | 10 | - |
| 032A-3 | R6 | 3×10 | 3x16 | 8 | - |
| 038A-3 | R6 | 3×10 | 3x16 | 8 | - |
| 045A-3 | R6 | 3×16 | 3x35 | 6 | - |
| 061A-3 | R6 | 3×25 | 3x35 | 4 | - |
| 072A-3 | R6 | 3×35 | 3x50 | 2 | - |
| 087A-3 | R6 | 3×50 | 3x70 | 2/0 | - |
| 3-phase U _N = 500 V (380500 V) | | | | | |
| 07A6-5 | R3 | 3×1.5 | ı | 14 | - |
| 11A0-5 | R3 | 3×1.5 | ı | 14 | - |
| 014A-5 | R3 | 3×6 | ı | 10 | - |
| 021A-5 | R3 | 3×6 | ı | 10 | - |
| 027A-5 | R6 | 3×10 | 3x16 | 8 | - |
| 034A-5 | R6 | 3×10 | 3x16 | 8 | - |
| 040A-5 | R6 | 3×16 | 3x35 | 6 | - |
| 052A-5 | R6 | 3×25 | 3x35 | 4 | - |
| 065A-5 | R6 | 3×35 | 3x50 | 2 | - |
| 077A-5 | R6 | 3×35 | 3x70 | 2 | - |
| 3AXD00000588487 | | | | | |

¹⁾ The cable sizing is based on max. 9 cables laid on a cable ladder side by side, ambient temperature 30 °C, PVC insulation, surface temperature 70 °C (EN 60204-1 and IEC 60364-5-52/2001). For other conditions, size the cables according to local safety regulations, appropriate input voltage and the load current of the drive. See also page 181 for the accepted cable sizes of the drive.

²⁾ Aluminum cables must not be used with drives of frame size R3.

Note: For ambient temperatures above +40 °C (+104 °F), the power cables must be rated for 90 °C (194 °F) minimum.

See also section Terminal and entry data for the power cables on page 181.

Alternative power cable types

The recommended and the not allowed power cable types to be used with the drive are presented below.

Recommended power cable types



Symmetrical shielded cable with three phase conductors and a concentric PE conductor as the shield. The shield must meet the requirements of IEC 61800-5-1, see page 61. Check with local/state/country electrical codes for allowance.



Symmetrical shielded cable with three phase conductors and a concentric PE conductor as the shield. A separate PE conductor is required if the shield does not meet the requirements of IEC 61800-5-1, see page 61.



Symmetrical shielded cable with three phase conductors and symmetrically constructed PE conductor, and a shield. The PE conductor must meet the requirements of IEC 61800-5-1, see page 61.

Power cable types for limited use



A four-conductor system (three phase conductors and a protective conductor on a cable tray) is not allowed for motor cabling (it is allowed for input cabling).

WARNING! Do not use unshielded single core cables for drives on IT (ungrounded) networks. A dangerous voltage can become present on the nonconductive outer sheath of the cable. This can cause injury or death.



A four-conductor system (three phase conductors and a PE conductor in a PVC conduit) is allowed for input cabling with phase conductor cross-section less than 10 mm² (8 AWG) or motors ≤ 30 kW (40 hp). Not allowed in the USA.

³⁾ In the USA, aluminum cables must not be used.

⁴⁾ The cable sizing is based on NEC Table 310-16 for copper wires, 75 °C (167 °F) wire insulation at 40 °C (104 °F) ambient temperature. Not more than three current-carrying conductors in raceway or cable or earth (directly buried). For other conditions, size the cables according to local safety regulations, appropriate input voltage and the load current of the drive. See also page 181 for the accepted cable sizes of the drive.



Corrugated or EMT cable with three phase conductors and a protective conductor is allowed for motor cabling with phase conductor cross section less than 10 mm² (8 AWG) or motors < 30 kW (40 hp).

Not allowed power cable types




Symmetrical shielded cable with individual shields for each phase conductor is not allowed on any cable size for input or motor cabling.

Motor cable shield

If the motor cable shield is used as the sole protective earth conductor of the motor, make sure that the conductivity of the shield is sufficient. See section General rules on page 67, or IEC 61800-5-1.

To effectively suppress radiated and conducted radio-frequency emissions, the cable shield conductivity must be at least 1/10 of the phase conductor conductivity. The requirements are easily met with a copper or aluminum shield. The minimum requirement of the motor cable shield of the drive is shown below. It consists of a concentric layer of copper wires with an open helix of copper tape or copper wire. The better and tighter the shield, the lower the emission level and bearing currents.



Additional US requirements

Use type MC continuous corrugated aluminum armor cable with symmetrical grounds or shielded power cable for the motor cables if metallic conduit is not used. For the North American market, 600 V AC cable is accepted for up to 500 V AC, 1000 V AC cable is required above 500 V AC (below 600 V AC). For drives rated over 100

amperes, the power cables must be rated for 75 °C (167 °F). For UL Type 12 drives of frame R6, the power cables must be rated for 90 °C (194 °F).

Conduit

Couple separate parts of a conduit together: bridge the joints with a ground conductor bonded to the conduit on each side of the joint. Also bond the conduits to the drive enclosure and motor frame. Use separate conduits for input power, motor, brake resistor, and control wiring. When conduit is employed, type MC continuous corrugated aluminum armor cable or shielded cable is not required. A dedicated ground cable is always required.

Note: Do not run motor wiring from more than one drive in the same conduit.

Armored cable / shielded power cable

Six-conductor (three phases and three ground) type MC continuous corrugated aluminum armor cable with symmetrical grounds is available from the following suppliers (trade names in parentheses):

- Anixter Wire & Cable (Philsheath)
- BICC General Corp (Philsheath)
- Rockbestos Co. (Gardex)
- · Oaknite (CLX).

Shielded power cables are available from the following suppliers:

- Belden
- LAPPKABEL (ÖLFLEX)
- Pirelli


Selecting the control cables

Shielding

All control cables must be shielded.

Use a double-shielded twisted pair cable (figure a below) for analog signals. Employ one individually shielded pair for each signal. Do not use common return for different analog signals.

A double-shielded cable is the best alternative for low-voltage digital signals but single-shielded (b) twisted pair cable is also acceptable.



Signals in separate cables

Run analog and digital signals in separate, shielded cables.

Do not mix 24 V AC/DC and 115/230 V AC signals in the same cable.

Signals allowed to be run in the same cable

Relay-controlled signals, providing their voltage does not exceed 48 V, can be run in the same cables as digital input signals. The relay-controlled signals should be run as twisted pairs.

Relay cable

The cable type with braided metallic screen (for example ÖLFLEX by LAPPKABEL, Germany) has been tested and approved by the manufacturer.

Control panel cable

In remote use, the cable connecting the control panel to the drive must not exceed 100 m (330 ft). If multiple drives are connected, the total length of the panel bus must not exceed 100 m (330 ft).

The cable type tested and approved by the manufacturer is used in control panel option kits. Suitable cables are CAT 5e unshielded or shielded twisted pair cables.

Drive composer PC tool cable

Connect the Drive composer PC tool to the drive through the USB port of the control panel. Use a USB type A (PC) - type B (control panel) cable. The maximum length of the cable is 3 m (9.8 ft).

Routing the cables


General rules

Route the motor cable away from other cable routes. Motor cables of several drives can be run in parallel installed next to each other. The motor cable, input power cable and control cables should be installed on separate travs. Avoid long parallel runs of motor cables with other cables in order to decrease electromagnetic interference caused by the rapid changes in the drive output voltage.

Where control cables must cross power cables, make sure they are arranged at an angle as near to 90 degrees as possible. Do not run extra cables through the drive.


The cable trays must have good electrical bonding to each other and to the grounding electrodes. Aluminum tray systems can be used to improve local equalizing of potential.

A diagram of the cable routing is shown below.



Separate control cable ducts

Lead 24 V and 230 V (120 V) control cables in separate ducts unless the 24 V cable is insulated for 230 V (120 V) or insulated with an insulation sleeving for 230 V (120 V).



Continuous motor cable shield or enclosure for equipment on the motor cable

To minimize the emission level when safety switches, contactors, connection boxes or similar equipment are installed on the motor cable between the drive and the motor:

- European Union: Install the equipment in a metal enclosure with 360 degree grounding for the shields of both the incoming and outgoing cable, or connect the shields of the cables otherwise together.
- US: Install the equipment in a metal enclosure in a way that the conduit or motor cable shielding runs consistently without breaks from the drive to the motor.

Implementing thermal overload and short-circuit protection

Protecting the drive and input power cable in short-circuits

Protect the drive and input cable with fuses as follows:



Size the fuses at the distribution board according to instructions given in chapter Technical data on page 165. The fuses will protect the input cable in short-circuit situations, restrict drive damage and prevent damage to adjoining equipment in case of a short-circuit inside the drive.

Note: If you want to use circuit breakers, contact ABB. Fuses must be used with circuit breakers in the USA.

Protecting the motor and motor cable in short-circuits

The drive protects the motor cable and motor in a short-circuit situation when the motor cable is sized according to the nominal current of the drive. No additional protection devices are needed.

Protecting the drive and the input power and motor cables against thermal overload

The drive protects itself and the input and motor cables against thermal overload when the cables are sized according to the nominal current of the drive. No additional thermal protection devices are needed.

WARNING! If the drive is connected to multiple motors, use a separate circuit breaker or fuses for protecting each motor cable and motor against overload. The drive overload protection is tuned for the total motor load. It may not trip due to an overload in one motor circuit only

Protecting the motor against thermal overload

According to regulations, the motor must be protected against thermal overload and the current must be switched off when overload is detected. The drive includes a motor thermal protection function that protects the motor and switches off the current when necessary. Depending on a drive parameter value, the function either monitors a calculated temperature value (based on a motor thermal model) or an actual

temperature indication given by motor temperature sensors. The user can tune the thermal model further by feeding in additional motor and load data.

The most common temperature sensors are:

- motor sizes IEC180...225: thermal switch, eg, Klixon
- motor sizes IEC200...250 and larger: PTC or Pt100.

For more information, see the firmware manual.

Protecting the drive against ground faults

The drive is equipped with an internal ground fault protective function to protect the unit against ground faults in the motor and motor cable. This is not a personnel safety or a fire protection feature. The ground fault protective function can be reduced with a parameter 31.20 Earth fault.

Residual current device compatibility

The drive is suitable to be used with residual current devices of Type B.

Note: The EMC filter of the drive includes capacitors connected between the main circuit and the frame. These capacitors and long motor cables increase the ground leakage current and may cause fault current circuit breakers to function.

Implementing the Emergency stop function

For safety reasons, install the emergency stop devices at each operator control station and at other operating stations where emergency stop may be needed. Design the emergency stop according to relevant standards.

Note: Pressing the stopkey \bigcirc on the control panel of the drive does not generate an emergency stop of the motor or separate the drive from dangerous potential.

Implementing the Safe torque off function

See chapter Safe torque off function on page 213.

Implementing the safety functions provided with the FSO safety functions module (options +Q972 and +Q973)

The drive can be equipped with a safety functions module as factory installed (option +Q973 or +Q972). The module is also available as a retrofilt kit. The safety functions module enables the implementation of functions such as Safe brake control (SBC), Safe stop 1 (SS1), Safe stop emergency (SSE), Safely limited speed (SLS) and Safe maximum speed (SMS).

The settings of the FSO-xx are at default when delivered from the factory. The wiring of the external safety circuit and configuration of the FSO-xx module are the responsibility of the machine builder.

The FSO-xx reserves the standard Safe torque off (STO) connection of the drive control unit. STO can still be utilized by other safety circuits through the FSO-xx.

For the installation of the safety functions module, see section *Installation of safety* functions modules on page 111. For wiring instructions, safety data and more information on the option, see FSO-12 safety functions module user's manual (3AXD50000015612 [English]) or FSO-21 safety functions module user's manual (3AXD50000015614 [English]).

Declaration of Conformity

See page 195.

Implementing the ATEX-certified Safe motor disconnection function (option +Q971)

With option +Q971, the drive supplies ATEX-certified safe motor disconnection without contactor that uses the drive Safe torque off function. For more information, see ACS880 ATEX-certified Safe disconnection function application guide (3AUA0000132231 [English]). See also section Deratings for special settings in the drive control program on page 171.

Implementing the undervoltage control (power-loss ridethrough)

See the firmware manual.

Using a safety switch between the drive and the motor

ABB recommends to install a safety switch between the permanent magnet motor and the drive output. This is needed to isolate the motor from the drive during maintenance work on the drive.

Using a contactor between the drive and the motor

Implementing the control of the output contactor depends on how you select the drive to operate.

When you have selected to use

DTC control mode and motor ramp stop,

open the contactor as follows:

- 1. Give a stop command to the drive.
- 1. Wait until the drive decelerates the motor to zero speed.
- Open the contactor.

When you have selected to use

DTC control mode and motor coast stop; or scalar control mode.

open the contactor as follows:

- 1. Give a stop command to the drive.
- 2. Open the contactor.


WARNING! When the DTC control mode is in use, never open the output contactor while the drive controls the motor. The DTC control operates extremely fast, much faster than it takes for the contactor to open its contacts. When the contactor starts opening while the drive controls the motor, the DTC control will try to maintain the load current by immediately increasing the drive output voltage to the maximum. This will damage or destroy the contactor completely.

Protecting the contacts of relay outputs

Inductive loads (relays, contactors, motors) cause voltage transients when switched off.

It is highly recommended that inductive loads are equipped with noise attenuating circuits (varistors, RC filters [AC] or diodes [DC]) in order to minimize the EMC emission at switch-off. If not suppressed, the disturbances may connect capacitively or inductively to other conductors in the control cable and form a risk of malfunction in other parts of the system.

Install the protective component as close to the inductive load as possible. Do not install protective components at the relay outputs.



| 1 | Relay outputs |
|---|---------------|
| 2 | Varistor |
| 3 | RC filter |
| 4 | Diode |

Implementing a motor temperature sensor connection



WARNING! IEC 60664 requires double or reinforced insulation between live parts and the surface of accessible parts of electrical equipment which are either non-conductive or conductive but not connected to the protective earth.

To connect a motor temperature sensor and other similar components to the drive, you have four alternatives:

- 1. If there is double or reinforced insulation between the sensor and the live parts of the motor, you can connect the sensor directly to the inputs of the drive.
- 2. If there is basic insulation between the sensor and the live parts of the motor, you can connect the sensor to the inputs of the drive if all circuits connected to the drive's digital and analog inputs (typically extra-low voltage circuits) are protected against contact and insulated with basic insulation from other low-voltage circuits. The insulation must be rated for the same voltage level as the drive main circuit. Note that extra-low voltage circuits (such as 24 V DC) typically do not meet these requirements.
- You can connect the sensor to an extension module with reinforced insulation (eg, CMOD-02) between the sensor connector and the other connectors of the module. See the table below for the sensor insulation requirement. For sensor connection to the extension module, see its manual.
- 4. You can connect a sensor to an external thermistor relay the insulation of which is rated for the main circuit voltage of the drive.

Drive I/O, I/O extension and encoder interface modules

See sections:

- section Al1 and Al2 as Pt100, Pt1000, PTC and KTY84 sensor inputs (XAI, XAO) on page 102
- section DI6 (XDI:6) as PTC sensor input on page 104
- FPTC-01 thermistor protection module (option +L536) for ACS880 drives user's manual (3AXD50000027750 [English])
- FPTC-02 ATEX-certified thermistor protection module Ex II (2) GD (option +L537+Q971) for ACS880 drives user's manual (3AXD50000027782 [English]).

This table shows what temperature sensor types you can connect to the drive I/O extension modules as well as the insulation requirement for the sensor.

| Extension module | | Temperature sensor type | | sensor | Temperature sensor insulation requirement |
|------------------|--|-------------------------|-----|---------------------|---|
| Туре | Insulation/Isolation | PTC | KTY | Pt100 , Pt100 | |
| | | | | 0 | |
| FIO-11 | Galvanic isolation between sensor connector and other connectors (including drive control unit connector) | - | Х | Х | Reinforced insulation |
| FEN- xx | Galvanic isolation between sensor connector and other connectors (including drive control unit connector) | Х | Х | - | Reinforced insulation |

| Extension module | | Temperature sensor type | | sensor | Temperature sensor insulation requirement |
|------------------|---|-------------------------|-----|--------------------------|--|
| Type | Insulation/Isolation | PTC | KTY | Pt100 , Pt100 0 | |
| FAIO- 01 | Basic insulation between sensor connector and drive control unit connector. No insulation between sensor connector and other IO connectors. | Х | Х | Х | Basic insulation. Connectors of extension module other than sensor connector must be left unconnected. |
| FPTC- xx | Reinforced insulation between sensor connector and other connectors (including drive control unit connector). | Х | - | - | No special requirement |

Note: The inaccuracy of the drive analog inputs for Pt100 sensors is 10 $^{\circ}$ C (18 $^{\circ}$ F). If a better accuracy is needed, use the FAIO-01 analog I/O extension module (option +L525).



Electrical installation – IEC

Contents of this chapter

The chapter describes how to check the insulation of the assembly and the compatibility with IT (ungrounded) and corner-grounded TN systems. It then shows how to connect the power and control cables, install optional modules and connect a PC.

Warnings



WARNING! Obey the instructions in chapter Safety instructions on page 13. If you ignore them, injury or death, or damage to the equipment can occur.

Make sure that the drive is disconnected from the input power during installation. If you need to disconnect the drive, wait for 5 minutes after disconnecting the input power before you start the work.




Required tools

- · wire stripper
- screwdriver and/or wrench with a set of suitable bits

Grounding the motor cable shield at the motor end

Ground the motor cable shield at the motor end. For minimum radio frequency interference, ground the motor cable shield 360 degrees at the cable entry of the motor terminal box.



Checking the insulation of the assembly

Drive

Do not make any voltage tolerance or insulation resistance tests on any part of the drive as testing can damage the drive. Every drive has been tested for insulation between the main circuit and the chassis at the factory. Also, there are voltagelimiting circuits inside the drive which cut down the testing voltage automatically.

Input power cable

Check the insulation of the input cable according to local regulations before connecting it to the drive.


Motor and motor cable



- 1. Stop the drive and do the steps in section Precautions before electrical work on page 16 before you start the work.
- Check that the motor cable is disconnected from the drive output terminals T1/U, T2/V and T3/W.
- 3. Measure the insulation resistance between the phase conductors and between each phase conductor and the Protective Earth conductor. Use a measuring voltage of 1000 V DC. The insulation resistance of a motor must exceed 100 Mohm (reference value at 25 °C or 77 °F). For the insulation resistance of other motors, please consult the manufacturer's instructions.



Note: Moisture inside the motor casing will reduce the insulation resistance. If moisture is suspected, dry the motor and repeat the measurement.





Checking the compatibility with IT (ungrounded) and corner-grounded delta systems

EMC filter option +E200 or +E202


The EMC filter option +E200 or +E202 is not suitable for use on an IT (ungrounded) system or on a corner-grounded delta system. Disconnect the EMC filter before connecting the drive on these systems. See section When to disconnect EMC filter (option +E200 or +E202) or ground-to-phase varistor on page 81.

WARNING! Do not install the drive with EMC filter option +E200 or +E202 on an IT system (an ungrounded power system or a high-resistance-grounded [over 30 ohms] power system) or on a corner-grounded delta system. If you do, the system will be connected to ground potential through the EMC filter capacitors of the drive. This can cause danger, or damage the drive.

Note: When EMC filter is disconnected, the drive EMC compatibility is considerably reduced.

Ground-to-phase varistor

The ground-to-phase varistor is not suitable for use on an IT (ungrounded) system or on a corner-grounded delta system. Disconnect the ground-to-phase varistor before you connect the drive on these systems. See section When to disconnect EMC filter (option +E202) or ground-to-phase varistor on page 81.





■ When to disconnect EMC filter (option +E200 or +E202) or ground-to-phase varistor

| Frame size | Symmetrically grounded TN-S systems ¹ | Corner-grounded delta systems ² | IT systems (ungrounded or high-resistance grounded [>30 ohms]) ³ |
|---------------|--|--|---|
| R3 | Do not disconnect | Do not disconnect | Remove EMC and VAR screws |
| R6 | Do not disconnect | Remove EMC DC screw only | Remove EMC AC, EMC DC and VAR screws |
| R8 | Do not disconnect | Remove EMC and VAR screws | Remove EMC and VAR screws |
| = | 1 L1 L2 L3 N PE Drive | 2 L1 L2 L3 PE L2 L3 PE L2 L3 PE | 3 L1 L2 L3 Drive |

Note 1: Corner-grounded systems: Frames R3 and R6 are evaluated for use on corner-grounded systems by UL standards. Not evaluated by IEC standards for use on corner-grounded systems.

Note 2: These are the EMC filter and varistor screws of different drive frame sizes.

| Frame size | EMC filter (+E200, +E202) screws | Ground-to-phase varistor screws |
|------------|----------------------------------|---------------------------------|
| R3 | EMC | VAR |
| R6 | EMC AC, EMC DC | VAR |
| R8 | EMC DC | VAR* |

^{*)} VAR screw functions also as EMC AC screw in frame R8.

The drive can be connected on a TT system under these conditions:

- 1. Residual current device has been installed in the supply system.
- 2. These screws have been disconnected. Otherwise EMC filter and ground-tophase varistor capacitor leakage current will cause the residual current device to trip.

| Frame size | EMC filter (+E200, +E202) screws | Ground-to-phase varistor screws |
|------------|----------------------------------|---------------------------------|
| R3 | EMC | VAR |
| R6 | EMC AC, EMC DC | VAR |
| R8 | EMC DC | VAR* |
| <u></u> | L1 L2 L3 N | |

3AXD10000681917

3. Because the EMC filter screws have been disconnected, ABB does not guarantee the EMC category.



- ABB does not guarantee the functioning of the ground leakage detector built inside the drive.
- 5. In large systems the residual current device can trip without a real reason.

Identifying different types of electrical power systems

To identify the electrical power system type, find out the supply transformer connection. If that is not possible, measure these voltages at the distribution board before you connect power to the drive:

- 1. input voltage line to line (U_{L-L})
- 2. input voltage line 1 to ground (U_{L1-G})
- 3. input voltage line 2 to ground $(U_{1,2-G})$
- 4. input voltage line 3 to ground (U_{L3-G}).


The line-to-ground voltages in relation to the line-to-line voltage of the electrical power system types are shown below.

| U _{L-L} | U _{L1-G} | U _{L2-G} | U _{L3-G} | Electrical power system type |
|------------------|---------------------------------|---------------------------------|---------------------------|--|
| Х | 0.58·X | 0.58·X | 0.58·X | Symmetrically grounded TN system (TN-S system) |
| Х | 1.0·X | 1.0·X | 0 | Corner-grounded delta system (nonsymmetrical) |
| Х | 0.5·X | 0.5·X | 0.57·X | Midpoint-grounded delta system (nonsymmetrical) |
| Х | Varying level versus time | Varying level versus time | Varying level versus time | IT systems (ungrounded or high- resistance-grounded [>30 ohms]) nonsymmetrical |



Disconnecting internal EMC filter (option +E200 or +E202) and ground-to-phase varistor – frame R3


- 1. Stop the drive and do the steps in section *Precautions before electrical work* on page *16* before you start the work.
- 2. Remove the front cover. See page 88.
- 3. Remove the EMC screw.
- 4. Remove the VAR screw.





Disconnecting internal EMC filter (option +E200 or +E202) and ground-to-phase varistor - frame R6


- 1. Stop the drive and do the steps in section *Precautions before electrical work* on page 16 before you start the work.
- 2. Remove the front cover. See page 88.
- 3. Remove the VAR screw.
- 4. Remove the EMC AC and/or EMC DC screws.





Disconnect the EMC filter and/or varistor when necessary. See *When to disconnect EMC filter (option +E200 or +E202) or ground-to-phase varistor* on page 81.


- 1. Stop the drive and do the steps in section *Precautions before electrical work* on page *16* before you start the work.
- 2. Remove the front cover if it is not already removed. See page 88.
- 3. Remove the VAR screw.
- 4. Remove the EMC screw.





Connecting the power cables

Connection diagram



- For alternatives, see section Selecting the supply disconnecting device on page 53.
- 2 Use a separate grounding PE cable (2a) or a cable with a separate PE conductor (2b) if the conductivity of the shield does not meet the requirements for the PE conductor (see page 61). If the protective PE conductor is smaller than 10 mm², you must use a second earthing conductor, see page 18
- 360-degree grounding is recommended if shielded cable is used. Ground the other end of the input cable shield or PE conductor at the distribution board.
- 4 360-degree grounding is required.
- Use a separate grounding cable if the shield does not meet the requirements of IEC 61800-5-1 (see page 61) and there is no symmetrically constructed grounding conductor in the cable (see page 64).


Note:

If there is a symmetrically constructed grounding conductor on the motor cable in addition to the conductive shield, connect the grounding conductor to the grounding terminal at the drive and motor ends.

Do not use an asymmetrically constructed motor cable for motors above 30 kW (see page 61). Connecting its fourth conductor at the motor end increases bearing currents and causes extra wear.

The procedure of connecting the power cables to the standard drive is described below. For the procedure with UK gland plate (option +H358), see also *UK gland plate installation guide* (3AXD50000110711 [English]).

1. For frame R3: Remove the front cover:




For frame R6 and R8 (IP21): Remove the covers as follows:

- To remove the middle front cover, loosen the retaining screw with a screwdriver. Remove the cover.
- Remove the lower front cover

For frame R6 and R8 (IP55): Remove the covers as follows:


- Loosen the screws that attach the front cover to the frame.
- · Remove the cover.







WARNING! Make sure you have disconnected the EMC filter and/or groundto-phase varistor when necessary. See Checking the compatibility with IT (ungrounded) and corner-grounded delta systems page 80.

2. Attach the residual voltage warning sticker in the local language.




3. For frames R6 and R8: Remove the shroud on the power cable terminals,









4. For frame R8: For easier installation, you can remove the side plates.



5. Remove the rubber grommets of the cables to be installed from the cable entry plate.


6. Cut an adequate hole into the rubber grommet. Slide the grommet onto the cable.







7. Prepare the ends of the cables as illustrated in the figure. If you use aluminum cables, put grease to the peeled aluminum cable before connecting it to the drive. Two different motor cable types are shown in the figures (6a, 6b). **Note:** The bare shield will be grounded 360 degrees.








- 8. Put the cable through the hole of the cable entry plate and attach the grommet to the hole.
- 9. Connect the cables:
 - Ground the shield 360 degrees by tightening the clamp of the power cable grounding shelf onto the stripped part of the cable.
 - Connect the twisted shield of the cable to the grounding terminal.
 - Connect the additional PE conductors (if any).
 - Connect the phase conductors of the motor cable to the T1/U, T2/V and T3/W terminals and the phase conductors of the input cable to the T1, T2 and T3 terminals.
 - Tighten the screws to the torque given below in the installation drawing.



R3









Note 1 for frame R8: Install the side plates if removed.


Note 2 for frame R8: The power cable connectors can be detached. For the instructions, see section R8 power cable connection if you detach the connectors on page 97.

10. <u>For frame R6 types bigger than -040A-x:</u> Cut tabs in the shroud for the installed cables. <u>For frame R8:</u> Knock out holes in the shroud for the input cables.



11. Install the shroud onto the power cable connection terminals.








R8 power cable connection if you detach the connectors

The power cable connectors of frame R8 are detachable. If you detach them, you can connect the motor cables with cable lugs and the input cables as follows.


Cable lug installation for T1/U, T2/V, T3/W, UDC+ and UDC-

- Remove the nut that attaches the connector to the terminal post and remove the connector.
- Attach the conductor to a cable lug. Put the cable lug onto the post.
- Tighten the nut to a torque of 30 N·m.



Connecting the condutors to L1, L2 and L3 terminals

- To detach the L1, L2 and L3 terminals, undo the screw (M6×20 Torx combi screw) that attaches the terminal to its busbar.
- Insert the conductor to the terminal. Tighten the conductor to 40 N·m.
- Put the terminal back. Tighten the fastening screw to a torque of 8 N·m.



Connecting the control cables

See section Default I/O connection digram on page 100 for the default I/O connections of the drive.

Connect the cables as described under Control cable connection procedure (IEC) on page 104.



WARNING! Do not connect the +24 V AC cable to the control board ground when the control board is powered using an external 24 V AC supply.



Default I/O connection digram XPOW External power input Wire sizes: +24VI 0.5 ... 2.5 mm² 24 V DC, 2 A GND 2 **Tightening** XAI Reference voltage and analog inputs torques: 0.5 N·m +VREF 10 V DC, R_L 1...10 kohm -VREF -10 V DC, R_I 1...10 kohm for both AGND Ground stranded and Speed reference 0(2)...10 V, Rin > 4 AI1+ solid wiring. 200 kohm 1) 5 AI1-6 Al2+ By default not in use. 0(4)...20 mA, R_{in} = 100 ohm 2) AI2-Al1 current/voltage selection jumper <u>J1</u> J1 J2 J2 Al2 current/voltage selection jumper XAO Analog outputs Motor speed rpm $0...20 \text{ mA}, R_1 <$ A01 AGND 500 ohm 3 AO2 Motor current 0...20 mA, R_1 < 500 ohm AGND XD2D Drive-to-drive link В Drive-to-drive link 2 Α **BGND** 3 Drive-to-drive link termination switch J3 XRO1, XRO2, XRO3 Relay outputs NC Ready 12 250 V AC / 30 V DC COM 2 A 13 NO 21 NC Running 250 V AC / 30 V DC 22 COM 23 NO Faulted(-1) 31 NC COM 250 V AC / 30 V DC NO 2 A 33 Digital interlock XD24 DIIL Run enable +24VD +24 V DC 200 mA 3) Digital input ground 3 DICOM +24VD +24 V DC 200 mA 3) 5 DIOGND Digital input/output ground Ground selection switch XDIO Digital input/outputs DIO1 Output: Ready DIO2 Output: Running XDI Digital inputs See the next page DI1 Stop (0) / Start (1) for the notes. 2 DI2 Forward (0) / Reverse (1) 3 DI3 DI4 Acceleration & deceleration select 4) 4 DI5 Constant speed 1 (1 = On) 5 DI6 By default not in use. 6 XSTO Safe torque off OUT1 Safe torque off. Both circuits must be 2 SGND IN1 closed for the drive to start. IN2 Safety functions module connection X12 X13 Control panel connection X205 Memory unit connection

Notes:

- $^{1)}$ Current [0(4)...20 mA, R_{in} = 100 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input selected with jumper J1. Change of setting requires reboot of control unit.
- ²⁾ Current [0(4)...20 mA, $R_{\rm in}$ = 100 ohm] or voltage [0(2)...10 V, $R_{\rm in}$ > 200 kohm] input selected with jumper J2. Change of setting requires reboot of control unit.
- 3) Total load capacity of these outputs is 4.8 W (200 mA / 24 V) minus the power taken by DIO1 and DIO2.
- 4) 0 = open, 1 = closed

| | Ramp times according to | | | |
|---|----------------------------|--|--|--|
| 0 | Parameters 23.12 and 23.13 | | | |
| 1 | Parameters 23.14 and 23.15 | | | |


Further information on the usage of the connectors and jumpers is given in the sections below. See also section Control unit (ZCU-12) connection data on page 193.

Jumpers and switches

| Jumper/ Switch | Description | Positions |
|-------------------|--|--|
| J1 (Al1) | Determines whether analog input Al1 is used as a current or voltage input. | Current (I) Current (I) Voltage (U) Current (I) |
| J2 (AI2) | Determines whether analog input Al2 is used as a current or voltage input. | Current (I) Current (I) Voltage (U) Current (I) |
| J3 | Drive-to-drive link termination. Must be set to terminated position when the drive is the last unit on the link. | Bus is terminated. Bus is not terminated. |
| J6 | Common digital input ground selection switch. Determines whether DICOM is separated from DIOGND (ie, common reference for digital inputs floats). See <i>Ground isolation diagram</i> on page 196. | DICOM and DIOGND connected (default). DICOM and DIOGND separated. |

Al1 and Al2 as Pt100, Pt1000, PTC and KTY84 sensor inputs (XAI, XAO)

Three Pt100, Pt1000 and PTC sensors or one KTY84 sensor for motor temperature measurement can be connected between an analog input and output as shown below. Leave the other end of the shield unconnected or ground it indirectly via a few nanofarads high-frequency capacitor, for example, 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.



- 1) Set the input type to voltage with switch J1 for analog input Al1or with J2 for analog input Al2. Set the appropriate analog input unit to V (volt) in parameter group 12 Standard Al.
- 2) Select the excitation mode in parameter group 13 Standard AO.

WARNING! As the inputs pictured above are not insulated according to IEC 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment or the temperature sensor must be isolated from the I/O terminals.

External power supply for the control unit (XPOW)

External +24 V (2 A) power supply for the control unit can be connected to terminal block XPOW. Using an external supply is recommended if

- the control board needs to be kept operational during input power breaks, for example, due to continuous fieldbus communication
- immediate restart is needed after power breaks (that is, no control board power up delay is allowed).


Drive-to-drive link (XD2D)

The drive-to-drive link is a daisy-chained RS-485 transmission line that allows basic master/follower communication with one master drive and multiple followers.

Set termination activation jumper J3 (see section *Jumpers and switches* on page 101) next to this terminal block to the ON position on the drives at the ends of the drive-to-drive link. On intermediate drives, set the jumper to the OFF position.

Use shielded twisted-pair cable (~100 ohm, for example, PROFIBUS-compatible cable) for the wiring. For best immunity, high quality cable is recommended. Keep the cable as short as possible; the maximum length of the link is 50 meters (164 ft). Avoid unnecessary loops and running the cable near power cables (such as motor cables).

The following diagram shows the wiring of the drive-to-drive link.




DIIL input (XD24:1)

The DIIL input can be selected as the source of, for example, an emergency stop command or an external event. See the firmware manual for more information.



A PTC sensor can be connected to this input for motor temperature measurement as follows. The sensor resistance must not exceed the threshold resistance of the digital input at the motor normal operating temperature. Do not connect both ends of the cable shield directly to ground. Leave the other end of the shield unconnected or ground it indirectly via a few nanofarads high-frequency capacitor, for example, 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points. See the firmware manual for parameter settings.



WARNING! As the inputs pictured above are not insulated according to IEC 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment or the temperature sensor must be isolated from the I/O terminals.

Safe torque off (XSTO)



For the drive to start, both connections (OUT1 to IN1 and IN2) must be closed. By default, the terminal block has jumpers to close the circuit. Remove the jumpers before connecting an external Safe torque off circuitry to the drive. See chapter *Safe torque off function* on page *213*.

Safety functions module connection (X12)


See section Implementing the safety functions provided with the FSO safety functions module (options +Q972 and +Q973) on page 70, and FSO-12 safety functions module user's manual (3AXD50000015612 [English]) or FSO-21 safety functions module user's manual (3AXD50000015614 [English]).

Control cable connection procedure (IEC)



WARNING! Obey the instructions in chapter *Safety instructions* on page *13*. If you ignore them, injury or death, or damage to the equipment can occur.

- 1. Stop the drive and do the steps in section *Precautions before electrical work* on page 16 before you start the work.
- 2. Remove the front cover(s) if not already removed. See page 88.
- 3. For frame R3, pull the control panel holder up.




- 4. Cut an adequate hole into the rubber grommet and slide the grommet onto the cable. Slide the cable through a hole in the bottom plate and attach the grommet to the hole.
- 5. Route the cable as shown in the figures below.
- 6. Ground the outer shield of the cable 360 degrees under the grounding clamp at the cable entry. Keep the cable unstripped as close to the terminals of the control unit as possible. Secure the cables inside the drive mechanically.
- 7. Frame R3: Leave the pair cable shields and grounding wires unconnected at the drive end, and ground them at the other cable end. Cut any unconnected wires at the drive end. Frame R6 and R8: Ground the pair-cable shields and grounding wire under the clamp below the control unit.




8. Connect the conductors to the appropriate terminals of the control unit (see page 100and tighten to 0.5...0.6 N·m.


Note:

- Leave the other ends of the control cable shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, eq. 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.
- Keep any signal wire pairs twisted as close to the terminals as possible. Twisting the wire with its return wire reduces disturbances caused by inductive coupling.











Installing option modules


Mechanical installation of option modules

See section Overview of power and control connections page 34 for the available slots for each module. Install the option modules as follows:

occur.


WARNING! Obey the instructions in chapter *Safety instructions* on page 13. If you ignore them, physical injury or death, or damage to the equipment can

- 1. Stop the drive and disconnect it from the power line. Wait for 5 minutes and then make sure by measuring that there is no voltage. See section *Precautions before* electrical work on page 16 before you start the work.
- 2. Remove the front cover(s) if not already removed (see page 100).
- 3. For frame R3, pull the control panel holder up.



4. Insert the module carefully into its position on the control unit.

5. Tighten the mounting screw torque of 0.8 N·m. **Note:** The screw tightens the connections and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.



Wiring option modules

See the appropriate optional module manual for specific installation and wiring instructions. See section *Control cable connection procedure (IEC)* on page 104 for the routing of the cables.



Installation of safety functions modules

The safety functions module can be mounted onto Slot 2 on the control unit or, in frames R6 and R8, also next to the control unit.


Installation procedure into Slot 2



WARNING! Obey the instructions in chapter Safety instructions on page 13. If you ignore them, physical injury or death, or damage to the equipment can occur.

- 1. Stop the drive and disconnect it from the power line. Wait for 5 minutes and then make sure by measuring that there is no voltage. See section Precautions before electrical work on page 16 before you start the work.
- 2. Remove the front cover (see the section Connecting the power cables on page 87).
- 3. For frame R3: Pull the control panel stand up.
- 4. Insert the module carefully into its position on the control unit.
- 5. Attach the module with four screws.
- 6. Tighten the grounding screw of the electronics to 0.8 N·m. Note: The grounding screw (a) is essential for fulfilling the EMC requirements and for proper operation of the module.
- 7. Connect the flat cable to connector X110 on the module and to connector X12 on the drive control unit.
- 8. Connect the Safe torque off (STO) cable to connector X111 on the module and to connector XSTO on the drive module control unit as shown in section Wiring on page 214.
- 9. Connect the external +24 V power supply cable to connector X112.
- 10. Connect the other wires as shown in FSO-12 safety functions module user's manual (3AXD50000015612 [English]) or in FSO-21 safety functions module user's manual (3AXD50000015614 [English]).








Installation next to the control unit on frames R6 and R8

occur.

WARNING! Obey the instructions in chapter *Safety instructions* on page *13*. If you ignore them, physical injury or death, or damage to the equipment can

- 1. Stop the drive and disconnect it from the power line. Wait for 5 minutes and then make sure by measuring that there is no voltage. See section *Precautions before* electrical work on page 16 before you start the work.
- 2. Remove the front cover (see page 88.).
- 3. Insert the module carefully into its position.
- 4. Attach the module with four screws.
- 5. Tighten the grounding screw of the electronics to 0.8 N·m. **Note:** Correct installation of the grounding screw (a) is essential for fulfilling the EMC requirements and for proper operation of the module.
- 6. Connect the flat cable to connector X110 on the module and to connector X12 on the drive control unit.
- 7. Connect the Safe torque off (STO) cable to connector X111 on the module and to connector XSTO on the drive module control unit as shown in section Wiring on page 214.
- 8. Connect the external +24 V power supply cable to connector X112.
- 9. Connect the other wires as shown in FSO-12 safety functions module user's manual (3AXD50000015612 [English]) or in FSO-21 safety functions module user's manual (3AXD50000015614 [English]).









Reinstalling cover(s)

After installation, reinstall the covers.








Connecting a PC



WARNING! Do not connect the PC directly to the control panel connector of the control unit. It can cause damage.

Connect a PC to the drive with an USB data cable (USB Type A <-> USB Type Mini-B) as follows:

- 1. Lift the USB connector cover from bottom upwards.
- 2. Insert the USB cable Mini-B plug in the control panel USB connector.
- 3. Insert the USB cable A-plug in the USB connector of the PC. -> The panel displays: USB connected.





Controlling several drives through the panel bus

One control panel (or PC) can be used to control several drives by constructing a panel bus.


Note: If the panel platform does not have two connectors for the panel cable, you need an additional FDPI-02 module for chaining the panel bus. See FDPI-02 diagnostics and panel interface user's manual (3AUA0000113618 [English]).

- 1. Connect the panel to one drive using an Ethernet (eg. CAT5E) cable. Note for IP55 (UL Type 12) drives: Remove the front cover and put the cables through the control cable lead-throughs.
 - Use Menu Settings Edit texts Drive to give a descriptive name to the drive.
 - Use parameter 49.01 to assign the drive with a unique node ID number.
 - Set other parameters in group 49 if necessary.
 - Use parameter **49.06** to validate any changes.

Repeat the above for each drive.

- 2. With the panel connected to one drive, link the drives together using Ethernet cables. (Each panel platform has two connectors.)
- 3. In the last drive, switch bus termination on. With a panel platform, move the terminating switch into the outer position. Termination should be off on all other units.
- 4. On the control panel, switch on the panel bus functionality (Options Select drive - Panel bus). The unit to be controlled can now be selected from the list under Options - Select drive.
- 5. If a PC is connected to the control panel, the drives on the panel bus are automatically displayed in the Drive composer tool.
- 6. For IP55 (UL Type 12) drives, Install the front cover.







Electrical installation – USA

Contents of this chapter

The chapter describes how to check the insulation of the assembly and the compatibility with IT (ungrounded) and corner-grounded TN systems. It then shows how to connect the power and control cables, install optional modules and connect a PC.

Warnings



WARNING! Obey the instructions in chapter *Safety instructions* on page 13. If you ignore them, injury or death, or damage to the equipment can occur.

Make sure that the drive is disconnected from the input power during installation. If you need to disconnect the drive, wait for 5 minutes after disconnecting the input power before you start the work.

Required tools

- wire stripper
- screwdriver and/or wrench with a set of suitable bits

Checking the insulation of the assembly



Do not make any voltage tolerance or insulation resistance tests on any part of the drive as testing can damage the drive. Every drive has been tested for insulation between the main circuit and the chassis at the factory. Also, there are voltagelimiting circuits inside the drive which cut down the testing voltage automatically.



Input power cable


Check the insulation of the input cable according to local regulations before connecting it to the drive.

Motor and motor cable

Check the insulation of the motor and motor cable as follows:

- 1. Stop the drive and do the steps in section *Precautions before electrical work* on page *16* before you start the work.
- Check that the motor cable is disconnected from the drive output terminals T1/U, T2/V and T3/W
- 3. Measure the insulation resistance between the phase conductors and between each phase conductor and the Protective Earth conductor. Use a measuring voltage of 1000 V DC. The insulation resistance of a motor must exceed 100 Mohm (reference value at 25 °C or 77 °F). For the insulation resistance of other motors, please consult the manufacturer's instructions.

Note: Moisture inside the motor casing will reduce the insulation resistance. If moisture is suspected, dry the motor and repeat the measurement.




Checking the compatibility with IT (ungrounded) and corner-grounded delta systems



See section Checking the compatibility with IT (ungrounded) and corner-grounded delta systems on page 80.

Connecting the power cables

Connection diagram



- For alternatives, see section Selecting the supply disconnecting device on page 53.
- If the protective PE conductor is smaller than 10 mm², you must use a second earthing 2 conductor (2a), see page 18.

Note:

If there is a symmetrically constructed grounding conductor on the motor cable in addition to the conductive shield, connect the grounding conductor to the grounding terminal at the drive and motor ends.


Do not use an asymmetrically constructed motor cable for motors above 30 kW (see page 61). Connecting its fourth conductor at the motor end increases bearing currents and causes extra wear.



Connection procedure

The procedure of connecting the power cables to the standard drive is described below. For the procedure with UK gland plate (option +H358), see also *UK gland plate installation guide* (3AXD50000110711 [English]).

1. For frame R3: Remove the front cover:




For frame R6 and R8 (UL Type 1): Remove the covers as follows:

- To remove the middle front cover, loosen the retaining screw with a screwdriver. Remove the cover.
- · Remove the lower front cover

For frame R6 and R8 (UL Type 12): Remove the covers as follows:


- Loosen the screws that attach the front cover to the frame.
- Remove the cover.







WARNING! Make sure you have disconnected the EMC filter and/or groundto-phase varistor when necessary. See Checking the compatibility with IT (ungrounded) and corner-grounded delta systems page 120.

2. Attach the residual voltage warning sticker in the local language.




3. For frames R6 and R8: Remove the shroud on the power cable terminals,







4. For frame R8: For easier installation, you can remove the side plates.




5. Remove the rubber grommets of the cables to be installed from the cable entry plate.


6. Attach the cable conduits to the bottom plate holes.







- 7. Remove the cable shelfs.
- 8. Reinstall the four screw plugs to avoid moisture exchange through the empty holes!





9. Strip the cable ends. (Note the extra length of the grounding conductors.) Slide the cables through the connectors.






10. Connect the grounding conductors to the grounding terminals. Connect the conductors of the input and motor cables. Tighten the screws.



Connect the phase conductors of the motor cable to the T1/U, T2/V and T3/W terminals and the phase conductors of the input cable to the T1, T2 and T3 terminals.


For cable lug installation of frame R8, see section R8 power cable connection if you detach the connectors on page 130.


R3





R6







Note 1 for frame R8: Install the side plates if removed.


Note 2 for frame R8: The power cable connectors can be detached. For the instructions, see section *R8 power cable connection if you detach the connectors* on page *130*.

11. For frame R6 types bigger than -040A-x: Cut tabs in the shroud for the installed cables. For frame R8: Knock out holes in the shroud for the input cables.



12. Install the shroud onto the power cable connection terminals.






R8 power cable connection if you detach the connectors

The power cable connection connectors of frame R8 are detachable. If you detach them, you can connect the motor cables with cable lugs and the input cables as follows. For UL installations, see also section *UL listed cable lugs and tools* on page 182.


Cable lug installation for T1/U, T2/V, T3/W, UDC+ and UDC-:

- Remove the nut that attaches the connector to its terminal post and remove the connector.
- Attach the conductor to the cable lug. Put the cable lug onto the post.
- Tighten the nut to a torque of 30 N·m (22 lbf·ft).



Connecting the connectors to L1, L2 and L3 terminals

- To detach the L1, L2 and L3 terminals, undo the screw (M6×20 Torx combi screw) that attaches the terminal to its busbar.
- Insert the conductor to the terminal. Tighten the conductor to 40 N·m (30 lbf·ft).
- Put the terminal back. Tighten the fastening screw to a torque of 8 N·m (6 lbf·ft).



Connecting the control cables

See section Default I/O connection digram on page 133 for the default I/O connections of the drive.


Connect the cables as described under Control cable connection procedure on page 137.



WARNING! Do not connect the +24 V AC cable to the control board ground when the control board is powered using an external 24 V AC supply.



Default I/O connection digram



Notes:

- 1) Current [0(4)...20 mA, R_{in} = 100 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input selected with jumper J1. Change of setting requires reboot of control unit.
- ²⁾ Current [0(4)...20 mA, R_{in} = 100 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input selected with jumper J2. Change of setting requires reboot of control unit.
- 3) Total load capacity of these outputs is 4.8 W (200 mA / 24 V) minus the power taken by DIO1 and DIO2.
- 4) 0 = open, 1 = closed

| DI4 | Ramp times according to | |
|-----|----------------------------|--|
| 0 | Parameters 23.12 and 23.13 | |
| 1 | Parameters 23.14 and 23.15 | |

Further information on the usage of the connectors and jumpers is given in the sections below. See also section *Control unit (ZCU-12) connection data* on page 193.


Jumpers and switches

| Jumper/ Switch | Description | Positions |
|-------------------|--|--|
| J1 (Al1) | Determines whether analog input Al1 is used as a current or voltage input. | Current (I) |
| | | O Voltage (U) |
| J2 (Al2) | Determines whether analog input Al2 is used as a current or voltage input. | Current (I) Current (I) Current (I) Current (I) |
| | | · · · · · · · · · · · · · · · · · · · |
| J3 | Drive-to-drive link termination. Must be set to terminated position when the drive is the last unit on the link. | Bus is terminated. Bus is not terminated. |
| J6 | Common digital input ground selection switch. Determines whether DICOM is separated from DIOGND (ie, common reference for digital inputs floats). See <i>Ground isolation diagram</i> on page 196. | DICOM and DIOGND connected (default). DICOM and DIOGND separated. |



Al1 and Al2 as Pt100, Pt1000, PTC and KTY84 sensor inputs (XAI, XAO)

Three Pt100, Pt1000 and PTC sensors or one KTY84 sensor for motor temperature measurement can be connected between an analog input and output as shown below. Leave the other end of the shield unconnected or ground it indirectly via a few nanofarads high-frequency capacitor, for example, 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.



- 1) Set the input type to voltage with switch J1 for analog input Al1or with J2 for analog input Al2. Set the appropriate analog input unit to V (volt) in parameter group 12 Standard Al.
- 2) Select the excitation mode in parameter group 13 Standard AO.

WARNING! As the inputs pictured above are not insulated according to IEC 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment or the temperature sensor must be isolated from the I/O terminals.

External power supply for the control unit (XPOW)

External +24 V (2 A) power supply for the control unit can be connected to terminal block XPOW. Using an external supply is recommended if

- the control board needs to be kept operational during input power breaks, for example, due to continuous fieldbus communication
- immediate restart is needed after power breaks (that is, no control board power up delay is allowed).




Drive-to-drive link (XD2D)

The drive-to-drive link is a daisy-chained RS-485 transmission line that allows basic master/follower communication with one master drive and multiple followers.

Set termination activation jumper J3 (see section *Jumpers and switches* on page 134) next to this terminal block to the ON position on the drives at the ends of the drive-to-drive link. On intermediate drives, set the jumper to the OFF position.

Use shielded twisted-pair cable (~100 ohm, for example, PROFIBUS-compatible cable) for the wiring. For best immunity, high quality cable is recommended. Keep the cable as short as possible; the maximum length of the link is 50 meters (164 ft). Avoid unnecessary loops and running the cable near power cables (such as motor cables).

The following diagram shows the wiring of the drive-to-drive link.




DIIL input (XD24:1)

The DIIL input can be selected as the source of, for example, an emergency stop command or an external event. See the firmware manual for more information.



DI6 (XDI:6) as PTC sensor input

A PTC sensor can be connected to this input for motor temperature measurement as follows. The sensor resistance must not exceed the threshold resistance of the digital input at the motor normal operating temperature. Do not connect both ends of the cable shield directly to ground. Leave the other end of the shield unconnected or ground it indirectly via a few nanofarads high-frequency capacitor, for example, 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points. See the firmware manual for parameter settings.



WARNING! As the inputs pictured above are not insulated according to IEC 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment or the temperature sensor must be isolated from the I/O terminals.

Safe torque off (XSTO)

For the drive to start, both connections (OUT1 to IN1 and IN2) must be closed. By default, the terminal block has jumpers to close the circuit. Remove the jumpers before connecting an external Safe torque off circuitry to the drive. See chapter Safe torque off function on page 213.

Safety functions module connection (X12)

See section Implementing the safety functions provided with the FSO safety functions module (options +Q972 and +Q973) on page 70, and FSO-12 safety functions module user's manual (3AXD50000015612 [English]) or FSO-21 safety functions module user's manual (3AXD50000015614 [English]).


Control cable connection procedure



WARNING! Obey the instructions in chapter Safety instructions on page 13. If you ignore them, injury or death, or damage to the equipment can occur.




- Stop the drive and do the steps in section Precautions before electrical work on page 16 before you start the work.
- 2. Remove the front cover(s) if not already removed. See page 122.
- 3. For frame R3, pull the control panel holder up.





- 4. Cut an adequate hole into the rubber grommet and slide the grommet onto the cable. Slide the cable through a hole in the bottom plate and attach the grommet to the hole.
- 5. Route the cable as shown in the figures below.
- 6. Secure the cables inside the drive mechanically.
- 7. <u>Frame R3</u>: Leave the pair cable shields and grounding wires unconnected at the drive end, and ground them at the other cable end. Cut any unconnected wires at the drive end. <u>Frame R6 and R8</u>: Ground the pair-cable shields and grounding wire under the clamp below the control unit.
- 8. Connect the conductors to the appropriate terminals of the control unit (see page 133and tighten to 0.5...0.6 N·m (0.4 lbf·ft).


Note:


- Leave the other ends of the control cable shields unconnected or ground them
 indirectly via a high-frequency capacitor with a few nanofarads, eg, 3.3 nF / 630 V.
 The shield can also be grounded directly at both ends if they are in the same
 ground line with no significant voltage drop between the end points.
- Keep any signal wire pairs twisted as close to the terminals as possible. Twisting
 the wire with its return wire reduces disturbances caused by inductive coupling.













Installing option modules

See section Installing option modules on page 109.

Reinstalling cover(s)

After installation, reinstall the covers.





Connecting a PC

See section Connecting a PC on page 116.

Controlling several drives through the panel bus

See section Controlling several drives through the panel bus on page 117.







Installation checklist

Contents of this chapter

This chapter contains an installation checklist which you must complete before you start up the drive.

Warnings



WARNING! Obey the instructions in chapter *Safety instructions* on page 13. If you ignore them, injury or death, or damage to the equipment can occur.

Checklist

Do the steps in section Precautions before electrical work on page 16 before you start the work. Go through the checklist together with another person.

| Check that | > |
|--|---|
| The ambient operating conditions meet the specification in section <i>Ambient conditions</i> on page 192. | |
| If the drive will be connected to a corner-grounded TN system: The internal EMC filter has been disconnected. See section Checking the compatibility with IT (ungrounded) and corner-grounded delta systems on page 80. | |
| If the drive will be connected to an IT (ungrounded) system: The internal EMC filter and the ground-to-phase varistor has been disconnected. See section Checking the compatibility with IT (ungrounded) and corner-grounded delta systems on page 80. | |

| Check that | √ |
|--|----------|
| If the drive has not been powered (either in storage or unused) over tree years: The electrolytic DC capacitors in the DC link of the drive have been reformed. See section <i>Reforming the capacitors</i> on page 160. | |
| There is an adequately sized protective earth (ground) conductor between the drive and the switchboard. | |
| There is an adequately sized protective earth (ground) conductor between the motor and the drive. | |
| All protective earth (ground) conductors have been connected to the appropriate terminals and the terminals have been tightened (pull conductors to check). | |
| The supply voltage matches the nominal input voltage of the drive. Check the type designation label. | |
| The input power cable has been connected to appropriate terminals, the phase order is correct, and the terminals have been properly tightened. (Pull conductors to check.) | |
| Appropriate supply fuses and disconnector have been installed. | |
| The motor cable has been connected to appropriate terminals, the phase order is right, and the terminals have been tightened. (Pull conductors to check.) | |
| The brake resistor cable (if present) has been connected to appropriate terminals, and the terminals have been tightened. (Pull conductors to check.) | |
| The motor cable (and brake resistor cable, if present) has been routed away from other cables. | |
| The control cables (if any) have been connected to the control board. | |
| If a drive bypass connection will be used: The direct-on-line contactor of the motor and the drive output contactor are either mechanically or electrically interlocked (cannot be closed simultaneously). | |
| There are no tools, foreign objects or dust from drilling inside the drive. | |
| Drive and motor connection box covers are in place. | |
| The motor and the driven equipment are ready for start-up. | |

Start-up

Contents of this chapter

This chapter describes the start-up procedure of the drive.

Start-up procedure

- Run setup of the drive control program according to the start-up instructions given in Quick start-up guide for ACS880 primary control program (3AUA0000098062 [English]) or in the firmware manual.
 - For drives with ABB sine filter, check that parameter 95.15 Special HW settings is set to ABB sine filter. For other sine filters, see Sine filter hardware manual (3AXD50000016814 [English]).
 - For drives with ABB motors in explosive atmospheres, see also ACS880 drives with ABB motors in explosive atmospheres (3AXD50000019585 [English]).
- 2. Validate the Safe torque off function according to the instructions given in chapter *Safe torque off function* on page *213*.
- Validate the safety functions (options +Q923, +Q973 and Q982) as described in FSO-12 safety functions module user's manual (3AXD50000015612 [English]), FSO-21 safety functions module user's manual (3AXD50000015614 [English]) or FSPS-21 safety functions fieldbus module user's manual (3AXD50000158638 [English]).



Maintenance and hardware diagnostics

Contents of this chapter

The chapter contains preventive maintenance instructions and LED indicator descriptions.

Maintenance intervals

The table below shows the maintenance tasks which can be done by the end user. The complete maintenance schedule is available on the Internet (www.abb.com/drivesservices). For more information, consult your local ABB Service representative (www.abb.com/searchchannels).

Maintenance and component replacement intervals are based on the assumption that the equipment is operated within the specified ratings and ambient conditions. ABB recommends annual drive inspections to ensure the highest reliability and optimum performance.

Note: Long term operation near the specified maximum ratings or ambient conditions may require shorter maintenance intervals for certain components. Consult your local ABB Service representative for additional maintenance recommendations.

Description of symbols

| Action | Description |
|--------|--|
| I | Visual Inspection and maintenance action if needed |
| Р | Performance of on/off-site work (commissioning, tests, measurements or other work) |
| R | Replacement of component |

Recommended annual maintenance actions by the user

| Action | Description |
|--------|--|
| Р | Quality of supply voltage |
| I | Spare parts |
| Р | Capacitor reforming, spare modules and spare capacitors (page 160) |
| I | Tightness of terminals |
| I | Dustiness, corrosion or temperature |
| Р | Heat sink cleaning (page 151) |

Recommended maintenance actions by the user

| Component | Years from start-up | | | | | | | |
|---|---------------------|---|---|----|----|----|----|--|
| | 3 | 6 | 9 | 12 | 15 | 18 | 21 | |
| Cooling | | | | | | | | |
| Main cooling fan | | | | | | | | |
| Main cooling fans | | | R | | | R | | |
| Auxiliary cooling fan | | | | | | | | |
| Auxiliary cooling fan | | | R | | | R | | |
| Second auxiliary cooling fan (IP55, UL Type 12) | | | R | | | R | | |
| Aging | | | | | | | | |
| Control unit battery (real-time clock) | | R | | R | | R | | |
| Control panel battery (real-time clock) | | | R | | | R | | |

4FPS10000309652

Heatsink

The drive heatsink fins pick up dust from the cooling air. The drive can run into overtemperature warnings and faults if the heatsink is not clean. When necessary. clean the heatsink as follows.

WARNING! Obey the instructions in chapter *Safety instructions* on page 13. Ignoring the instructions can cause physical injury or death, or damage to the equipment.

WARNING! Use a vacuum cleaner with antistatic hose and nozzle. Using a As normal vacuum cleaner creates static discharges which can damage circuit boards

- 1. Stop the drive and disconnect it from the power line. Wait for 5 minutes and then make sure by measuring that there is no voltage. See section *Precautions before* electrical work on page 16 before you start the work.
- 2. Remove the cooling fan(s). See section *Fans* on page 151.
- 3. Blow clean, dry and oil free compressed air from bottom to top and simultaneously use a vacuum cleaner at the air outlet to trap the dust.

Note: If there is a risk of dust entering adjoining equipment, perform the cleaning in another room.

4. Reinstall the cooling fan(s).

Fans

See section Maintenance intervals on page 149 for the fan replacement interval in average operation conditions.

In a speed-controlled fan, the speed of the fan matches the cooling needs. This increases the life span of the fan.


Main fans are speed controlled. When the drive is stopped, the main fan is kept running at low speed to cool the control board. IP21 (UL Type 1) frames R6 and R8 and all IP55 (UL Type 12) frames have auxiliary fans that are not speed controlled and run all the time when the control board is powered.


Replacement fans are available from the manufacturer. Do not use other than specified spare parts.

Replacing the main cooling fan, frame R3

WARNING! Obey the instructions in chapter *Safety instructions* on page *13*. If you ignore them, physical injury or death, or damage to the equipment can

- Stop the drive and disconnect it from the power line. Wait for 5 minutes and then
 make sure by measuring that there is no voltage. See section *Precautions before*electrical work on page 16 before you start the work.
- 2. To release the locking, turn clockwise with a screwdriver.
- 3. Turn the fan assembly off.
- Install the new fan in reverse order.







Replacing the main cooling fan, frame R6

WARNING! Obey the instructions in chapter *Safety instructions* on page 13. If you ignore them, physical injury or death, or damage to the equipment can

- 1. Stop the drive and disconnect it from the power line. Wait for 5 minutes and then make sure by measuring that there is no voltage. See section Precautions before electrical work on page 16 before you start the work.
- 2. Lever the fan assembly off the drive frame with for example a screwdriver (2a) and pull out the fan assembly (2b)
- 3. Pull the fan assembly down.
- 4. Unplug the fan power supply and grounding wires from the drive.
- 5. Install the new fan in reverse order.







Replacing the main cooling fan, frame R8

WARNING! Obey the instructions in chapter *Safety instructions* on page 13. Ignoring the instructions can cause physical injury or death, or damage to the equipment.

- Stop the drive and disconnect it from the power line. Wait for 5 minutes and then
 make sure by measuring that there is no voltage. See section *Precautions before*electrical work on page 16 before you start the work.
- 2. Undo the mounting screws of the fan assembly.
- 3. Unplug the fan power supply and grounding wires from the drive.
- 4. Pull the fan assembly down.
- 5. Undo the mounting screws of the fan.
- 6. Install the new fan in reverse order.






Replacing the auxiliary cooling fan, IP55 (UL Type 12) frame R3

occur.

WARNING! Obey the instructions in chapter Safety instructions on page 13. If you ignore them, physical injury or death, or damage to the equipment can

- 1. Stop the drive and disconnect it from the power line. Wait for 5 minutes and then make sure by measuring that there is no voltage. See section Precautions before electrical work on page 16 before you start the work.
- 2. Remove the control panel, see section *Control panel* on page 35.
- 3. Remove the front cover (see page 88).
- 4. Release the retaining clips.
- 5. Lift the fan off.
- 6. Unplug fan power supply wires.
- 7. Install the new fan in reverse order. **Note:** Make sure that the arrow on the fan points down.





Replacing the auxiliary cooling fan, frame R6

OCCUI.

WARNING! Obey the instructions in chapter *Safety instructions* on page *13*. If you ignore them, physical injury or death, or damage to the equipment can

- Stop the drive and disconnect it from the power line. Wait for 5 minutes and then
 make sure by measuring that there is no voltage. See section *Precautions before*electrical work on page 16 before you start the work.
- 2. Remove the upper front covers. See section Connection procedure on page 88.
- Release the retaining clips.
- 4. Lift the fan off.
- 5. Unplug fan power supply wires.
- 6. Remove the grille from the fan.
- Install the new fan in reverse order.
 Note: Make sure that the arrow on the fan points up.
- 8. Reinstall the front covers. See section Reinstalling cover(s) on page 115.







Replacing the auxiliary cooling fan, frame R8

occur.

WARNING! Obey the instructions in chapter Safety instructions on page 13. If you ignore them, physical injury or death, or damage to the equipment can

- 1. Stop the drive and disconnect it from the power line. Wait for 5 minutes and then make sure by measuring that there is no voltage. See section Precautions before electrical work on page 16 before you start the work.
- 2. Remove the upper front covers. See section *Connection procedure* on page 88.
- 3. Release the retaining clips.
- 4. Lift the fan off.
- 5. Unplug fan power supply wires.
- 6. Remove the grille.
- 7. Install the new fan in reverse order. **Note:** Make sure that the arrow on the fan points up.
- 8. Replace the front covers.






Replacing the second auxiliary cooling fan IP55 (UL Type 12), frame R8

WARNING! Obey the instructions in chapter Safety instructions on page 13. If you ignore them, physical injury or death, or damage to the equipment can occur.

- 1. Stop the drive and disconnect it from the power line. Wait for 5 minutes and then make sure by measuring that there is no voltage. See section *Precautions before* electrical work on page 16 before you start the work.
- 2. Remove the IP55 front cover.
- Remove the lower front cover from the IP55 cover.
- 4. Unplug the fan power supply wires.
- Remove the fan.
- 6. Install the new fan in reverse order. Make sure that the arrow on the fan points up.



Capacitors

The drive intermediate DC circuit employs several electrolytic capacitors. Their lifespan depends on the operating time of the drive, loading and ambient temperature. Capacitor life can be prolonged by lowering the ambient temperature.

Capacitor failure is usually followed by damage to the drive and an input cable fuse failure, or a fault trip. Contact the manufacturer if capacitor failure is suspected. Replacements are available from the manufacturer. Do not use other than specified spare parts.

Reforming the capacitors

Reform the capacitors if the drive has not been powered for three years or more. The reforming is done by powering the unit not loaded for 60 minutes. See section Type designation label on page 36 for how to find out the manufacturing date from the serial number. For information on reforming the capacitors, see Converter module capacitor reforming instructions (3BFE64059629 [English]).

Memory unit

When a drive is replaced, the parameter settings can be retained by transferring the memory unit from the defective drive to the new drive. The memory unit is located on the control unit.




WARNING! Do not remove or insert a memory unit when the drive is powered or the control unit is powered from an external power source.

After power-up, the drive will scan the memory unit. If different parameter settings are detected, they are copied to the drive. This may take several minutes.

Replacing the memory unit

Pull the clip at the back of the memory unit up and take the unit off. Replace the unit in reverse order.



Replacing the control unit battery

For instructions how to replace the control unit battery, contact an ABB service center.

Control panel

Cleaning the control panel

Use a soft damp cloth to clean the control panel. Avoid harsh cleaners which could scratch the display window.

Replacing the battery in the control panel

A battery is used in all control panels to keep the clock operating in memory during power interruptions.

The expected life for the battery is greater than ten years.

Note: The battery is NOT required for any control panel or drive functions, except the clock.


- 1. Remove the control panel from the drive. See section *Control panel* on page 35.
- 2. To remove the battery, use a coin to rotate the battery cover on the back of the control panel.
- 3. Replace the battery with type CR2032. Dispose the old battery according to local disposal rules or applicable laws.



LEDs

Drive LEDs

There is a green POWER and a red FAULT LED visible when the control panel is removed. If a control panel is attached to the drive, switch to remote control (otherwise a fault will be generated), and then remove the panel to be able to see the LEDs .



The table below describes the drive LED indications.

| LEDs off | LED lit and | d steady | LED blink | nking | | |
|----------|------------------|--|------------------|--|--|--|
| No power | Green (POWER) | Power supply on the board OK | Green (POWER) | Blinking: Drive in an alarm state Blinking for one second: Drive selected on the control panel when multiple drives are connected to the same panel bus. | | |
| | Red (FAULT) | Active fault in the drive. To reset the fault, press RESET from the control panel or switch off the drive power. | Red (FAULT) | Active fault in the drive. To reset the fault, switch off the drive power. | | |

Control panel LEDs

The assistant control panel has one LED. For the meaning of the LED indications, see ACX-AP-x assistant control panels user's manual (3AUA0000085685 [English]).





Technical data

Contents of this chapter

The chapter contains the technical specifications of the drive, for example ratings, sizes and technical requirements as well as provisions for fulfilling the requirements for CE, UL and other approval marks.



Ratings

IEC ratings

| Type | Frame | | Max. | Арр. | Output ratings | | | | | |
|----------------|--------------------|-----------------------|------------------|-------|----------------|----------------|-----------------|-----------------|-----------------|-----------------|
| ACS880 -11- | size | rating | current | power | Nomin | al use | Light-d | uty use | Heavy-duty use | |
| | | <i>I</i> ₁ | I _{max} | SN | 12 | P _N | / _{Ld} | P _{Ld} | / _{Hd} | P _{Hd} |
| | | Α | Α | kVA | Α | kW | Α | kW | Α | kW |
| 3-phase U | _N = 400 | V (380. | 415 V) | | | | | | | |
| 09A4-3 | R3 | 8 | 13.6 | 6.9 | 10.0 | 4.0 | 9.5 | 4.0 | 8.0 | 3.0 |
| 12A6-3 | R3 | 10 | 17.0 | 8.9 | 12.9 | 5.5 | 12.0 | 5.5 | 10.0 | 4.0 |
| 017A-3 | R3 | 14 | 21.9 | 12 | 17.0 | 7.5 | 16 | 7.5 | 12.9 | 5.4 |
| 025A-3 | R3 | 20 | 28.8 | 17 | 25 | 11 | 24 | 11 | 17 | 7.5 |
| 032A-3 | R6 | 27 | 42.5 | 22 | 32 | 15 | 30 | 15 | 25 | 11 |
| 038A-3 | R6 | 33 | 54.4 | 26 | 38 | 18.5 | 36 | 18.5 | 32 | 15.0 |
| 045A-3 | R6 | 40 | 64.6 | 31 | 45 | 22 | 43 | 22 | 38 | 18.5 |
| 061A-3 | R6 | 51 | 76.5 | 42 | 61 | 30 | 58 | 30 | 45 | 22 |
| 072A-3 | R6 | 63 | 103.7 | 50 | 72 | 37 | 68 | 37 | 61 | 30 |
| 087A-3 | R6 | 76 | 122.4 | 60 | 87 | 45 | 83 | 45 | 72 | 37 |
| 105A-3 | R8 | 88 | 148 | 73 | 105 | 55 | 100 | 55 | 87 | 45 |
| 145A-3 | R8 | 120 | 178 | 100 | 145 | 75 | 138 | 75 | 105 | 55 |
| 169A-3 | R8 | 144 | 247 | 117 | 169 | 90 | 161 | 90 | 145 | 75 |
| 206A-3 | R8 | 176 | 287 | 143 | 206 | 110 | 196 | 110 | 169 | 90 |

| Туре | Frame | | Max. | App. | Output ratings | | | | | |
|----------------|----------------------|-----------------------|------------------|-------|----------------|----------------|-----------------|----------|-----------------|-----------------|
| ACS880 -11- | size | rating | current | power | Nomin | al use | Light-d | uty use | Heavy-c | luty use |
| | | <i>I</i> ₁ | I _{max} | SN | 12 | P _N | / _{Ld} | P_{Ld} | / _{Hd} | P _{Hd} |
| | | Α | Α | kVA | Α | kW | Α | kW | Α | kW |
| 3-phase U | ' _N = 500 | V (380. | 500 V) | | | | | | | |
| 07A6-5 | R3 | 7 | 9.5 | 6.6 | 7.6 | 4.0 | 7.2 | 4.0 | 5.2 | 2.2 |
| 11A0-5 | R3 | 9 | 13.8 | 9.5 | 11.0 | 5.5 | 10.4 | 5.5 | 7.6 | 4.0 |
| 014A-5 | R3 | 12 | 18.7 | 12 | 14 | 7.5 | 13 | 7.5 | 11.0 | 5.5 |
| 021A-5 | R3 | 17 | 26.3 | 18 | 21 | 11.0 | 19 | 11.0 | 14 | 7.5 |
| 027A-5* | R6 | 24 | 35.7 | 23 | 27 | 15.0 | 26 | 15.0 | 21 | 11.0 |
| 034A-5* | R6 | 29 | 45.9 | 29 | 34 | 18.5 | 32 | 18.5 | 27 | 15.0 |
| 040A-5* | R6 | 34 | 57.8 | 35 | 40 | 22.0 | 38 | 22.0 | 34 | 18.5 |
| 052A-5* | R6 | 44 | 68.0 | 45 | 52 | 30.0 | 49 | 30.0 | 40 | 22.0 |
| 065A-5* | R6 | 54 | 88.4 | 56 | 65 | 37.0 | 62 | 37.0 | 52 | 30.0 |
| 077A-5* | R6 | 66 | 110.5 | 67 | 77 | 45.0 | 73 | 45.0 | 65 | 37.0 |
| 101A-5 | R8 | 72 | 148 | 87 | 101 | 55.0 | 91 | 55.0 | 77 | 45.0 |
| 124A-5 | R8 | 88 | 178 | 107 | 124 | 75.0 | 118 | 75.0 | 96 | 55.0 |
| 156A-5 | R8 | 120 | 247 | 137 | 156 | 90.0 | 148 | 90.0 | 124 | 75.0 |
| 180A-5 | R8 | 144 | 287 | 156 | 180 | 110.0 | 171 | 110.0 | 156 | 90.0 |

3AXD00000588487



^{*} These ratings are not to be used for drives with degree of protection of IP55 (UL Type 12) option +B056.

UL (NEC) ratings

| Туре | Frame | Input | Max. | App. | Output ratings | | | | | |
|----------------|-------------------|-----------------------|------------------|-------|-----------------|----------|-----------------|-----------------|--|--|
| ACS880 -11- | size | rating | current | power | Nomin | al use | Heavy-c | Heavy-duty use | | |
| | | <i>I</i> ₁ | I _{max} | SN | / _{Ld} | P_{Ld} | / _{Hd} | P _{Hd} | | |
| | | Α | Α | kVA | Α | hp | Α | hp | | |
| 3-phase L | $J_{\rm N} = 480$ | V (44048 | 30 V) | | | | | | | |
| 07A6-5 | R3 | 5,8 | 9.5 | 6.6 | 7.6 | 5.0 | 5.2 | 3.0 | | |
| 11A0-5 | R3 | 7,8 | 13.8 | 9.5 | 11.0 | 7.5 | 7.6 | 5.0 | | |
| 014A-5 | R3 | 10,6 | 18.7 | 12 | 14.0 | 10.0 | 11.0 | 7.5 | | |
| 021A-5 | R3 | 15,6 | 26.3 | 18 | 21.0 | 15.0 | 14.0 | 10.0 | | |
| 027A-5* | R6 | 21,3 | 35.7 | 23 | 27.0 | 20.0 | 21.0 | 15.0 | | |
| 034A-5* | R6 | 26,2 | 45.9 | 29 | 34.0 | 25.0 | 27.0 | 20.0 | | |
| 040A-5* | R6 | 31,2 | 57.8 | 35 | 40.0 | 30.0 | 34.0 | 25.0 | | |
| 052A-5* | R6 | 40,1 | 68.0 | 45 | 52.0 | 40.0 | 40.0 | 30.0 | | |
| 065A-5* | R6 | 49,5 | 88.4 | 56 | 65.0 | 50.0 | 52.0 | 40.0 | | |
| 077A-5* | R6 | 60,2 | 110.5 | 67 | 77.0 | 60.0 | 65.0 | 50.0 | | |
| 101A-5 | R8 | 74 | 148 | 87 | 96.0 | 75.0 | 77.0 | 60.0 | | |
| 124A-5 | R8 | 100 | 178 | 107 | 124.0 | 100.0 | 96.0 | 75.0 | | |
| 156A-5 | R8 | 120 | 247 | 137 | 156.0 | 125.0 | 124.0 | 100.0 | | |
| 180A-5 | R8 | 147 | 287 | 156 | 180.0 | 150.0 | 156.0 | 125.0 | | |

3AXD00000588487

^{*} These ratings are not to be used for drives with degree of protection of IP55 (UL Type 12) option +B056.

See definitions and notes on page 167.

Definitions

- U_{N} Nominal voltage of the drive. For input voltage range, see section *Electrical power* network specification on page 183.
- Nominal input current (rms) at 40 °C (104 °F) 11
- Maximum output current. Available for two seconds at start. Then as long as allowed I_{max} by drive temperature.
- 12 Nominal output current. Maximum continuous rms output current allowed (no overload). This is indicated in the type designation label as output current I2.
- Nominal power of the drive. Typical motor power (no overloading). The kilowatt P_{N} ratings apply to most IEC 4-pole motors. The horsepower ratings apply to most NEMA 4-pole motors.
- Maximum current with 10% overload, allowed for one minute every five minutes *l*1 d
- P_{Ld} Typical motor power in light-duty use (110% overload)
- Maximum current with 50% overload, allowed for one minute every five minutes I_{Hd}
 - 1) Maximum current with 30% overload, allowed for one minute every five minutes
 - ²⁾ Maximum current with 25% overload, allowed for one minute every five minutes
- Typical motor power in heavy-duty use (50% overload) P_{Hd}

Sizing

Drive sizing is based on the rated motor current and power. To achieve the rated motor power given in the table, the rated current of the drive must be higher than or equal to the rated motor current. Also the rated power of the drive must be higher than or equal to compared to the rated motor power. The power ratings are the same regardless of the supply voltage within one voltage range.

Note: ABB recommends the DriveSize dimensioning tool (available from (ttp://new.abb.com/drives/software-tools/drivesize) for selecting the drive, motor and gear combination.

Derating

The load capacity $(I_2, I_{l,d}, I_{Hd})$; note that I_{max} is not derated) decreases for certain situations, as defined below. In such situations, where full motor power is required, oversize the drive so that the derated value provides sufficient capacity.



Ambient temperature derating, IP21 (UL Type 1)

| Temperature range | Derating |
|-------------------|---|
| up to +40 °C | No derating |
| up to +104 °F | |
| +40+55 °C | Derate 1% for every 1 °C (1.8 °F): Calculate the output by multiplying the |
| +104+131 °F | current given in the rating table by the derating factor (k, in the diagram |
| | below). |
| | k |
| | |
| | 1.00 |
| | 1.00 |
| | 0.95 |
| | |
| | 0.90 |
| | |
| | 0.85 |
| | |
| | 0.80 |
| | -15 °C +40 °C +50 °C +55 °C T |
| | -59 °F +104 °F +122 °F +131 °F |



Ambient temperature derating, IP55 (UL Type 12)

The derating is the same as for degree of protection of IP21 (UL Type 1) except for drive types shown below.

| Temperature range | Derating | | | | | | | |
|----------------------------|----------------|--------------------|--------------|------------|-------------|--------------------|--|--|
| | ACS880 |)-11-087A-3+ | B056 and | -077A-5+ | -B056 | | | |
| up to +40 °C | No derating | g | | | | | | |
| up to +104 °F | | | | | | | | |
| +40+55 °C | | | | | | erate 2% for every | | |
| +104+131 °F | | | | | | y multiplying the | | |
| | below). | en in the rating | table by th | e derating | tactor (K, | in the diagram | | |
| | k — | | | | | | | |
| | Α . | ļ | | | | | | |
| | 1.00 | I | | | | | | |
| | 1.00 | i | | | | | | |
| | 0.95 — | I | | | | 0.95 | | |
| | 0.90 | i | | | | | | |
| | 0.30 | | | | | | | |
| | 0.85 — | <u> </u> | | | | _ | | |
| | 0.80 | I I | | | | | | |
| | 0.60 | I | | | | | | |
| | 0.75 | + | | <u> </u> | | 0.75 | | |
| | -15 ° | | | 5 °C +50 | | 55 °C | | |
| | -59 ° | + | 104 °F +1′ | 13 °F +12 | 2 °F +1. | 31 °F <i>T</i> | | |
| | |)-11-206A-3+ | B056 and | -180A-5+ | -B056 | | | |
| up to +40 °C | No derating | g | | | | | | |
| up to +104 °F +40+55 °C | Daneta 4 5 | 0/ for account 4 0 | C (4 0 °F): | Caladata 4 | | by multiplying the | | |
| +40+55 C +104+131 °F | | | | | | in the diagram | | |
| | below). | | tubio by til | o dordanig | ractor (it, | iii aio alagiaiii | | |
| | k – | | | | | _ | | |
| | | 1 | | | | | | |
| | 1.00 | l l | | | | | | |
| | 0.05 | 1 | | | | | | |
| | 0.95 — | 1 | | | | | | |
| | 0.90 | i | | | | | | |
| | | I | | | | | | |
| | 0.85 | i i | | | | 0.85 | | |
| | 0.80 | | | | | _ | | |
| | 0.75 | I | | | | 0.775 | | |
| | 0.75 □ -15° | C + | 40 °C | +50 | °C +5 | 55 °C <i>T</i> | | |
| | -59 ° | | 104 °F | +122 | | 31 °F | | |



Ambient temperature derating in table format

| Type ACS880 -11 | <u>≤</u> 40 IP21, |) °C IP55 | | °C IP55 | |) °C , IP55 | | 5 °C , IP55 |
|------------------------|------------------------|---------------------------|------------|------------|--------|----------------------|--------|----------------------|
| | % | <i>l</i> ₂ (A) | % | (A) | % | I _{out} (A) | % | I _{out} (A) |
| 3-phase U _N | ₁ = 400 V (| 38415 V | ') | | | | | |
| 09A4-3 | 100 | 10.0 | 95 | 9.5 | 90 | 9.0 | 85 | 8.5 |
| 12A6-3 | 100 | 12.9 | 95 | 12.3 | 90 | 11.6 | 85 | 11.0 |
| 017A-3 | 100 | 17.0 | 95 | 16.2 | 90 | 15.3 | 85 | 14.5 |
| 025A-3 | 100 | 25 | 95 | 23.8 | 90 | 22.5 | 85 | 21.3 |
| 032A-3 | 100 | 32 | 95 | 30.4 | 90 | 28.8 | 85 | 27.2 |
| 038A-3 | 100 | 38 | 95 | 36.1 | 90 | 34.2 | 85 | 32.3 |
| 045A-3 | 100 | 45 | 95 | 42.8 | 90 | 40.5 | 85 | 38.3 |
| 061A-3 | 100 | 61 | 95 | 58.0 | 90 | 54.9 | 85 | 51.9 |
| 072A-3 | 100 | 72 | 95 | 68.4 | 90 | 64.8 | 85 | 61.2 |
| 087A-3 | 100 | 87 | 95 | 82.7 | 90/85 | 78.3/74 | 85/75 | 74/65.3 |
| 105A-3 | 100 | 105 | 95 | 99,8 | 90 | 94,5 | 85 | 89,3 |
| 145A-3 | 100 | 145 | 95 | 137,8 | 90 | 130,5 | 85 | 123,3 |
| 169A-3 | 100 | 169 | 95 | 160,6 | 90 | 152,1 | 85 | 143,7 |
| 206A-3 | 100 | 206 | 92.5 | 190,6 | 85 | 175,1 | 77,5 | 159,7 |
| 3-phase U _N | ₁ = 500 V (| 380500 | V) | | | | | |
| 07A6-5 | 100 | 7.6 | 95/95 | 7.2 | 90/90 | 6.8 | 85/85 | 6.5 |
| 11A0-5 | 100 | 11.0 | 95/95 | 10.5 | 90/90 | 9.9 | 85/85 | 9.4 |
| 014A-5 | 100 | 14 | 95/95 | 13.3 | 90/90 | 12.6 | 85/85 | 11.9 |
| 021A-5 | 100 | 21 | 95/95 | 20.0 | 90/90 | 18.9 | 85/85 | 17.9 |
| 027A-5 | 100 | 27 | 95/95 | 25.7 | 90/90 | 24.3 | 85/85 | 23.0 |
| 034A-5 | 100 | 34 | 95/95 | 32.3 | 90/90 | 30.6 | 85/85 | 28.9 |
| 040A-5 | 100 | 40 | 95/95 | 38.0 | 90/90 | 36.0 | 85/85 | 34.0 |
| 052A-5 | 100 | 52 | 95/95 | 49.4 | 90/90 | 46.8 | 85/85 | 44.2 |
| 065A-5 | 100 | 65 | 95/95 | 61.8 | 90/90 | 58.5 | 85/85 | 55.3 |
| 077A-5 | 100 | 77 | 95/95 | 73.2 | 90/85* | 69.3/65.5* | 85/75* | 65.5/57.8* |
| 101A-5 | 100 | 101 | 95 | 96,0 | 90 | 90,9 | 85 | 85,9 |
| 124A-5 | 100 | 124 | 95 | 117,8 | 90 | 111,6 | 85 | 105,4 |
| 156A-5 | 100 | 156 | 95 | 148,2 | 90 | 140,4 | 85 | 132,6 |
| 180A-5 | 100 | 180 | 92,5 | 166,5 | 85 | 153,0 | 77,5 | 139,5 |
| | | ı | | ı | | 1 | 3AX | D00000588487 |





Deratings for special settings in the drive control program

Enabling special settings in the drive control program can require output current derating.

Ex motor, sine filter, low noise

Contact ABB for the deratings of these cases:

- drive is used with an ABB motor for explosive atmospheres (Ex) and EX motor in Parameter 95.15 Special HW settings is enabled
- sine filter given in the selection table on page 226 is used and ABB Sine filter in Parameter 95.15 Special HW settings is enabled
- Low noise optimization is selected in Parameter 97.09 Switching freq mode.

Note: If Ex motors are used together with sine filters, EX motor in Parameter 95.15 Special HW settings is disabled and ABB Sine filter in Parameter 95.15 Special HW **settings** is enabled. Obey the instructions of the motor manufacturer.

| Type ACS880 | Output ratings | | | | | | | |
|-------------------------------|----------------|----------------|------------------------|--------------------|----------------|----------------|-----------------------|-----------------------|
| ACS880 -11 | EX n | notor (AB | B Ex mot | ors) | | ABB Si | ine filter | |
| | Nomin | al use | Light- duty use | Heavy- duty use | Nominal use | | Light- duty use | Heavy- duty use |
| | I _N | P _N | <i>I</i> _{Ld} | I _{Hd} | I _N | P _N | / _{Ld} | / _{Hd} |
| | Α | kW | Α | Α | Α | kW | Α | Α |
| <i>U</i> _N = 400 V | | | | | | | | |
| 09A4-3 | 10.0 | 4.0 | 9.5 | 8.0 | 9.2 | 4.0 | 8.7 | 7.2 |
| 12A6-3 | 12.9 | 5.5 | 12.0 | 10.0 | 12.1 | 5.5 | 11.5 | 9.2 |
| 017A-3 | 17 | 8 | 16 | 12.6 | 16 | 7.5 | 15 | 12 |
| 025A-3 | 25 | 11 | 24 | 17 | 24 | 11 | 23 | 16 |
| 032A-3 | 32 | 15 | 30 | 25 | 31 | 15 | 29 | 23 |
| 038A-3 | 38 | 19 | 36 | 32 | 37 | 18.5 | 35 | 31 |
| 045A-3 | 45 | 22 | 43 | 38 | 43 | 22 | 41 | 36 |
| 061A-3 | 61 | 30 | 58 | 45 | 58 | 30 | 55 | 43 |
| 072A-3 | 72 | 37 | 68 | 61 | 64 | 30 | 61 | 58 |
| 087A-3 | 87 | 45 | 83 | 72 | 77 | 37 | 73 | 64 |
| 105A-3 | 105 | 55 | 100 | 87 | 105 | 55 | 100 | 87 |
| 145A-3 | 145 | 75 | 138 | 105 | 145 | 75 | 138 | 105 |
| 169A-3 | 169 | 90 | 161 | 145 | 169 | 90 | 161 | 145 |
| 206A-3 | 206 | 110 | 196 | 169 | 206 | 110 | 196 | 169 |
| <i>U</i> _N = 500 V | | | • | | | | | |
| 07A6-5 | 7.6 | 4.0 | 7.2 | 5.2 | 7.0 | 3.0 | 6.7 | 4.8 |
| 11A0-5 | 11.0 | 5.5 | 10.4 | 7.6 | 10.2 | 4.0 | 9.7 | 7.0 |
| 014A-5 | 14 | 7.5 | 13 | 11 | 13 | 5.5 | 12 | 10.2 |
| 021A-5 | 21 | 11.0 | 19 | 14 | 19 | 7.5 | 18 | 13 |



| Type Output ratings | | | | | | | | |
|---------------------|----------------|----------------|------------------------|--------------------|-----------------|----------------|-----------------------|-----------------------|
| ACS880 -11 | EX n | notor (AB | B Ex mot | ors) | ABB Sine filter | | | |
| | Nomin | al use | Light- duty use | Heavy- duty use | Nominal use | | Light- duty use | Heavy- duty use |
| | / _N | P _N | <i>I</i> _{Ld} | / _{Hd} | I _N | P _N | / _{Ld} | / _{Hd} |
| | Α | kW | Α | Α | Α | kW | Α | Α |
| 027A-5 | 27 | 15 | 26 | 21 | 25 | 11.0 | 24 | 19.0 |
| 034A-5 | 34 | 18.5 | 32 | 27.0 | 31 | 15 | 29 | 25 |
| 040A-5 | 40 | 22 | 38 | 34 | 34 | 18.5 | 32 | 31.0 |
| 052A-5 | 52 | 30 | 49 | 40 | 44 | 22 | 42 | 34 |
| 065A-5 | 65 | 37 | 62 | 52 | 52 | 30 | 49 | 44 |
| 077A-5 | 77 | 45 | 73 | 65 | 61 | 37 | 58 | 52 |
| 101A-5 | 101 | 45,0 | 91 | 45 | 101 | 45,0 | 91 | 45 |
| 124A-5 | 124 | 55,0 | 118 | 55 | 124 | 55,0 | 118 | 55 |
| 156A-5 | 156 | 75,0 | 148 | 75 | 156 | 75,0 | 148 | 75 |
| 180A-5 | 180 | 90,0 | 171 | 90 | 180 | 90,0 | 171 | 90 |
| | • | • | • | | | • | 3AXD0 | 0000588487 |

| - / | ۸ | • |
|-----|---|----|
| _/ | ı | ` |
| / | ! | `\ |
| _ | | _ |

| | 3AAD00000366487 |
|-----------------|---|
| U_{N} | Supply voltage range |
| I _N | Nominal output current (available continuously with no over-loading) |
| P_{N} | Typical motor power in no-overload use |
| I _{Ld} | Continuous rms output current allowing 10% overload for 1 minute every 5 minutes |
| / _{Hd} | Continuous rms output current allowing 50% overload for 1 minute every 5 minutes. |
| P_{Hd} | Typical motor power in heavy-duty use |
| Note 1: The | e ratings apply at an ambient temperature of 40 °C (104 °F). |

| Type ACS880 Parameter 97.09 Switching freq mode | | | | | | |
|---|----------------|-----------------|-----------------|--|--|--|
| -11 | Nominal use | Light- duty use | Heavy-duty use | | | |
| | I _N | I _{Ld} | / _{Hd} | | | |
| | Α | Α | Α | | | |
| <i>U</i> _N = 400 V | | | | | | |
| 09A4-3 | 8.5 | 8.1 | 6.5 | | | |
| 12A6-3 | 11.3 | 10.7 | 8.5 | | | |
| 017A-3 | 15 | 14.3 | 11.3 | | | |
| 025A-3 | 22 | 20.9 | 15.0 | | | |
| 032A-3 | 30 | 29 | 22 | | | |
| 038A-3 | 35 | 33 | 30 | | | |
| 045A-3 | 41 | 39 | 35 | | | |
| 061A-3 | 56 | 53 | 41 | | | |

| -11 | · | | | | | |
|------------------------|----------------|-----------------|-----------------|--|--|--|
| -11 | Nominal use | Light- duty use | Heavy-duty use | | | |
| | I _N | / _{Ld} | / _{Hd} | | | |
| | Α | Α | Α | | | |
| 072A-3 | 56 | 53 | 47 | | | |
| 087A-3 | 67 | 64 | 56 | | | |
| 105A-3 | 105 | 100 | 87 | | | |
| 145A-3 | 145 | 138 | 105 | | | |
| 169A-3 | 169 | 161 | 145 | | | |
| 206A-3 | 206 | 196 | 169 | | | |
| U _N = 500 V | | | | | | |
| 07A6-5 | 6.5 | 6.2 | 4.4 | | | |
| 11A0-5 | 9.4 | 8.9 | 6.5 | | | |
| 014A-5 | 12.0 | 11.4 | 9.4 | | | |
| 021A-5 | 18.0 | 17.1 | 12.0 | | | |
| 027A-5 | 23.0 | 21.9 | 18.0 | | | |
| 034A-5 | 29 | 28 | 23 | | | |
| 040A-5 | 29 | 28 | 23 | | | |
| 052A-5 | 37 | 35 | 29 | | | |
| 065A-5 | 39 | 37 | 33 | | | |
| 077A-5 | 46 | 44 | 39 | | | |
| 101A-5 | 101 | 91 | 77 | | | |
| 124A-5 | 124 | 118 | 96 | | | |

Output ratings with selection Low noise optimization of parameter Parameter 97.09 Switching freq mode

Type ACS880

156A-5

180A-5

156

180

156 3AXD00000588487

124

| U_{N} | Supply voltage range |
|-----------------|---|
| I _N | Nominal output current (available continuously with no over-loading) |
| P_{N} | Typical motor power in no-overload use |
| / _{Ld} | Continuous rms output current allowing 10% overload for 1 minute every 5 minutes |
| / _{Hd} | Continuous rms output current allowing 50% overload for 1 minute every 5 minutes. |
| P_{Hd} | Typical motor power in heavy-duty use |
| Note 1: The | ratings apply at an ambient temperature of 40 °C (104 °F). |

148

171



High speed mode

Selection **High speed mode** of parameter **95.15 Special HW settings** improves control performance at high output frequencies. We recommend it to be selected with output frequency of 120 Hz and above.

This table gives the drive ratings for the maximum output frequency when **High speed mode** in parameter **95.15 Special HW settings** is enabled: With output frequencies smaller than this recommended maximum output frequency, the current derating is less than the values given in the table. Contact ABB for operation above the recommended maximum output frequency or for the output current derating with output frequencies above 120 Hz and below the maximum output frequency.

At the output frequency 120 Hz no derating.

| Type ACS880 | Output ratings with selection High speed mode of parameter 95.15 Special HW settings | | | | | | |
|-------------------------------|--|----------------|-----------------|-----------------|--|--|--|
| -11 | Maximum output frequency | Nominal use | Light-duty use | Heavy-duty use | | | |
| | f _{max} | I _N | I _{Ld} | / _{Hd} | | | |
| | Hz | Α | Α | Α | | | |
| <i>U</i> _N = 400 V | | | | | | | |
| 09A4-3 | 500 | 8.5 | 8.1 | 6.5 | | | |
| 12A6-3 | 500 | 11.3 | 10.7 | 8.5 | | | |
| 017A-3 | 500 | 15 | 14.3 | 11.3 | | | |
| 025A-3 | 500 | 22 | 20.9 | 15.0 | | | |
| 032A-3 | 500 | 30 | 29 | 22 | | | |
| 038A-3 | 500 | 35 | 33 | 30 | | | |
| 045A-3 | 500 | 41 | 39 | 35 | | | |
| 061A-3 | 500 | 56 | 53 | 41 | | | |
| 072A-3 | 500 | 56 | 53 | 47 | | | |
| 087A-3 | 500 | 67 | 64 | 56 | | | |
| 105A-3 | 500 | 105 | 100 | 87 | | | |
| 145A-3 | 500 | 145 | 138 | 105 | | | |
| 169A-3 | 500 | 156 | 148 | 122 | | | |
| 206A-3 | 500 | 192 | 180 | 155 | | | |
| U _N = 500 V | | | | | | | |
| 07A6-5 | 500 | 6.5 | 6.2 | 4.4 | | | |
| 11A0-5 | 500 | 9.4 | 8.9 | 6.5 | | | |
| 014A-5 | 500 | 12.0 | 11.4 | 9.4 | | | |
| 021A-5 | 500 | 18.0 | 17.1 | 12.0 | | | |
| 027A-5 | 500 | 23.0 | 21.9 | 18.0 | | | |
| 034A-5 | 500 | 29 | 28 | 23 | | | |
| 040A-5 | 500 | 29 | 28 | 23 | | | |
| 052A-5 | 500 | 37 | 35 | 29 | | | |



| Type ACS880 -11 | Output ratings with selection High speed mode of parameter 95.15 Special HW settings | | | | | | |
|-----------------------|--|----------------|------------------------|-----------------|--|--|--|
| -" | Maximum output frequency | Nominal use | Heavy-duty use | | | | |
| | f _{max} | / _N | <i>I</i> _{Ld} | I _{Hd} | | | |
| | Hz | Α | Α | Α | | | |
| 065A-5 | 500 | 39 | 37 | 33 | | | |
| 077A-5 | 500 | 46 | 44 | 39 | | | |
| 101A-5 | 500 | 101 | 91 | 77 | | | |
| 124A-5 | 500 | 124 | 118 | 96 | | | |
| 156A-5 | 500 | 144 | 136 | 87 | | | |
| 180A-5 | 500 | 169 | 160 | 147 | | | |

3AXD00000588487

| | 0/VID00000000401 |
|------------------|--|
| f _{max} | Maximum output frequency with High speed mode |
| U _N | Nominal voltage of the drive |
| I _N | Continuous rms output current. No overload capability at 40 °C (104 °F) |
| P_{N} | Typical motor power in no-overload use. |
| I _{Ld} | Continuous rms output current allowing 10% overload for 1 minute every 5 minutes |
| I _{Hd} | Continuous rms output current allowing 50% overload for 1 minute every 5 minutes |



Altitude derating

In altitudes 1000...4000 m (3300...13120 ft) above sea level, the derating is 1% for every 100 m (330 ft).

The output current is calculated by multiplying the current given in the rating table by the derating factor k, which for x meters (1000 m \leq x \leq 4000 m) is:

$$k = 1 - \frac{1}{10\,000\,\mathrm{m}} \cdot (x - 1000)\,\mathrm{m}$$

Check the network compatibility restrictions above 2000 m (6562 ft), see *Installation* site altitude on page 192.

Fuses protect the input cable in short-circuit situations. They also restrict drive damage and prevent damage to adjoining equipment in case of a short-circuit inside the drive. We recommend the high speed aR fuses specified below. The gG fuses can be used for frames R3 and R6 if they operate rapidly enough (max. 0.1 seconds). The operating time depends on the supply network impedance and the cross-sectional area and length of the supply cable. Obey the local regulations.

Note: Fuses from other manufacturers can be used if they meet the ratings and the melting curve of the fuse does not exceed the melting curve of the fuse mentioned in the table.

aR fuses

| Type | aR | | | | | | |
|------------------------|-----------------|------------------|----------------|------------------|-------------------|--|--|
| ACS880 -11- | Nominal current | <i>l</i> ²t | Voltage rating | Bussmann type | IEC 60269 size | | |
| | Α | A ² s | V | | | | |
| 3-phase U _N | = 400 V (3 | 80415 V |) | | | | |
| 09A4-3 | 25 | 130 | 690 | 170M1561 | 000 | | |
| 12A6-3 | 25 | 130 | 690 | 170M1561 | 000 | | |
| 017A-3 | 40 | 460 | 690 | 170M1563 | 000 | | |
| 025A-3 | 40 | 460 | 690 | 170M1563 | 000 | | |
| 032A-3 | 63 | 1450 | 690 | 170M1565 | 000 | | |
| 038A-3 | 63 | 1450 | 690 | 170M1565 | 000 | | |
| 045A-3 | 80 | 2550 | 690 | 170M1566 | 000 | | |
| 061A-3 | 100 | 4650 | 690 | 170M1567 | 000 | | |
| 072A-3 | 125 | 8500 | 690 | 170M1568 | 000 | | |
| 087A-3 | 160 | 16000 | 690 | 170M1569 | 000 | | |
| 105A-3 | 315 | 46500 | 690 | 170M3817 | 1 | | |
| 145A-3 | 315 | 46500 | 690 | 170M3817 | 1 | | |
| 169A-3 | 450 | 105000 | 690 | 170M5809 | 2 | | |
| 206A-3 | 500 | 145000 | 690 | 170M5810 | 2 | | |
| 3-phase U _N | = 500 V (3 | 80500 V |) | | | | |
| 07A6-5 | 25 | 130 | 690 | 170M1561 | 000 | | |
| 11A0-5 | 25 | 130 | 690 | 170M1561 | 000 | | |
| 014A-5 | 40 | 460 | 690 | 170M1563 | 000 | | |
| 021A-5 | 40 | 460 | 690 | 170M1563 | 000 | | |
| 027A-5 | 63 | 1450 | 690 | 170M1565 | 000 | | |
| 034A-5 | 63 | 1450 | 690 | 170M1565 | 000 | | |
| 040A-5 | 80 | 2550 | 690 | 170M1566 | 000 | | |
| 052A-5 | 100 | 4650 | 690 | 170M1567 | 000 | | |
| 065A-5 | 125 | 8500 | 690 | 170M1568 | 000 | | |
| 077A-5 | 160 | 16000 | 690 | 170M1569 | 000 | | |
| 101A-5 | 250 | 28500 | 690 | 170M3816 | 1 | | |
| 124A-5 | 315 | 46500 | 690 | 170M3817 | 1 | | |



| Type | aR | | | | | |
|----------------|-----------------|------------------|----------------|------------------|-------------------|--|
| ACS880 -11- | Nominal current | <i>l</i> ²t | Voltage rating | Bussmann type | IEC 60269 size | |
| | Α | A ² s | V | | | |
| 156A-5 | 400 | 74000 | 690 | 170M5808 | 2 | |
| 180A-5 | 500 | 155000 | 690 | 170M5810 | 2 | |

3AXD00000588487

gG fuses

gG fuses can be used for frames R3 and R6 if they operate rapidly enough (max. 0.1 seconds).

| Type | Min. | Input | gG (IEC 60269) | | | | | | |
|---|--|----------|-----------------|-------------------------|----------------|-------------|-------------------|--|--|
| ACS880 -11- | short- circuit current ¹⁾ | current | Nominal current | <i>l</i> ² t | Voltage rating | ABB type | IEC 60269 size | | |
| | Α | Α | Α | A ² s | V | | | | |
| 3-phase <i>U</i> _N = 400 V (380415 V) | | | | | | | | | |
| 09A4-3 | 120 | 8.0 | 16 | 700 | 500 | OFAF000H16 | 000 | | |
| 12A6-3 | 120 | 10.0 | 16 | 700 | 500 | OFAF000H16 | 000 | | |
| 017A-3 | 200 | 14.0 | 25 | 2500 | 500 | OFAF000H25 | 000 | | |
| 025A-3 | 250 | 20.0 | 32 | 4500 | 500 | OFAF000H32 | 000 | | |
| 032A-3 | 350 | 27.0 | 40 | 7700 | 500 | OFAF000H40 | 000 | | |
| 038A-3 | 400 | 33.0 | 50 | 15400 | 500 | OFAF000H50 | 000 | | |
| 045A-3 | 500 | 40.0 | 63 | 21300 | 500 | OFAF000H63 | 000 | | |
| 061A-3 | 800 | 51.0 | 80 | 37000 | 500 | OFAF000H80 | 000 | | |
| 072A-3 | 1000 | 63.0 | 100 | 63600 | 500 | OFAF000H100 | 000 | | |
| 087A-3 | 1000 | 76.0 | 100 | 63600 | 500 | OFAF000H100 | 000 | | |
| 3-phase U | _N = 500 V (3 | 380500 V | ') | | | | | | |
| 07A6-5 | 120 | 7.0 | 16 | 700 | 500 | OFAF000H16 | 000 | | |
| 11A0-5 | 120 | 9.0 | 16 | 700 | 500 | OFAF000H16 | 000 | | |
| 014A-5 | 200 | 12.0 | 25 | 2500 | 500 | OFAF000H25 | 000 | | |
| 021A-5 | 250 | 17.0 | 32 | 4500 | 500 | OFAF000H32 | 000 | | |
| 027A-5 | 350 | 24.0 | 40 | 7700 | 500 | OFAF000H40 | 000 | | |
| 034A-5 | 400 | 29.0 | 50 | 15400 | 500 | OFAF000H50 | 000 | | |
| 040A-5 | 500 | 34.0 | 63 | 21300 | 500 | OFAF000H63 | 000 | | |
| 052A-5 | 800 | 44.0 | 80 | 37000 | 500 | OFAF000H80 | 000 | | |
| 065A-5 | 1000 | 54.0 | 100 | 63600 | 500 | OFAF000H100 | 000 | | |
| 077A-5 | 1000 | 66.0 | 100 | 63600 | 500 | OFAF000H100 | 000 | | |

3AXD00000588487



¹⁾ Minimum short-circuit current of the installation

UL class T fuses for branch circuit protection per NEC are listed below. Fast acting class T or faster fuses are recommended in the USA. Check on the fuse time-current curve to ensure the operating time of the fuse is below 0.5 seconds for frames R3 and R6 and below 0.1 seconds for frame R8. Obey the local regulations.

Note 1: See also *Implementing thermal overload and short-circuit protection* on page 69.

Note 2: Fuses with higher current rating than the recommended ones must not be used.

Note 3: Fuses from other manufacturers can be used if they meet the ratings and the melting curve of the fuse does not exceed the melting curve of the fuse mentioned in the table.

| Type | Input current | UL (one fuse per phase) | | | | | | |
|---|---------------|-------------------------|--------------------------------|---------|----------|--|--|--|
| ACS880 -11- | | | Nominal current Voltage rating | | UL class | | | |
| | А | A | V | | | | | |
| 3-phase U _N = 500 V (380500 V) | | | | | | | | |
| 07A6-5 | 7 | 15 | 600 | JJS-15 | Т | | | |
| 11A0-5 | 9 | 20 | 600 | JJS-20 | Т | | | |
| 014A-5 | 12 | 25 | 600 | JJS-25 | Т | | | |
| 021A-5 | 17 | 35 | 600 | JJS-35 | Т | | | |
| 027A-5 | 24 | 40 | 600 | JJS-40 | Т | | | |
| 034A-5 | 29 | 50 | 600 | JJS-50 | Т | | | |
| 040A-5 | 34 | 60 | 600 | JJS-60 | Т | | | |
| 052A-5 | 44 | 80 | 600 | JJS-80 | Т | | | |
| 065A-5 | 54 | 90 | 600 | JJS-90 | Т | | | |
| 077A-5 | 66 | 110 | 600 | JJS-110 | Т | | | |
| 101A-5 | 72 | 150 | 600 | JJS-150 | Т | | | |
| 124A-5 | 88 | 200 | 600 | JJS-200 | Т | | | |
| 156A-5 | 120 | 225 | 600 | JJS-225 | Т | | | |
| 180A-5 | 144 | 300 | 600 | JJS-300 | Т | | | |





Dimensions, weights and free space requirements

| Frame | Height | Width | Depth | Weight | Height | Width | Depth | Weight | |
|-------|--------|------------|----------|--------|---------------------|-------|-------|--------|--|
| size | mm | mm | mm | kg | mm | mm | mm | kg | |
| | | IP | 21 | | IP55 (option +B056) | | | | |
| R3 | 495 | 205 | 356 | 23 | 490 | 203 | 360 | 23 | |
| R6 | 771 | 252 | 382 | 74 | 771 | 252 | 445 | 74 | |
| R8 | 965 | 300 | 430 | 112* | 966 | 300 | 496 | 118** | |
| | | IP20 (opti | on +P940 |) | IP20 (option +P944) | | | | |
| R3 | 490 | 203 | 349 | 18.3 | - | - | - | - | |
| R6 | 771 | 252 | 349 | 59 | - | - | - | | |
| R8 | 965 | 300 | 430 | 109*** | - | - | - | - | |

^{*} for types -105A-3, 145A-3, -101A-5, -124A-5: 102 kg

^{***} for types -105A-3, 145A-3, -101A-5, -124A-5: 99 kg

| Frame | Height | Width | Depth | Weight | Height | Width | Depth | Weight | |
|-------|--------|----------|-----------|-----------|-----------------------------|-------|-------|--------|--|
| size | in | in | in | lb | in | in | in | lb | |
| | | UL T | ype 1 | | UL Type 12 | | | | |
| R3 | 19.49 | 8.07 | 14.02 | 50.72 | 19.29 | 7.99 | 14.17 | 50.72 | |
| R6 | 30.35 | 9.92 | 15.03 | 161.85 | 30.35 | 9.92 | 17.54 | 161.85 | |
| | UL O | pen Type | (option + | P940) | UL Open Type (option +P944) | | | | |
| R3 | 19.29 | 7.99 | 13.74 | 40.34 | - | - | - | - | |
| R6 | 30.35 | 9.92 | 14.09 | 130.07 | - | - | - | - | |
| R8 | 37.95 | 11.81 | 16.94 | 240.30*** | - | - | - | - | |



Free space requirements

See section Examining the installation site on page 42.

^{**} for types -105A-3, 145A-3, -101A-5, -124A-5: 108 kg

^{*} for types -105A-3, 145A-3, -101A-5, -124A-5: 224.87 lb

^{**} for types -105A-3, 145A-3, -101A-5, -124A-5: 238.10 lb

^{***} for types -105A-3, 145A-3, -101A-5, -124A-5: 218.26 lb

Losses, cooling data and noise

The air flow direction is from bottom to top.

This table shows typical heat loss values, required air flow and noise at the nominal ratings of the drive. The heat loss values can vary depending on voltage, cable conditions, motor efficiency and power factor. To obtain more accurate values for given conditions, use ABB DriveSize tool (http://new.abb.com/drives/softwaretools/drivesize)

| Type | Heat dissipation | Air | flow | Noise | Frame | | | |
|--|---------------------------------|------|--------------------------|-------|-------|--|--|--|
| ACS880- 11 | W | m³/h | ft ³ / min | dB(A) | size | | | |
| 3-phase <i>U</i> _N = 400 (380415 V) | | | | | | | | |
| 09A4-3 | 226 | 361 | 212 | 57 | R3 | | | |
| 12A6-3 | 329 | 361 | 212 | 57 | R3 | | | |
| 017A-3 | 395 | 361 | 212 | 57 | R3 | | | |
| 025A-3 | 579 | 361 | 212 | 57 | R3 | | | |
| 032A-3 | 625 | 550 | 324 | 65 | R6 | | | |
| 038A-3 | 751 | 550 | 324 | 65 | R6 | | | |
| 045A-3 | 912 | 550 | 324 | 65 | R6 | | | |
| 061A-3 | 1088 | 550 | 324 | 65 | R6 | | | |
| 072A-3 | 1502 | 550 | 324 | 65 | R6 | | | |
| 087A-3 | 1904 | 550 | 324 | 65 | R6 | | | |
| 105A-3 | 1877 | 700 | 412 | 68 | R8 | | | |
| 145A-3 | 2963 | 700 | 412 | 68 | R8 | | | |
| 169A-3 | 3168 | 700 | 412 | 68 | R8 | | | |
| 206A-3 | 3990 | 805 | 412 | 68 | R8 | | | |
| 3-phase U | _V = 500 V (380500 V) | | | | | | | |
| 07A6-5 | 219 | 361 | 212 | 57 | R3 | | | |
| 11A0-5 | 278 | 361 | 212 | 57 | R3 | | | |
| 014A-5 | 321 | 361 | 212 | 57 | R3 | | | |
| 021A-5 | 473 | 361 | 212 | 57 | R3 | | | |
| 027A-5 | 625 | 550 | 324 | 65 | R6 | | | |
| 034A-5 | 711 | 550 | 324 | 65 | R6 | | | |
| 040A-5 | 807 | 550 | 324 | 65 | R6 | | | |
| 052A-5 | 960 | 550 | 324 | 65 | R6 | | | |
| 065A-5 | 1223 | 550 | 324 | 65 | R6 | | | |
| 077A-5 | 1560 | 550 | 324 | 65 | R6 | | | |
| 101A-5 | 1995 | 700 | 412 | 68 | R8 | | | |
| 124A-5 | 2800 | 700 | 412 | 68 | R8 | | | |
| 156A-5 | 3168 | 700 | 412 | 68 | R8 | | | |
| 180A-5 | 3872 | 805 | 412 | 68 | R8 | | | |





Terminal and entry data for the power cables

IEC

Input, motor and DC cable entries, maximum wire sizes (per phase) and terminal screw sizes and tightening torques are given below.

| Frame size | Cable entries | | L1, L2, L3 terminals | | T1/U, T2 | /V, T3/W, UE terminals |)+, UDC- | |
|------------|----------------------|-----------------|---|-----------------|----------|--|-----------------|----------------------|
| | Per cable type | Ø ¹⁾ | Min wire size (solid/ stranded) ²⁾ | | | Min wire size (solid/ stranded) ² | size (solid/ | Tightening torque |
| | pcs | mm | mm ² | mm ² | N·m | mm ² | mm ² | N·m |
| R3 | 1 | 23 | 0.5 | 16.0 | 1.7 | 0.5 | 16.0 | 1.7 |
| R6 | 1 | 45 | 6.0 | 70.0 | 5.6 | 6.0 | 70.0 | 5.6 |
| R8 | 1 | 45 | 16 | 150 | 33.9 | 25 | 150 | 30 |

3AXD00000586715

Note: Only copper cables are allowed for drive types up to -039A-4.

For tightening torques of grounding terminals, see section *Connection procedure*, page 88.



UL

Input, motor and DC cable entries, maximum wire sizes (per phase) and terminal screw sizes and tightening torques are given below.

| Frame size | Cal entr | | L1, L2, L3 terminals | | | T1/U, T2/V, T3/W, UDC+, UDC- terminals | | |
|------------|----------------------|-----------------|---|---------------------------------|--------|--|--------------|-------------------|
| | Per cable type | Ø ¹⁾ | Min wire size (solid/ stranded) ²⁾ | ize (solid/ size (solid/ torque | | Min wire size (solid/ stranded) ² | size (solid/ | Tightening torque |
| | pcs | in | AWG | AWG | lbf∙ft | AWG | AWG | lbf∙ft |
| R3 | 1 | 0.91 | 20 | 6 | 1.3 | 20 | 6 | 1.3 |
| R6 | 1 | 1.77 | 10 | 2/0 | 4.1 | 10 | 2/0 | 4.1 |
| R8 | 1 | 1.77 | 6 | 300 | 25 | 4 | 300 | 22 |

3AXD00000586715

Note: Only copper cables are allowed for drive types up to -039A-4.

For tightening torques of grounding terminals, see section *Connection procedure*, page 88.

¹⁾ Maximum cable diameter accepted. For the bottom plate hole diameters, see chapter Dimension drawings on page 203.

²⁾ Minimum wire size does not necessarily have enough current capability for full load. Make sure the installation complies with local laws and regulations.

¹⁾ Maximum cable diameter accepted. For the bottom plate hole diameters, see chapter Dimension drawings on page 203..

³⁾ Minimum wire size does not necessarily have enough current capability for full load. Make sure the installation complies with local laws and regulations.

UL listed cable lugs and tools

| Wire size | Wire size Compre | | C | Crimping tool | | |
|-----------|-------------------|--------------------|-------------------|-----------------|---------------|--|
| kcmil/AWG | Manufacturer | Туре | Manufacturer | Type | No. of crimps | |
| 6 | Thomas & Betts | E10731 54136 | Thomas & Betts | TBM4S TBM45S | 1 | |
| | Burndy | YAV6C-L2 | Burndy | MY29-3 | 1 | |
| | Ilsco | CCL-6-38 | Ilsco | ILC-10 | 2 | |
| 4 | Thomas & Betts | 54140 | Thomas & Betts | TBM4S | 1 | |
| | Burndy | YA4C-L4BOX | Burndy | MY29-3 | 1 | |
| | Ilsco | CCL-4-38 | Ilsco | MT-25 | 1 | |
| 2 | Thomas & Betts | 54143TB 54142TB | Thomas & Betts | TBM4S TBM4S | 1 | |
| | Burndy | YA2C-L4BOX | Burndy | MY29-3 | 2 | |
| | Ilsco | CRC-2 | Ilsco | IDT-12 | 1 | |
| | Ilsco | CCL-2-38 | Ilsco | MT-25 | 1 | |
| 1 | Thomas & Betts | 54148 | Thomas & Betts | TBM-8 | 3 | |
| | Burndy | YA1C-L4BOX | Burndy | MY29-3 | 2 | |
| | Ilsco | CRA-1-38 | Ilsco | IDT-12 | 1 | |
| | Ilsco | CCL-1-38 | Ilsco | MT-25 | 1 | |
| 1/0 | Thomas & Betts | 54109 | Thomas & Betts | TBM-8 | 3 | |
| | Burndy | YA25-L4BOX | Burndy | MY29-3 | 2 | |
| | Ilsco | CRB-0 | Ilsco | IDT-12 | 1 | |
| | Ilsco | CCL-1/0-38 | Ilsco | MT-25 | 1 | |
| 2/0 | Thomas & Betts | 54110 | Thomas & Betts | TBM-8 | 3 | |
| | Burndy | YAL26T38 | Burndy | MY29-3 | 2 | |
| | Ilsco | CRA-2/0 | Ilsco | IDT-12 | 1 | |
| | Ilsco | CCL-2/0-38 | Ilsco | MT-25 | 1 | |

Terminal and entry data for the control cables

IEC

Control cable entries, wire sizes and tightening torques (T) are given below.

| Frame | Cable entries | | Control cable entries and terminal sizes | | | | |
|-------|---------------|--------------|--|------------------------|-----------------|----------------------|--|
| size | Holes | Max cable | | GND, EXT. 24V inals | | ND, RO, STO inals | |
| | | size | Wire size | Τ | Wire size | T | |
| | pcs | mm | mm ² | N·m | mm ² | N·m | |
| R3 | 4 | 17 | 0.22.5 | 0.50.6 | 0.142.5 | 0.50.6 | |
| R6 | 4 | 17 | 0.142.5 | 0.50.6 | 0.142.5 | 0.50.6 | |



| Frame | Cable entries | | Control cable entries and terminal sizes | | | |
|-------|-----------------|------|--|--------|--------------------------------------|--------|
| size | Holes Max cable | | +24V, DCOM, DGND, EXT. 24V terminals | | DI, AI/O, AGND, RO, STO terminals | |
| | | size | Wire size | Τ | Wire size | Т |
| | pcs | mm | mm ² | N·m | mm ² | N·m |
| R8 | 4 | 17 | 0.142.5 | 0.50.6 | 0.142.5 | 0.50.6 |

3AXD00000586715

US

(cos phi₁)

Control cable entries, wire sizes and tightening torques (*T*) are given below.

| Frame | Frame Cable entries | | Control cable entries and terminal sizes | | | | |
|-------|---------------------|--------------|--|------------------------|-----------------------|----------------------|--|
| size | Holes | Max cable | +24V, DCOM, D term | GND, EXT. 24V inals | DI, AI/O, AGI term | ND, RO, STO inals | |
| | | size | Wire size | Τ | Wire size | T | |
| | pcs | in | AWG | lbf∙ft | AWG | lbf∙ft | |
| R3 | 3 | 0.67 | 2414 | 0.4 | 2614 | 0.4 | |
| R6 | 4 | 0.67 | 2614 | 0.4 | 2614 | 0.4 | |
| R8 | 4 | 0.67 | 2614 | 0.4 | 2614 | 0.4 | |

3AXD00000586715



Electrical power network specification

| | • |
|---|--|
| Voltage (U ₁) | ACS880-11-xxxx-3 drives: 380415 V AC 3-phase +10%15%. This is indicated in the type designation label as typical input voltage level 3~ 400 V AC. |
| | ACS880-11-xxxx-5 drives: 380500 V AC 3-phase +10%15%. This is indicated in the type designation label as typical input voltage levels 3~ 400/480/500 V AC. |
| | +10%15%. This is indicated in the type designa |
| Network type | Public low voltage networks. TN (grounded), IT (ungrounded) . See section <i>Checking the compatibility with IT (ungrounded) and corner-grounded delta systems</i> on page 80. |
| Rated conditional short-circuit current (IEC 60439-1) | 65 kA when protected by fuses given in the fuse tables |
| Short-circuit current protection (UL 61800-5-1) | US and Canada: The drive is suitable for use on a circuit capable of delivering not more than 100 kA symmetrical amperes (rms) at 480 V maximum when protected by fuses given in the fuse table, see page 178. |
| Frequency (f ₁) | 47 to 63 Hz. This is indicated in the type designation label as typical input frequency level f1 (50/60 Hz). |
| Imbalance | Max. ± 3% of nominal phase to phase input voltage |
| Fundamental power factor | 1 (at nominal load) |
| | |

Harmonic distortion

Harmonics are below the limits defined in IEEE519,

IEC61000-3-12 and G5/4 standards.

The table below shows typical results on indicated networks. Values are measured at the input terminals of the drive.

| R _{sc} | THD voltage (%) | THD current (%) |
|-----------------|-----------------|-----------------|
| 20 | 3 | 2.5* |
| 100 | 1.9 | 2.5* |

THD =
$$\sqrt{\frac{50}{\sum_{2}^{50}} \left(\frac{I_{\text{n}}}{I_{\text{1contmax}}}\right)^{2}}$$

THD Total harmonic distortion. The voltage THD

depends on the short-circuit ratio (Rsc). The spectrum of the distortion also contains

interharmonics.

*I*_n nth harmonic component

 R_{sc} Short-circuit ratio. $R_{sce} = I_{sc}/I_{N}$

 $I_{\rm sc}$ Short-circuit current at point of common

coupling (PCC)

I_{1contmax} Continuous maximum input current of the line-

side converter

I_I Maximum demand load current



Motor types Asynchronous AC induction motors, permanent magnet

synchronous motors, AC induction servomotors,

synchronous reluctance motors

Frequency (f_2) 0....500 Hz

For drives with du/dt filter: 120 Hz

For drives with sine filter: 120 Hz

Frequency resolution 0.01 Hz

See section *Ratings* on page 165.



Current

Maximum recommended motor cable length

For frame R3: 150 m (492 ft)

For frames R6 and R8: 300 m (984 ft).

Note 1: With motor cables longer than 150 m (492 ft) or switching frequencies higher than default, the EMC

Directive requirements may not be fulfilled.

Note 2: Longer motor cables cause a motor voltage decrease which limits the available motor power. The decrease depends on the motor cable length and characteristics. Contact ABB for more information. Note that a sine filter (optional) at the drive output also causes a voltage decrease.

Control unit (ZCU-12) connection data

Power supply

24 V (±10%) DC, 2 A

(XPOW)

Supplied from the power unit of the drive, or from an external power supply through connector XPOW (pitch

5 mm, wire size 2.5 mm²).

Relay outputs RO1...RO3

Connector pitch 5 mm, wire size 2.5 mm²

(XRO1 ... XRO3)

250 V AC / 30 V DC, 2 A Protected by varistors

+24 V output

Connector pitch 5 mm, wire size 2.5 mm²

(XD24:2 and XD24:4)

Total load capacity of these outputs is 4.8 W (200 mA/

24 V) minus the power taken by DIO1 and DIO2.

Digital inputs DI1...DI6

(XDI:1 ... XDI:6)

Connector pitch 5 mm, wire size 2.5 mm² 24 V logic levels: "0" < 5 V, "1" > 15 V

R_{in}: 2.0 kohm

Input type: NPN/PNP (DI1...DI5), NPN (DI6) Hardware filtering: 0.04 ms, digital filtering up to 8 ms DI6 (XDI:6) can alternatively be used as an input for PTC

sensors.

"0" > 4 kohm, "1" < 1.5 kohm I_{max}: 15 mA (for DI6 5 mA)

Start interlock input DIIL (XD24:1)

Connector pitch 5 mm, wire size 2.5 mm²

24 V logic levels: "0" < 5 V. "1" > 15 V

R_{in}: 2.0 kohm

Input type: NPN/PNP

Hardware filtering: 0.04 ms, digital filtering up to 8 ms



Digital inputs/outputs DIO1 and DIO2 (XDIO:1 and XDIO:2)

Input/output mode selection by parameters.

DIO1 can be configured as a frequency input (0...16 kHz with hardware filtering of 4 microseconds) for 24 V level square wave signal (sinusoidal or other wave form cannot be used). DIO2 can be configured as a 24 V level square wave frequency output. See the firmware manual, parameter group 11.

Connector pitch 5 mm, wire size 2.5 mm²


As inputs:

24 V logic levels: "0" < 5 V, "1" > 15 V

R_{in}: 2.0 kohm Filtering: 0.25 ms

As outputs:

Total output current from +24VD is limited to 200 mA.





Reference voltage for analog inputs +VREF and -VREF (XAI:1 and XAI:2)

Analog inputs Al1 and Al2 (XAI:4 ... XAI:7).

Current/voltage input mode selection by jumpers. See page 101.

Connector pitch 5 mm, wire size 2.5 mm² 10 V \pm 1% and -10 V \pm 1%, R_{load} 1...10 kohm

Connector pitch 5 mm, wire size 2.5 mm²
Current input: –20...20 mA, R_{in} : 100 ohm
Voltage input: –10...10 V, R_{in} : > 200 kohm
Differential inputs, common mode range ±30 V
Sampling interval per channel: 0.25 ms

Hardware filtering: 0.25 ms, adjustable digital filtering up to

8 ms

Resolution: 11 bit + sign bit Inaccuracy: 1% of full scale range

Inaccuracy for Pt100 sensors: 10 °C (50 °F) Connector pitch 5 mm, wire size 2.5 mm²

0...20 mA, $R_{\rm load}$ < 500 ohm Frequency range: 0...300 Hz Resolution: 11 bit + sign bit Inaccuracy: 2% of full scale range

Connector pitch 5 mm, wire size 2.5 mm²

Physical layer: RS-485 Termination by switch

Analog outputs AO1 and AO2 (XAO)

Drive to drive link (XD2D)

Safe torque off connection (XSTO)

Connector pitch 5 mm, wire size 2.5 mm²

Input voltage range: -3...30 V DC Logic levels: "0" < 5 V, "1" > 17 V

Current consumption of frames R1 to R7: 30 mA

(24 V DC, continuous) per STO channel

Current consumption of frames R8 and R9: 12 mA

(24 V DC, continuous) per STO channel Maximum output current from OUT1: 100 mA

(24 V DC, continuous)

For the drive to start, both connections must be closed

(OUT1 to IN1 and IN2).


EMC (immunity) according to IEC 61326-3-1

Control panel – PC connection

Connector: RJ-45 Cable length < 3 m

The terminals on the board fulfil the Protective Extra Low Voltage (PELV) requirements. The PELV requirements of a relay output are not fulfilled if a voltage higher than 48 V is connected to the relay output.







Efficiency

Efficiency at nominal power level: Approximately 96% for frame R3 Approximately 96.5% for frame R6 Approximately 97% for frame R8

Degree of protection

| Degree of protection (IEC/EN 60529) | IP21, IP55, IP20 |
|--|-------------------------------------|
| Enclosure types (UL 61800-5-1) | UL Type 1, UL Type 12, UL Open Type |
| Overvoltage category (IEC 60664-1) | III |
| Protective classes (IEC/EN 61800-5-1) | I |

Materials




- PC/ABS 3 mm, color NCS 1502-Y (RAL 9002 / PMS 1C Cool Grey) and RAL 9017
- PC+10%GF 3.0mm, Color RAL 9017 (in two smallest R3 frames only)
- Plastic parts are made of UV resistant f1 classified plastics
- Hot-dip zinc coated steel sheet 1.5 to 2.5 mm, thickness of coating 100 micrometers, color NCS 1502-Y





Package


Plywood, cardboard and molded pulp. Foam cushions PE, PP-E, bands PP.
















Disposal

The main parts of the drive can be recycled to preserve natural resources and energy. Product parts and materials should be dismantled and separated.

Generally all metals, such as steel, aluminum, copper and its alloys, and precious metals can be recycled as material. Plastics, rubber, cardboard and other packaging material can be used in energy recovery. Printed circuit boards and large electrolytic capacitors need selective treatment according to IEC 62635 guidelines. To aid recycling, plastic parts are marked with an appropriate identification code.

Contact your local distributor for further information on environmental aspects and recycling instructions for professional recyclers. End of life treatment must follow international and local regulations.

Applicable standards

The drive complies with the following standards. The compliance with the European Low Voltage Directive is verified according to standard EN 61800-5-1.

EN 60204-1:2006 + AI:2009 +

AC:2010

Safety of machinery. Electrical equipment of machines. Part 1: General requirements. Provisions for compliance: The final assembler of the machine is responsible for installing

- emergency-stop device
- supply disconnecting device.

IEC/EN 60529:1981 +A1:1999 +

A2: 2013

Degrees of protection provided by enclosures (IP code)

EN 61000-3-12:2011

Electromagnetic compatibility (EMC) - Part 3-12: Limits -Limits for harmonic currents produced by equipment connected to public low-voltage systems with input current The standard is met with a Rsce (transformer short circuit ratio) of 350 or higher.

IEC/EN 61800-3:2004 + A1:2012

Adjustable speed electrical power drive systems. Part 3:

EMC requirements and specific test methods

IEC/EN 61800-5-1:2007

Adjustable speed electrical power drive systems. Part 5-1: Safety requirements – electrical, thermal and energy

IEC/EN 60664-1:2007

Insulation coordination for equipment within low-voltage

systems. Part 1: Principles, requirements and tests.

UL 61800-5-1: First edition 2012

Standard for Adjustable Speed Electrical Power Drive Systems - Part 5-1: Safety Requirements - Electrical,

Thermal and Energy

NEMA 250:2014

Enclosures for Electrical Equipment (1000 Volts

Maximum)

CSA C22.2 No. 274-17

Industrial control equipment



Environmental limits for the drive are given below. The drive is to be used in a heated, indoor, controlled environment. All printed circuit boards are conformal coated.

Operation

Storage

Transportation

| | installed for stationary use | in the protective package | in the protective package |
|---|---|---|-----------------------------------|
| Installation site altitude | • 0 to 4000 m (13123 ft) above sea level | - | - |
| | • 0 to 2000 m (6561 ft) above sea level ²⁾ | | |
| | Output derated above 1000 m (3281 ft), see page 175. | | |
| Surrounding air temperature | -15 to +55 °C (5 to 131 °F). No frost allowed. See section <i>Ratings</i> . | -40 to +70 °C (-40 to +158 °F) | -40 to +70 °C (-40 to +158 °F) |
| Relative humidity | 5 to 95% | Max. 95% | Max. 95% |
| | | llowed. Maximum al the presence of corr | |
| Contamination levels (IEC 60721-3-x) | IEC 60721-3-3: 2002: Classification of environmental conditions - Part 3-3: Classification of groups of environmental parameters and their severities - Stationary use of weather protected locations | IEC 60721-3-1: 1997 | IEC 60721-3-2: 1997 |
| Chemical gases | Class 3C2 | Class 1C2 | Class 2C2 |
| Solid particles | Class 3S2. No conductive dust allowed. | Class 1S3 (packing must support this, otherwise 1S2) | Class 2S2 |
| Pollution degree (IEC/EN 61800-5-1) | Pollution degree 2 | - | - |



| | Operation | Storage | Transportation |
|----------------------|-----------------|------------------------------|---------------------|
| | installed for | in the protective | in the protective |
| | stationary use | package | package |
| Atmospheric pressure | 70 to 106 kPa | 70 to 106 kPa | 60 to 106 kPa |
| | 0.7 to 1.05 | 0.7 to 1.05 | 0.6 to 1.05 |
| | atmospheres | atmospheres | atmospheres |
| Vibration | 10150 Hz | - | - |
| (IEC 60068-2:6) | Amplitude | | |
| | ±0.075 mm, | | |
| | 1057.56 Hz | | |
| | Constant peak | | |
| | acceleration | | |
| | 10 m/s² (1 gn), | | |
| | 57.56150 Hz | | |
| Vibration (ISTA) | - | R3: Displacement, | • |
| | | peak, 14200 vibrate | ory impacts |
| | | R6, R8 ISTA 3E): F | Random, overall |
| | | Grms level of 0.54 | |
| Shock/Drop (ISTA) | Not allowed | R3 (ISTA 1A): Drop | o, 6 faces, 3 edges |
| | | and 1 corner, 460 r | mm (18.1 in) |
| | | R6, R8 (ISTA 3E): | Shock, incline |
| | | impact: 1.2 m/s (3.5 | 94 ft/s) |
| | | Shock, rotational e (9.1 in) | dge drop: 230 mm |



CE marking

A CE mark is attached to the drive to verify that the drive follows the provisions of the European Low Voltage, EMC and RoHS Directives. The CE marking also verifies that the drive, in regard to its safety functions (such as Safe torque off), conforms with the Machinery Directive as a safety component.

Compliance with the European Low Voltage Directive

The compliance with the European Low Voltage Directive has been verified according to standards EN60204-1 and EN 61800-5-1.

Compliance with the European EMC Directive

The EMC Directive defines the requirements for immunity and emissions of electrical equipment used within the European Union. The EMC product standard (EN 61800-3:2004 + A1:2012) covers requirements stated for drives. See section Compliance with the EN 61800-3:2004 + A1:2012 below.

¹⁾ For neutral-grounded TN and TT systems and non-corner grounded IT systems.

²⁾ For corner-grounded TN, TT and IT systems

Compliance with the European ROHS II Directive

The RoHS II Directive defines the restriction of the use of certain hazardous substances in electrical and electronic equipment.

Compliance with the European WEEE Directive

The WEEE Directive defines the regulated disposal and recycling of electric and electrical equipment.

Compliance with the European Machinery Directive

The drive is an electronic product which is covered by the European Low Voltage Directive. However, the drive includes the Safe torque off function and can be equipped with other safety functions for machinery which, as safety components, are in the scope of the Machinery Directive. These functions of the drive comply with European harmonized standards such as EN 61800-5-2.



Declaration of conformity



EU Declaration of Conformity

Machinery Directive 2006/42/EC

Ma

Manufacturer: ABB Oy

Address: Hiomotie 13, 00380 Helsinki, Finland.

+358 10 22 11

declare under our sole responsibility that the following products:

Frequency converters

AC\$880-01

ACS880-04/-04F

ACS880-M04

ACS880-11/-31/-14/-34

with regard to the built-in safety function:

Safe torque off;

and with regard to the following optional safety functions with FSO-12 module (option code +Q973, encoderless):

Safe stop 1; Safe stop emergency; Safely-limited speed; Safe maximum speed; Safe brake control; Prevention of Unexpected Start-up;

and with regard to the following optional safety functions (option codes +Q972 and +L521, encoder supported):

Safe stop 1; Safe stop emergency; Safely-limited speed; Safe maximum speed; Safe brake control; Safe speed monitor; Safe direction; Prevention of Unexpected Start-up;

and with regard to the following optional safety function with FPTC-01 thermistor protection module (option code +L536):

Safe Motor Temperature;

are in conformity with all the relevant safety component requirements of EU Machinery Directive 2006/42/EC, when the listed safety functions are used for safety component functionality.

3AXD10000099646 1 (2)





EU Declaration of Conformity

Machinery Directive 2006/42/EC

The following harmonized standards have been applied:

Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional EN 61800-5-2:2007

EN 62061:2005 + AC:2010 + Safety of machinery - Functional safety of safety-related electrical,

A1:2013 + A2:2015 electronic and programmable electronic control systems

Safety of machinery - Safety-related parts of control systems. Part 1: EN ISO 13849-1:2015 General requirements

Safety of machinery - Safety-related parts of the control systems. Part EN ISO 13849-2:2012 2: Validation

EN 60204-1: 2006 + A1:2009 + Safety of machinery - Electrical equipment of machines - Part 1: AC:2010 General requirements

The following other standards have been applied:

Functional safety of electrical / electronic / programmable electronic IEC 61508:2010

safety-related systems

Adjustable speed electrical power drive systems - Part 5-2: Safety IEC 61800-5-2:2016

requirements - Functional

The products referred in this Declaration of conformity fulfil the relevant provisions of other European Union Directives which are notified in Single EU Declaration of conformity 3AXD10000497831.

Person authorized to compile the technical file:

Name and address: Juha Martinmaa, Hiomotie 13, 00380 Helsinki, Finland.

Helsinki, 15 Sep 2017

Manufacturer representative:

Vesa Kandell Vice President, ABB Oy



Compliance with the EN 61800-3:2004 + A1:2012

Definitions

EMC stands for Electromagnetic Compatibility. It is the ability of electrical/electronic equipment to operate without problems within an electromagnetic environment. Likewise, the equipment must not disturb or interfere with any other product or system within its locality.

First environment includes establishments connected to a low-voltage network which supplies buildings used for domestic purposes.

Second environment includes establishments connected to a network not directly supplying domestic premises.

Drive of category C2: drive of rated voltage less than 1000 V and intended to be installed and started up only by a professional when used in the first environment.

Note: A professional is a person or organization having necessary skills in installing and/or starting up power drive systems, including their EMC aspects.

Drive of category C3: drive of rated voltage less than 1000 V, intended for use in the second environment and not intended for use in the first environment.

Category C2

The emission limits are complied with the following provisions:

- 1. The drive is equipped with EMC filter E202.
- 2. The motor and control cables are selected as specified in this manual.
- 3. The drive is installed according to the instructions given in this manual.
- 4. For the maximum motor cable length with 4 kHz switching frequency, see page 185.

WARNING! The drive may cause radio interference if used in residential or domestic environment. The user is required to take measures to prevent interference, in association to the requirements for the CE compliance listed above, if necessary.

Note: Do not install a drive with the internal EMC filter connected on IT (ungrounded). The supply network becomes connected to ground potential through the internal EMC filter capacitors which may cause danger or damage to the drive. For disconnecting the EMC filter see page 84.

Note: Do not install a drive with internal EMC filter connected on corner-grounded TN systems; otherwise the drive will be damaged. For disconnecting the internal EMC filter see page 84.



Category C3

The drive complies with the standard with the following provisions:

- 1. The drive is equipped with EMC filter E200.
- 2. The motor and control cables are selected as specified in this manual.
- 3. The drive is installed according to the instructions given in this manual.
- 4. For the maximum motor cable length with 4 kHz switching frequency, see page 185


WARNING! A drive of category C3 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.



Category C4

If the provisions under Category C3 cannot be met, the requirements of the standard can be met as follows:

1. It is ensured that no excessive emission is propagated to neighboring low-voltage networks. In some cases, the inherent suppression in transformers and cables is sufficient. If in doubt, the supply transformer with static screening between the primary and secondary windings can be used.





- 2. An EMC plan for preventing disturbances is drawn up for the installation. A template is available from the local ABB representative.
- 3. The motor and control cables are selected as specified in this manual.
- 4. The drive is installed according to the instructions given in this manual.

WARNING! A drive of category C4 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.

UL marking

The drive is cULus listed.

UL checklist

WARNING! Operation of this drive requires detailed installation and operation instructions provided in the hardware and software manuals. The manuals are provided in electric format in the drive package or on the Internet. Retain the manuals with the drive at all times. Hard copies of the manuals can be ordered through the manufacturer.

- Make sure that the drive type designation label includes the cULus Listed marking.
- CAUTION Risk of electric shock. After disconnecting the input power, always
 wait for 5 minutes to let the intermediate circuit capacitors discharge before you
 start working on the drive, motor or motor cable.
- The drive is to be used in a heated, indoor controlled environment. The drive must be installed in clean air according to the enclosure classification. Cooling air must be clean, free from corrosive materials and electrically conductive dust. (IP55)-UL Type 12 enclosure. This enclosure provides protection from airborne dust and light sprays or splashing water from all directions.
- The maximum surrounding air temperature is +55 °C (131 °F)at rated current.
 The current is derated for 40 to 55 °C (104 to 131 °F).
- The drive is suitable for use in a circuit capable of delivering not more than 100,000 rms symmetrical amperes, 480 V maximum when protected by the UL fuses on page 178. The ampere rating is based on tests done according to the appropriate UL standard.
- The cables located within the motor circuit must be rated for at least 75 °C (167 °F) in UL-compliant installations.
- Integral solid state short circuit protection does not provide branch circuit
 protection. The input cable must be protected with fuses. Suitable IEC (class aR)
 fuses are listed on page 176 and UL (class T) fuses on page 178. These fuses
 provide branch circuit protection in accordance with the National Electrical Code
 (NEC) and Canadian Electrical Code. For installation in the United States, obey
 any other applicable local codes. For installation in Canada, obey any applicable
 provincial codes.

Note: Circuit breakers must not be used without fuses in the USA. Consult ABB for suitable circuit breakers.



WARNING! The opening of the branch-circuit protective device may be an indication that a fault current has been interrupted. To reduce the risk of fire or electric shock, current-carrying parts and other components of the controller should



be examined and replaced if damaged.

- The drive provides motor overload protection. For the adjustments, see the firmware manual.
- For drive overvoltage category, see page 189. For pollution degree, see page



WEEE marking

The drive is marked with the wheelie bin symbol. It indicates that at the end of life the drive should enter the recycling system at an appropriate collection point and not placed in the normal waste stream. See section *Disposal* on page 191.



China RoHS marking

The People's Republic of China Electronic Industry Standard (SJ/T 11364-2014) specifies the marking requirements for hazardous substances in electronic and electrical products. The green mark is attached to the drive to verify that it does not contain toxic and hazardous substances or elements above the maximum concentration values, and that it is an environmentally-friendly product which can be recycled and reused.



EAC marking

The drive has EAC certification. EAC marking is required in Russia, Belarus and Kazakhstan.

Disclaimers

General disclaimer

The manufacturer shall have no obligation with respect to any product which (i) has been improperly repaired or altered; (ii) has been subjected to misuse, negligence or accident; (iii) has been used in a manner contrary to the manufacturer's instructions; or (iv) has failed as a result of ordinary wear and tear.

Cybersecurity disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion,

202 Technical data

leakage and/or theft of data or information. ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.




Dimension drawings


Contents of this chapter

This chapter shows the dimension drawings of the drive. The dimensions are given in millimeters and [inches].


R3, IP21 (UL Type 1)




R3 - Option +B056 (IP55, UL Type 12)




R6, IP21 (UL Type 1)




R6 - Option +B054 (IP55, UL Type 12)




R6 - Option +B056 (IP55, UL Type 12)




R8, IP21 (UL Type 1)



R8 - Option +B056 (IP55, UL Type 12)



R8 - Option +B056 (IP55, UL Type 12)



Safe torque off function

What this chapter contains

This chapter describes the Safe torque off (STO) function of the drive and gives instructions for its use.

Description

The Safe torque off function can be used, for example, as the final actuator device of safety circuits that stop the drive in case of danger (such as an emergency stop circuit). Another typical application is a prevention of unexpected start-up function that enables short-time maintenance operations like cleaning or work on nonelectrical parts of the machinery without switching off the power supply to the drive.

When activated, the Safe torque off function disables the control voltage of the power semiconductors of the drive output stage (A, see diagram on page 215), thus preventing the drive from generating the torque required to rotate the motor. If the motor is running when Safe torque off is activated, it coasts to a stop.

The Safe torque off function has a redundant architecture, that is, both channels must be used in the safety function implementation. The safety data given in this manual is calculated for redundant use, and does not apply if both channels are not used.

The Safe torque off function of the drive complies with these standards:

| Standard | Name |
|--|---|
| IEC 60204-1:2016 EN 60204-1:2006 + A1:2009 + AC:2010 | Safety of machinery – Electrical equipment of machines – Part 1: General requirements |
| IEC 61326-3-1:2008 | Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 3-1: Immunity requirements for safety-related systems and for equipment intended to perform safety-related functions (functional safety) – General industrial applications |
| IEC 61508-1:2010 | Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 1: General requirements |
| IEC 61508-2:2010 | Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 2: Requirements for electrical/electronic/programmable electronic safety-related systems |
| IEC 61511-1:2016 | Functional safety – Safety instrumented systems for the process industry sector |
| IEC 61800-5-2:2016 EN 61800-5-2:2007 | Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional |
| IEC 62061:2005 + A1:2012 + A2:2015 EN 62061:2005 + AC:2010 + A1:2013 + A2:2015 | Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems |
| EN ISO 13849-1:2015 | Safety of machinery – Safety-related parts of control systems – Part 1: General principles for design |
| EN ISO 13849-2:2012 | Safety of machinery – Safety-related parts of control systems – Part 2: Validation |

The function also corresponds to Prevention of unexpected start-up as specified by EN 1037:1995 + A1:2008 and Uncontrolled stop (stop category 0) as specified in EN 60204-1:

Compliance with the European Machinery Directive

See section Compliance with the European Machinery Directive on page 194.

Wiring


The following diagrams show examples of Safe torque off wiring for

- a single drive (page 215)
- multiple drives (page 216)
- multiple drives when an external 24 V power supply is used (page 217)


For drives with option +L357+Q971, see ATEX-certified Safe disconnection function, Ex II (2) GD for ACS880 drives (option +Q971) application guide (3AUA0000074343 [English] and FPTC-02 ATEX-certified thermistor relay module, Ex II (2) GD (+L537+Q971) for ACS880 drives user's manual 3AXD50000027782 [English])

For information on the specifications of the STO input, see section *Technical data* on page 100.


Single drive (internal power supply)



Multiple drives (internal power supply)



Multiple drives (external power supply)



Wiring examples

Activation switch

In the wiring diagrams above (page 215), the activation switch has the designation (K). This represents a component such as a manually operated switch, an emergency stop push button switch, or the contacts of a safety relay or safety PLC.

- If a manually operated activation switch is used, the switch must be of a type that can be locked out to the open position.
- The contacts of the switch or relay must open/close within 200 ms of each other.
- An FSO-xx safety functions module or an FPTC-0x thermistor protection module can also be used. For more information, see the module documentation.

Cable types and lengths

- Double-shielded twisted-pair cable is recommended.
- Maximum cable length
 - 300 m (984 ft) between activation switch (K) and drive control board.
 - 60 m (200 ft) between multiple drives
 - 60 m (200 ft) between external power supply and first drive

Note: The voltage at the INx terminals of the control unit must be at least 17 V DC to be interpreted as "1".

Operation principle

- 1. The Safe torque off activates (the activation switch is opened, or safety relay contacts open).
- 2. The STO inputs on the drive control unit de-energize.
- 3. The control unit cuts off the control voltage from the drive IGBTs.
- 4. The control program generates an indication as defined by parameter 31.22 (refer to the firmware manual of the drive).
- 5. Motor coasts to a stop (if running). The drive cannot restart while the activation switch or safety relay contacts are open. After the contacts close, a reset may be needed (depending on the setting of parameter 31.22). A new start command is required to start the drive.

Start-up including acceptance test

To ensure the safe operation of a safety function, validation is required. The final assembler of the machine must validate the function by performing an acceptance test. The acceptance test must be performed

- at initial start-up of the safety function
- after any changes related to the safety function (circuit boards, wiring, components, settings, etc.)
- after any maintenance work related to the safety function.

Competence

The acceptance test of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6. The test procedures and report must be documented and signed by this person.

Acceptance test reports

Signed acceptance test reports must be stored in the logbook of the machine. The report shall include documentation of start-up activities and test results, references to failure reports and resolution of failures. Any new acceptance tests performed due to changes or maintenance shall be logged into the logbook.

Acceptance test procedure

After wiring the Safe torque off function, validate its operation as follows.

Note: f the drive is equipped with safety option +Q972 or +Q973, do the procedure shown in the FSO module documentation. If an FSO-xx safety functions module or an FPTC-0x module is installed, refer to its documentation.

| Action | | √ | | | |
|--|---|----------|--|--|--|
| // / | NING! Follow the <i>Safety instructions</i> , page <i>13</i> . If you ignore the actions physical injury or death, or damage to the equipment can occur. | | | | |
| Ensure that the drive can be run and stopped freely during start-up. | | | | | |
| Stop the drive (if running), switch the input power off and isolate the drive from the power line by a disconnector. | | | | | |
| Check the Safe torque off circuit connections against the wiring diagram. | | | | | |
| Close the disconnector and switch the power on. | | | | | |

| Action | √ |
|--|----------|
| Test the operation of the STO function when the motor is stopped. Give a stop command for the drive (if running) and wait until the motor shaft is at a standstill. Ensure that the drive operates as follows: Open the STO circuit. The drive generates an indication if one is defined for the 'stopped' state in parameter 31.22 STO indication run/stop. For the description of the warning, see the firmware manual. Give a start command to verify that the STO function blocks the drive's operation. The drive displays a warning. The motor should not start. Close the STO circuit. Reset any active faults. Restart the drive and check that the motor runs normally. | |
| Test the operation of the STO function when the motor is running. Start the drive and ensure the motor is running. Open the STO circuit. The motor should stop. The drive generates an indication if one is defined for the 'running' state in parameter 31.22 STO indication run/stop. For the description of the warning, see the firmware manual Reset any active faults and try to start the drive. Ensure that the motor stays at a standstill and the drive operates as described above in testing the operation when the motor is stopped. Close the STO circuit. Reset any active faults. Restart the drive and check that the motor runs normally. | |
| Test the operation of the failure detection. The motor can be stopped or running. Open the 1st channel of the STO circuit (wire coming to IN1). If the motor was running, it should coast to a stop. The drive generates a FA81 Safe Torque Off 1 loss fault indication (see the firmware manual). Give a start command to verify that the STO function blocks the operation. The motor should not start. Close the STO circuit. Reset any active faults. Restart the drive and check that the motor runs normally. Open the 2nd channel of the STO circuit (wire coming to IN2). If the motor was running, it should coast to a stop. The drive generates a FA82 Safe Torque Off 2 loss fault indication (see the firmware manual). Give a start command to verify that the STO function blocks the operation. The motor should not start. Close the STO circuit. Reset any active faults. Restart the drive and check that the motor runs normally. | |
| Document and sign the acceptance test report which verifies that the safety function is safe and accepted for operation. | |

Use

- 1. Open the activation switch, or activate the safety functionality that is wired to the STO connection.
- 2. STO inputs on the drive control unit de-energize, and the drive control unit cuts off the control voltage from the output IGBTs.
- 3. The control program generates an indication as defined by parameter 31.22 STO indication run/stop.
- 4. The motor coasts to a stop (if running). The drive will not restart while the activation switch or safety relay contacts are open.
- 5. Deactivate the STO by closing the activation switch, or resetting the safety functionality that is wired to the STO connection.
- Reset any faults before restarting.



WARNING! The Safe torque off function does not disconnect the voltage of the main and auxiliary circuits from the drive. Therefore maintenance work on electrical parts of the drive or the motor can only be carried out after isolating the drive from the main supply.



WARNING! (With permanent magnet motors or synchronous reluctance [SynRM] motors only). In case of a multiple IGBT power semiconductor failure, the drive can produce an alignment torque which maximally rotates the motor shaft by 180/p degrees (with permanent magnet motors) or

180/2p degrees (with synchronous reluctance [SynRM] motors) regardless of the activation of the Safe torque off function. p denotes the number of pole pairs.

Notes:

- If a running drive is stopped by using the Safe torque off function, the drive will cut off the motor supply voltage and the motor will coast to a stop. If this causes danger or is not otherwise acceptable, stop the drive and machinery using the appropriate stop mode before activating the Safe torque off function.
- The Safe torque off function overrides all other functions of the drive unit.
- The Safe torque off function is ineffective against deliberate sabotage or misuse.
- The Safe torque off function has been designed to reduce the recognized hazardous conditions. In spite of this, it is not always possible to eliminate all potential hazards. The assembler of the machine must inform the final user about the residual risks.

Maintenance

After the operation of the circuit is validated at start-up, the STO function shall be maintained by periodic proof testing. In high demand mode of operation, the

maximum proof test interval is 20 years. In low demand mode of operation, the maximum proof test interval is 5 or 2 years; see section *Safety data (SIL, PL)* (page 223). It is assumed that all dangerous failures of the STO circuit are detected by the proof test. To perform the proof test, do the *Acceptance test procedure* (page 219).

Note: See also the Recommendation of Use CNB/M/11.050 (published by the European co-ordination of Notified Bodies) concerning dual-channel safety-related systems with electromechanical outputs:

- When the safety integrity requirement for the safety function is SIL 3 or PL e (cat. 3 or 4), the proof test for the function must be performed at least every month.
- When the safety integrity requirement for the safety function is SIL 2 (HFT = 1) or PL d (cat. 3), the proof test for the function must be performed at least every 12 months.

The STO function of the drive does not contain any electromechanical components.

In addition to proof testing, it is a good practice to check the operation of the function when other maintenance procedures are carried out on the machinery.

Include the Safe torque off operation test described above in the routine maintenance program of the machinery that the inverter runs.

If any wiring or component change is needed after start up, or the parameters are restored, follow the test given in section *Acceptance test procedure* on page 219.

Use only ABB approved spare parts.

Record all maintenance and proof test activities in the machine logbook.

Competence

The maintenance and proof test activities of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6.

Fault tracing

The indications given during the normal operation of the Safe torque off function are selected by parameter 31.22 STO indication run/stop.

The diagnostics of the Safe torque off function cross-compare the status of the two STO channels. In case the channels are not in the same state, a fault reaction function is performed and the drive trips on an "STO hardware failure" fault. An attempt to use the STO in a non-redundant manner, for example activating only one channel, will trigger the same reaction.

See the drive firmware manual for the indications generated by the drive, and for details on directing fault and warning indications to an output on the control unit for external diagnostics.

Any failures of the Safe torque off function must be reported to ABB.

Safety data (SIL, PL)

The safety data for the Safe torque off function is given below.

Note: The safety data is calculated for redundant use, and does not apply if both STO channels are not used.

| Frame size | SIL/ SILC L | sc | PL | SFF (%) | PFH (T ₁ = 20 a) (1/h) | PFD _{avg} (T ₁ = 2 a) | PFD _{avg} (T ₁ = 5 a) | MTTF _D | DC (%) | Cat. | HFT | CCF | Life- time (a) |
|------------------|--|----|----|------------|---|--|--|-------------------|----------------|------|-----|-----|----------------------|
| $U_{\rm N} = 40$ | U _N = 400 V, U _N = 500 V | | | | | | | | | | | | |
| R3 | 3 | 3 | е | 99.2 | 3.14E-09 | 2.62E-05 | 6.56E-05 | 10321 | <u>></u> 90 | 3 | 1 | 80 | 20 |
| R6 | 3 | 3 | е | 99.4 | 3.15E-09 | 2.62E-05 | 6.56E-05 | 10122 | <u>></u> 90 | 3 | 1 | 80 | 20 |
| R8 | 3 | 3 | е | 99.1 | 3,20E-09 | 2,66E-05 | 6,65E-05 | 10333 | <u>></u> 90 | 3 | 1 | 80 | 20 |

- The following temperature profile is used in safety value calculations:
 - 670 on/off cycles per year with $\triangle T$ = 71.66 °C
 - 1340 on/off cycles per year with $\triangle T$ = 61.66 °C
 - 30 on/off cycles per year with $\triangle T$ = 10.0 °C
 - 32 °C board temperature at 2.0% of time
 - 60 °C board temperature at 1.5% of time
 - 85 °C board temperature at 2.3% of time.
- The STO is a type A safety component as defined in IEC 61508-2.
- Relevant failure modes:
 - The STO trips spuriously (safe failure)
 - The STO does not activate when requested

A fault exclusion on the failure mode "short circuit on printed circuit board" has been made (EN 13849-2, table D.5). The analysis is based on an assumption that one failure occurs at one time. No accumulated failures have been analyzed.

- STO reaction time (shortest detectable break): 1 ms
- STO response time: 2 ms (typical), 5 ms (maximum)
- Fault detection time: Channels in different states for longer than 200 ms
- Fault reaction time: Fault detection time + 10 ms
- STO fault indication (parameter 31.22) delay: < 500 ms
- STO warning indication (parameter 31.22) delay: < 1000 ms

Abbreviations

| Abbr. | Reference | Description |
|--------------------|------------------|--|
| Cat. | EN ISO 13849-1 | Classification of the safety-related parts of a control system in respect of their resistance to faults and their subsequent behavior in the fault condition, and which is achieved by the structural arrangement of the parts, fault detection and/or by their reliability. The categories are: B, 1, 2, 3 and 4. |
| CCF | EN ISO 13849-1 | Common cause failure (%) |
| DC | EN ISO 13849-1 | Diagnostic coverage |
| HFT | IEC 61508 | Hardware fault tolerance |
| MTTF _d | EN ISO 13849-1 | Mean time to dangerous failure: (The total number of life units) / (the number of dangerous, undetected failures) during a particular measurement interval under stated conditions |
| PFD _{avg} | IEC 61508 | Average probability of dangerous failure on demand, that is, mean unavailability of a safety-related system to perform the specified safety function when a demand occurs. |
| PFH | IEC 61508 | Average frequency of dangerous failures per hour, that is, average frequency of a dangerous failure of a safety related system to perform the specified safety function over a given period of time. |
| PL | EN ISO 13849-1 | Performance level. Levels ae correspond to SIL |
| SC | IEC 61508 | Systematic capability |
| SFF | IEC 61508 | Safe failure fraction (%) |
| SIL | IEC 61508 | Safety integrity level (13) |
| SILCL | IEC/EN 62061 | Maximum SIL (level 13) that can be claimed for a safety function or subsystem |
| SS1 | IEC/EN 61800-5-2 | Safe stop 1 |
| STO | IEC/EN 61800-5-2 | Safe torque off |
| T1 | IEC 61508-6 | Proof test interval. T1 is a parameter used to define the probabilistic failure rate (PFH or PFD) for the safety function or subsystem. Performing a proof test at a maximum interval of T1 is required to keep the SIL capability valid. The same interval must be followed to keep the PL capability (EN ISO 13849) valid. Note that any T1 values given cannot be regarded as a guarantee or warranty. See also section <i>Maintenance and hardware diagnostics</i> on page 149. |



Common mode, du/dt and sine filters

What this chapter contains

This chapter describes how to select external filters for the drive.

Common mode filters

When is a common mode filter needed?

See section Checking the compatibility of the motor and drive, page 54. Common mode filter kits are available from ABB with order number 64315811. A kit includes three wound cores. For installation instructions of the cores, see the instruction included in the kit package.

du/dt filters

When is a du/dt filter needed?

See section Checking the compatibility of the motor and drive, page 54.

| Type ACS880 -11 | du/dt filter type | Type ACS880 -11 | du/dt filter type |
|-------------------------------|-------------------|-------------------------------|-------------------|
| <i>U</i> _N = 400 V | • | <i>U</i> _N = 500 V | • |
| 09A4-3 | NOCH0016-6X | 07A6-5 | NOCH0016-6X |
| 12A6-3 | NOCH0016-6X | 11A0-5 | NOCH0016-6X |
| 017A-3 | NOCH0030-6X | 014A-5 | NOCH0030-6X |
| 025A-3 | NOCH0030-6X | 021A-5 | NOCH0030-6X |
| 032A-3 | NOCH0070-6X | 027A-5 | NOCH0070-6X |
| 038A-3 | NOCH0070-6X | 034A-5 | NOCH0070-6X |
| 045A-3 | NOCH0070-6X | 040A-5 | NOCH0070-6X |
| 061A-3 | NOCH0070-6X | 052A-5 | NOCH0070-6X |
| 072A-3 | NOCH0120-6X | 065A-5 | NOCH0120-6X |
| 087A-3 | NOCH0120-6X | 077A-5 | NOCH0120-6X |
| 105A-3 | NOCH0120-6X | 101A-5 | NOCH0120-6X |
| 145A-3 | FOCH0260-70 | 124A-5 | FOCH0260-7X |
| 169A-3 | FOCH0260-70 | 156A-5 | FOCH0260-7X |
| 206A-3 | FOCH0260-70 | 180A-5 | FOCH0260-7X |

3AXD00000588487

Description, installation and technical data of the NOCH filters

See AOCH and NOCH du/dt filters hardware manual (3AFE58933368 [English]).

Sine filters

Selecting a sine filter for the drive

The table below lists the preselected sine filters by Epcos.

| Туре | Sine filter type | I _{cont.} | P _{cont.} | He | Noise | | |
|-----------------------------|------------------|--------------------|--------------------|-------|--------|-------|-------|
| ACS880 -11 | | max | max | Drive | Filter | Total | |
| -11 | | Α | kW | w | w | w | dB(A) |
| <i>U</i> _N = 400 | V | | | | | | |
| 09A4-3 | B84143V0011R229 | 10,0 | 4,0 | 122 | 90 | 212 | 72 |
| 12A6-3 | B84143V0016R229 | 12,9 | 5,5 | 172 | 80 | 252 | 72 |
| 017A-3 | B84143V0025R229 | 17 | 7,5 | 232 | 140 | 372 | 75 |
| 025A-3 | B84143V0025R229 | 25 | 11,0 | 337 | 140 | 477 | 75 |
| 032A-3 | B84143V0033R229 | 32 | 15,0 | 457 | 160 | 617 | 75 |
| 038A-3 | B84143V0050R229 | 38 | 18,5 | 562 | 220 | 782 | 78 |
| 045A-3 | B84143V0050R229 | 45 | 22,0 | 667 | 220 | 887 | 78 |

| Туре | Sine filter type | I _{cont.} | P _{cont.} | He | at dissipa | ation | Noise |
|------------------------|------------------|--------------------|--------------------|-------|------------|-------|-------|
| ACS880 -11 | | max | max | Drive | Filter | Total | |
| | | Α | kW | W | W | W | dB(A) |
| 061A-3 | B84143V0066R229 | 61 | 30,0 | 907 | 250 | 1157 | 78 |
| 072A-3 | B84143V0075R229 | 72 | 37,0 | 1117 | 310 | 1427 | 79 |
| 087A-3 | B84143V0095R229 | 87 | 45,0 | 1120 | 400 | 1520 | 79 |
| 105A-3 | B84143V0130S230 | 105 | 55,0 | 1295 | 600 | 1895 | 80 |
| 145A-3 | B84143V0162S229 | 145 | 75,0 | 1440 | 550 | 1990 | 80 |
| 169A-3 | B84143V0162S229 | 169 | 90,0 | 1940 | 550 | 2490 | 80 |
| 206A-3 | B84143V0230S229 | 206 | 110,0 | 2310 | 900 | 3210 | 80 |
| U _N = 500 V | | | | | | | |
| 07A6-5 | B84143V0011R229 | 7,6 | 4,0 | 122 | 90 | 212 | 72,0 |
| 11A0-5 | B84143V0011R229 | 11,0 | 5,5 | 172 | 90 | 262 | 72,0 |
| 014A-5 | B84143V0016R229 | 14 | 7,5 | 232 | 80 | 312 | 70 |
| 021A-5 | B84143V0025R229 | 21 | 11,0 | 337 | 140 | 477 | 75 |
| 027A-5 | B84143V0033R229 | 27 | 15,0 | 457 | 160 | 617 | 75 |
| 034A-5 | B84143V0050R229 | 34 | 18,5 | 562 | 220 | 782 | 78 |
| 040A-5 | B84143V0050R229 | 40 | 22,0 | 667 | 220 | 887 | 78 |
| 052A-5 | B84143V0066R229 | 52 | 30,0 | 907 | 250 | 1157 | 78 |
| 065A-5 | B84143V0066R229 | 65 | 37,0 | 1117 | 250 | 1367 | 78 |
| 077A-5 | B84143V0075R229 | 77 | 37,0 | 1120 | 310 | 1430 | 78 |
| 101A-5 | B84143V0130S230 | 96 | 55,0 | 1295 | 630 | 1925 | 80 |
| 124A-5 | B84143V0130S230 | 124 | 55,0 | 1440 | 630 | 2070 | 80 |
| 158A-5 | B84143V0162S229 | 156 | 90,0 | 1940 | 550 | 2490 | 80 |
| 180A-5 | B84143V0162S229 | 180 | 110,0 | 2310 | 550 | 2860 | 80 |

3AXD00000588487

Definitions

| P _{cont.max} | Maximum continuous output power of the drive |
|-----------------------|--|
| I _{cont.max} | Maximum continuous output current of the drive |
| Noise | Noise level of the sine filter |

Derating

See section Deratings for special settings in the drive control program on page 171.

Description, installation and technical data

For the filter data sheets, go to http://en.tdk.eu/. See also *Sine filters hardware manual* (3AXD50000016814 [English])

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at www.abb.com/drives/documents.

Contact us

www.abb.com/drives www.abb.com/drivespartners

3AXD50000045932 Rev B (EN) EFFECTIVE: 2018-03-09 Corrections: 2018-04-09