

631

Serielles Übertragungsprotokoll
serial transfer protocol



Series



Serielles Übertragungsprotokoll 631

Serial transfer protocol 631

Typ / Model: EASY-seriell 631

Produkt-Handbuch

Product manual

Weitere Unterlagen,
die im Zusammenhang mit
diesem Dokument stehen.

631 - Produkt-Handbuch

*Further descriptions,
that relate to this document.*

UL: 7.1.8.2



631 - Product manual

© **EUROTHERM** Antriebstechnik GmbH.
Alle Rechte vorbehalten. Kein Teil der Beschreibung darf
in irgendeiner Form, ohne Zustimmung der Gesellschaft
vervielfältigt oder weiter verarbeitet werden.

Änderungen sind ohne vorherige Ankündigung
vorbehalten.

EUROTHERM hat für seine Produkte teilweise Waren-
zeichenschutz und Gebrauchsmusterschutz eintragen
lassen. Aus dem Überlassen der Beschreibungen darf
nicht angenommen werden, daß damit eine Übertragung
von irgendwelchen Rechten stattfindet.

Hergestellt in Deutschland, 1998

© **EUROTHERM Drives Limited.**
*All rights reserved. No portion of this description may
be produced or processed in any form without the
consent of the company.*

Changes are subject to change without notice.

EUROTHERM has registered in part trademark
protection and legal protection of designs. The handing
over of the descriptions may not be construed as the
transfer of any rights.

Made in Germany, 1998

INHALTSVERZEICHNIS **CONTENTS**

Seite/Page

1	Serielles Übertragungsprotokoll.....<i>Serial transfer protocol</i>	6
1.1	Schnittstellen-Einstellung für X15	<i>Standard interface setting for X15</i> 6
1.2	Beispiel-Codierung.....	<i>Example for encoding.....</i> 7
1.3	BCC-Bildung.....	<i>Setting up the BCC</i> 8
1.4	Zahlendarstellung in den Befehlen.....	<i>Numbers representation in the commands</i> 9
1.4.1	2 Byte hexadezimale Werte (WORD)	<i>2 byte hexadecimal values (WORD)</i> 9
1.4.2	4 Byte hexadezimale Werte (LWORD)	<i>4 byte hexadecimal values (LWORD)</i> 9
1.4.3	4 Byte Fließkommawerte (FLOAT).....	<i>4 byte floating point values (FLOAT)</i> 10
1.5	Normierungen der Parameter	<i>Parameters scaling</i> 10
2	Serieller Befehlssatz <i>Serial command set</i>	11
2.1	Befehl 0: 631 deaktivieren	<i>Command 0: disable 631.....</i> 11
2.2	Befehl 1: 631 aktivieren	<i>Command 1: activate 631.....</i> 11
2.3	Befehl 2: 631-Reset.....	<i>Command 2: 631-Reset</i> 12
2.4	Befehl 3: Hostlogin	<i>Command 3: Hostlogin</i> <i>(Anmeldung ausführen).....</i> 12
2.5	Befehl 4: Hostlogout	<i>Command 4: Hostlogout</i> <i>(Anmeldung aufheben).....</i> 13
2.6	Befehl 5: Daten in das EEPROM übertragen.....	<i>Command 5: Transfer data</i> <i>in the EEPROM</i> 13
2.7	Befehl 6:	<i>Command 6:</i> <i>631 Firmwareversion lesen</i> 14
2.8	Befehl 7:	<i>Command 7:</i> <i>631 Diagnoseinformationen</i> 15
2.9	Befehl 13:	<i>Command 13:</i> <i>BIAS-Satzzeiger setzen</i> 16
2.10	Befehl 16:	<i>Command 16:</i> <i>631 Diagnoseinformationen 2</i> 16
2.11	Befehl 17:	<i>Command 17:</i> <i>631 interne Diagnoseinformationen</i> 17
2.12	Befehl 22:	<i>Command 22:</i> <i>631 EEPROM-Zeiger lesen.....</i> 18
2.13	Befehl 23: Positionierbefehl.....	<i>Command 23: positioning command.....</i> 18
2.14	Befehl 33: BIAS-Diagnose lesen.....	<i>Command 33: read BIAS diagnosis</i> 19
2.15	Befehl 34: Variablen / Merker lesen	<i>Command 34: read variables / flags</i> 20
2.16	Befehl 36: Positionssatz starten.....	<i>Command 36: start position set</i> 21
2.17	Befehl 37:	<i>Command 37:</i> <i>CAN-BUS Diagnose lesen</i> 21
2.18	Befehl 39: Merker/Variable vorladen.....	<i>Command 39: flag/variable preset.....</i> 22
2.19	Befehl 37:	<i>Command 37:</i> <i>Power down Diagnose lesen.....</i> 22
2.20	Befehl 47: serieller Drehzahlsollwert.....	<i>Command 47: serial speed setpoint</i> 23
2.21	Befehl 48: SUCOnet K Simulation	<i>Command 48: SUCOnet K simulation</i> 23
2.22	Befehl 62 a:	<i>Command 62 a:</i> <i>Nennstrom Motor lesen</i> 24
2.23	Befehl 62 b:	<i>Command 62 b:</i> <i>Nennstrom Motor schreiben.....</i> 24

INHALTSVERZEICHNIS *CONTENTS*

	Seite/Page
2.24 Befehl 65 a:..... <i>Command 65 a:</i> Konfigurationsparameter lesen..... <i>read configuration parameters</i>	25
2.25 Befehl 65 b: Konfigurations- <i>Command 65 b: write</i> parameter schreiben..... <i>configuration parameters</i>	26
2.26 Befehl 66 a: Drehzahlregler- <i>Command 66 a: read parameters</i> parameter lesen..... <i>of the speed controller</i>	27
2.27 Befehl 66 b: Drehzahlregler- <i>Command 66 b: write parameters</i> parameter schreiben..... <i>of the speed controller</i>	28
2.28 Befehl 67 a:..... <i>Command 67 a:</i> Stromreglerparameter lesen..... <i>read parameters of the current controller</i>	29
2.29 Befehl 67 b:..... <i>Command 67 b:</i> Stromreglerparameter schreiben..... <i>write parameters of the current controller</i>	30
2.30 Befehl 68 a:..... <i>Command 68 a:</i> Lagereglerparameter lesen..... <i>read parameters of the position controller</i>	31
2.31 Befehl 68 b: Lageregler-..... <i>Command 68 b: write</i> parameter schreiben..... <i>parameters of the position controller</i>	32
2.32 Befehl 69 a: Positionssatz lesen <i>Command 69 a: read position set</i>	33
2.33 Befehl 69 b: Positionssatz schreiben <i>Command 69 b: write position set</i>	37
2.34 Befehl 72 a: Synchronprofil- <i>Command 72 a: Read cam-profile</i> parameterblock lesen <i>parameter set</i>	38
2.35 Befehl 72 b: Synchronprofil- <i>Command 72 b: Write cam-profile</i> parameterblock schreiben <i>parameter set</i>	39
2.36 Befehl 73 a: Stützstellenblock lesen <i>Command 73 a: Read profil point block</i>	40
2.37 Befehl 73 b: Stützstellenblock schreiben..... <i>Command 73 b: Write profil point block</i>	41
2.38 Befehl 74 a: E/A Definitionen lesen <i>Command 74 a: read I/O definitions</i>	42
2.39 Befehl 74 b: E/A Definitionen schreiben <i>Command 74 b: write I/O definitions</i>	43
2.40 Befehl 75a: CAN-Busparameter lesen..... <i>Command 75a: read CAN-bus parameters</i>	44
2.41 Befehl 75b: <i>Command 75b:</i> CAN-Busparameter schreiben <i>write CAN-bus parameters</i>	46
2.42 Befehl 76 a: BIAS-Programm lesen <i>Command 76 a: read BIAS-programm</i>	47
2.43 Befehl 76 b: <i>Command 76 b:</i> BIAS-Programm schreiben..... <i>write BIAS-Programm</i>	48
2.44 Befehl 78 a: Erweiterte Regel- <i>Command 78 a: read extended control</i> parameter lesen <i>parameters</i>	49
2.45 Befehl 78 b: Erweiterte Regel- <i>Command 78 b: write extended</i> parameter schreiben <i>control parameters</i>	49
3 Anhang.....<i>Appendix</i>	50
4 Änderungsliste<i>Modification Record</i>.....	53


1 Serielles Übertragungsprotokoll *Serial transfer protocol*

1.1 Schnittstellen-Einstellung für X15

19200 Baud
gerade Parität
1 Startbit
8 Datenbit
1 Stopbit

X15 RS232

4-Pol Modular-Buchse,
4-pole Modular-Jack




Standard interface setting for X15

19200 baud
even parity
1 start bit
8 data bits
1 stop bit

PC RS232

SUB D 9
Buchse
Ansicht auf Lötseite
female
view to solder side



RXD	1	631 Receive serial Data	PC Receive serial Data	3	RXD
TXD	2	631 Transmit serial Data	PC Transmit serial Data	2	TXD
	3	do not connect		do not connect	
GND	4	631GND	PC GND	5	GND

➤ Kabel komplett konfektioniert erhältlich

➤ *Cable ready to use available*

Jeder Befehl, der vom PC zum 631 gesendet wird, muß mit dem Zeichen ESC (1Bh) eingeleitet werden

An das ESC-Zeichen schließt sich die Nummer der angesprochenen Achse (immer 1) an.

Danach folgt eine Befehlskennung.
Abhängig von der Befehlskennung sind Datenbytes zu senden.

Beendet wird der Befehl mit dem BCC-Zeichen¹.

Jeder akzeptierte Befehl wird mit ACK(06h) (verstanden) quittiert.

Kann ein Befehl nicht korrekt interpretiert werden (Befehlscodierung nicht eingehalten, BCC nicht korrekt), so wird mit NAK (15h) (nicht verstanden) quittiert.

Wird der Befehl nicht innerhalb einer Maximalzeit² übertragen, so wird mit TIMEOUT (TOUT, 16h) quittiert.

Every command sent by the PC to the 631, must be introduced with the sign ESC (1Bh).

The ESC-sign follows the number of the concerned axis (1).

*Then a command code follows.
Depended on the command code data bytes have to be sent.*

The command is cancelled with the BCC-sign¹.

Every accepted command is acknowledged with ACK (06h) (understood).

If a command cannot be interpreted correctly (not kept command coding, BCC not correct), it is acknowledged with NAK (15h) (not understood).

If the command is not transmitted within a maximum time², it is acknowledged with TIMEOUT (TOUT, 16h)

¹ BCC-Bildung siehe Kapitel 1.4

² ca. 40 ms

Schnittstellen-Einstellung für X15

Die Fehlermeldungen NAK, TIMEOUT werden sofort nach dem Erkennen des Fehlers gesendet.

Danach ist der 631 wieder bereit, eine neue Befehlssequenz zu empfangen.

Ist der Befehl korrekt übertragen worden, aber im Betriebszustand des 631 nicht zulässig³, wird der Befehl mit einem CAN (18h) quittiert.

Quittungszeichen ACK, CAN, NAK und TIMEOUT sind nicht der Kreuzsicherung unterzogen.

Wird ein Befehl gesendet, der den 631 zur Rücksendung von Daten veranlaßt, z.B. Diagnoseinformationen auslesen, so wird erst das Erkennen des Befehls mit ACK quittiert. Anschließend werden die Daten mit BCC-Zeichen gesendet.

Standard interface setting for X15

The error messages NAK, TIMEOUT are sent immediately after recognizing the error.

Then the 631 is ready again to receive a new command sequency.

If the command was transmitted correctly, but not permissible in the operating mode of the 631 time³, the command is acknowledged with a CAN (18h).

Acknowledgement signs ACK, CAN, NAK, TIMEOUT are not subject to cross check.

If a command is sent, inducing the 631 to return data, e.g. read out diagnosis information, at first recognizing the command with ACK is acknowledged. Then the data with BCC-signs are sent.

1.2 Beispiel-Codierung

Example for encoding


condition/activity	631	example command	host	length	condition/action
explanation of the condition an reaction of the drive.	  	<p>< < < < request from host <<<<</p> <p>Beginning of the command axis-number command data 0 data n BCC</p> <p>ESC 1 01 2 hex 3 hex 4 hex 5 hex</p> <p>→ → → response from 631 !!! → → →</p> <p>Command was correctly transmitted and executed</p> <p>with read-commands data in response BCC</p> <p>byte n ---- byte 0 1-n</p> <p>hex n+1</p> <p>Command was not transmitted correctly</p> <p>Command was transmitted correctly but is not allowed in the current operating mode.</p> <p>Command was not transmitted completely</p> <p>NAK CAN TOUT</p>	  	number of send Byte number of receive byte	explanation of the EASYRIDER conditions and menue and hotkey selection.

³ z.B. fehlende Anmeldung für Parameterbefehle o.ä.


1.3 BCC-Bildung

Das BCC-Zeichen wird über das ganze Befehlswort gebildet, beginnend mit ESC ... bis zum BCC. Das BCC-Zeichen selbst wird nicht der Prüfung unterzogen.
Gebildet wird es durch eine "Exclusive Oder"-Verknüpfung der zu übertragenden Bytes

BEISPIEL:



EXAMPLE:




$$\text{BCC} = \text{<} \text{ESC} \text{>} \text{ XOR } \text{<} 1 \text{>} \text{ XOR } \text{<} 0 \text{>} = \text{1Ah}$$

$$\text{BCC} = \text{<} \text{ESC} \text{<} \text{XOR} \text{<} 1 \text{>} \text{ XOR } \text{<} 0 \text{>} = \text{1Ah}$$

631: <ACK>
631: <ACK>

Kreuzsicherung des 631 bei Lesebefehlen
Cross check of the 631 with read commands



$$\text{BCC} = \text{<} \text{ACK} \text{>} \text{ XOR } \text{<} \text{HEX} \text{>}$$

$$\text{BCC} = \text{<} \text{ACK} \text{>} \text{ XOR } \text{<} \text{HEX} \text{>}$$

Setting up the BCC

The BCC-sign is set up with the whole command word, beginning with ESC ... up to the BCC. The BCC-sign itself is not subject to the check.

It is set up via an "Exclusive Or"- connection of the bytes to be transmitted.

1.4 Zahlendarstellung in den Befehlen

1.4.1 2 Byte hexadezimale Werte (WORD)

Zahlenbereich $\pm 2^{15}$ (signed integer)

Beispiel: Der hexadezimale Wert 0123h stellt sich folgendermaßen dar:

01 = High-Byte (Byte 1)

23 = Low-Byte (Byte 2)

Reihenfolge innerhalb des seriellen Befehls:

Numbers representation in the commands

2 byte hexadecimal values (WORD)


Number range $\pm 2^{15}$ (signed integer)

Example: The hexadecimal value 0123h represents itself as follows:

01 = High-Byte (Byte 1)

23 = Low-Byte (Byte 2)

Precedence within the serial command:



1.4.2 4 Byte hexadezimale Werte (LWORD)

Zahlenbereich $\pm 2^{31}$ (signed long)

Beispiel: Der hexadezimale Wert 01234567h stellt sich folgendermaßen dar:

01 = High-Byte (Byte 1)

23 = Low-Byte (Byte 2)

45 = High-Byte (Byte 3)

67 = Low-Byte (Byte 4)

Reihenfolge innerhalb des seriellen Befehls:

4 byte hexadecimal values (LWORD)

Zahlenbereich $\pm 2^{31}$ (signed long)

Example: The hexadecimal value 01234567h represents itself as follows:


01 = High-Byte (Byte 1)

23 = Low-Byte (Byte 2)

45 = High-Byte (Byte 3)

67 = Low-Byte (Byte 4)

Precedence within the serial command:




1.4.3 4 Byte Fließkommawerte (FLOAT)

Zahlenbereich ca. $\pm 1,18 \times 10^{-38} \dots \pm 3,40 \times 10^{38}$

4 byte floating point values (FLOAT)

Number range approx. $\pm 1,18 \times 10^{-38} \dots \pm 3,40 \times 10^{38}$



V = Vorzeichen (0 = positiv; 1 = negativ)

1 = Exponent (2^n Multiplikator; n = Exponent-127)

2 = Mantisse (Bit 22=2⁰)

Beispiel: Der Fließkommawert 3.141592654

stellt sich als 4 Byte hexadezimaler Wert

folgendermaßen dar: 40 49 0F DB h

d.h. Vorzeichen = 0

Exponent = 80h; n=1; 2ⁿ=2

Mantisse = 490FDBh

V = Sign (0 = positive; 1 = negative)

I = Exponent (2^n Multiplier; n = Exponent-127)

2 = Mantissa (Bit 22=2⁰)

Example: The floating point value 3.141592654

represents itself as follows as 4 bytes of

hexadecimal value: 40 49 0F DB h

that is Sign = 0

Exponent = 80h; n=1; 2ⁿ=2

Mantissa = 490FDBh

4				9									0						F						D						B					
0	-1	-2	-3	-4	-5	-6	-7	-8	-9	-	10	-	11	12	13	14	-	15	16	17	18	19	-	20	-	21	-	22								
1	0	0	1	0	0	1	0	0	0	0	1	1	1	1	1	1	1	0	1	1	0	1	1	0	1	1	1	1	1							
$2+2^0+2^{-3}+2^{-6}+2^{-2}-11+2^{-12}+2^{-13}+2^{-14}+2^{-15}+2^{-16}+2^{-18}+2^{-19}+2^{-21}+2^{-22}= 3,141592741013$																																				

40 = Byte 1

40 = Byte 1

49 = Byte 2

49 = Byte 2

0F = Byte 3


0F = Byte 3

DB = Byte 4

DB = Byte 4

Reihenfolge innerhalb des seriellen Befehls:

Precedence within the serial command:



1.5 Normierungen der Parameter

Parameters scaling

Nummer number	Normierung	scaling
1	Wert = v [min^{-1}] * 2	value = v [rpm] * 2
2	Wert = a [min^{-1}/s] / 5	value = a [rpm/s] / 5
3		

2 Serieller Befehlssatz

Serial command set

2.1 Befehl 0: 631 deaktivieren

Funktion:

Dieser Befehl deaktiviert den 631.

Der Befehl ist jederzeit erlaubt.

Command 0: disable 631

Function:

This command disables the 631.

This command is allowed at any time.

condition/activity	631	command 0 : disable 631	host	length	condition/action
This command disables the 631 This command is allowed at any time. The display shows /-/ if there is now higher prior sign.		<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command axis-number command</p> <p>BCC (1B xor 01 xor 00 = 1A)</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and executed</p> <p>Command was not transmitted correctly</p> <p>Command was not transmitted completely</p>		4 Byte	EASYRIDER menu „command“; „deactivate drive“ or hotkey F10
				1 Byte	

2.2 Befehl 1: 631 aktivieren

Command 1: activate 631

Funktion:

Dieser Befehl hebt die Wirkung des Befehl 0 "631 deaktivieren" auf.

Der Befehl ist jederzeit erlaubt.

Function:

This command cancels the effect of the command 0 "disable 631"

The command is allowed at any time.

condition/activity	631	command 1 : activate 631	host	length	condition/action
This command cancels the effect of the command 0 "disable 631". This command is allowed at any time.		<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command axis-number command</p> <p>BCC (1B xor 01 xor 01 = 1B)</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and executed</p> <p>Command was not transmitted correctly</p> <p>Command was not transmitted completely</p>		4 Byte	EASYRIDER menu „command“; „activate drive“ or hotkey shift+F10
				1 Byte	

2.3 Befehl 2: 631-Reset

Funktion:

Dieser Befehl setzt eine erkannte Fehlerbedingung zurück.

Der Befehl ist nur erlaubt, wenn der PC angemeldet ist und der 631 deaktiviert wurde.

Command 2: 631-Reset

Function:

This command resets a recognized error code.

The command is only allowed when the PC is logged in and the 631 was enabled.

condition/activity	631	command 2 : reset 631	host	length	condition/action
This command resets a recognized error code.		< < < < request ??? <<< 1 2 3 BCC (1B xor 01 xor 02 = 18)		4 Byte	EASYRIDER menu „command“; „reset drive“
The command is only allowed when the PC is logged in and the 631 was enabled		→ → → → response !!! → → → Command was correctly transmitted and executed Command was not transmitted correctly Command was transmitted correctly but is not allowed in the current operating mode. Command was not transmitted completely	 	1 Byte	

2.4 Befehl 3: Hostlogin (Anmeldung ausführen)

Funktion:

Dieser Befehl führt die Hostanmeldung des PC aus.

Der Befehl ist nur erlaubt, wenn nicht bereits eine Hostanmeldung vorliegt.

Command 3: Hostlogin (execute login)

Function:

This command executes the hostlogin of the PC.

The command is only allowed, when there is not already a hostlogin.

condition/activity	631	command 3 : hostlogin	host	length	condition/action
This command executes the hostlogin of the PC.		< < < < request ??? <<< 1 2 3 BCC (1B xor 01 xor 03 = 19)		4 Byte	EASYRIDER menu „command“; „PC login“ or hotkey F6
The command is only allowed, when there is not already a hostlogin.		→ → → → response !!! → → → Command was correctly transmitted and executed Command was not transmitted correctly Command was sent correctly, but there is already a login Command was not transmitted completely	 	1 Byte	
Notice : for several commands it is necessary to set the drive in the host login mode.					

2.5 Befehl 4: Hostlogout (Anmeldung aufheben)

Funktion:

Dieser Befehl hebt eine zuvor ausgeführte Hostanmeldung wieder auf.

Der Befehl ist nur erlaubt, wenn eine Hostanmeldung vorliegt.

Command 4: Hostlogout (cancel login)

Function:

This command cancels a hostlogin executed before.

This command is only allowed, when a hostlogin exists.

condition/activity	631	command 4 : hostlogout	host	length	condition/action
<p>This command cancels a hostlogin executed before. This command is only allowed, when a hostlogin exists.</p> <p>Notice : for several commands it is necessary to set the drive in the host login mode.</p>		<p>← ← ← ← request ??? ← ← ← ← ESC 1 01 2 04 3 1E BCC (1B xor 01 xor 04 = 1E) → → → → response !!! → → → → Command was correctly transmitted and executed Command was not transmitted correctly Command was sent correctly, but there is no login Command was not transmitted completely</p>	 	4 Byte 1 Byte	EASYRIDER menu „command“; „PC logout“ or hotkey shift + F6

2.6 Befehl 5: Daten in das EEPROM übertragen

Funktion:

Dieser Befehl startet das Speichern der 631-Parameter im EEPROM.

Der Befehl ist nur nach Anmeldung erlaubt⁴, weiterhin muß der 631 deaktiviert sein und nicht bereits eine Speicherung gestartet worden sein.

Command 5: Transfer data in the EEPROM

Function:

This command starts storing the 631-parameters in the EEPROM.

The command is only allowed after having logged in⁴, furthermore the 631 must be disabled and a storage may not be started already.

condition/activity	631	command 5 : transfer data to EEPROM	host	length	condition/action
<p>This command starts storing the 631-parameters in the EEPROM. The command is only allowed after having logged in, furthermore the 631 must be disabled and a storage may not be started already.</p>		<p>← ← ← ← request ??? ← ← ← ← ESC 1 01 2 05 3 1F BCC (1B xor 01 xor 05 = 1F) → → → → response !!! → → → → Command was correctly transmitted and executed Command was not transmitted correctly Command was sent correctly, but the conditions are not met. Command was not transmitted completely</p>	 	4 Byte 1 Byte	EASYRIDER menu „command“; „store all data“ or hotkey F7 notice : the store procedure can be controlled with the command 16h ⁵

⁴ siehe Befehl 3: Hostlogin, Kapitel 2.4

⁵ siehe Befehl 16h EEPROM Zeiger Kapitel 2.23.

see command 3: Hostlogin, chapter 2.4

see command 16h: read 631 EEPROM pointer, chapter 2.23

2.7 Befehl 6: 631 Firmwareversion lesen

Funktion:

Dieser Befehl liest die aktuelle Version der 631-Firmware aus.

Der Befehl ist jederzeit erlaubt

Command 6: read 631 firmware version

Function:

This command reads out current the version of the 631-firmware.

The command is allowed at any time.

condition/activity	631	command 6 : read 631 firmwareversion	host	length	condition/action																														
<p>This command reads out current the version of the 631-firmware. The command is allowed at any time.</p> <p>The ASCII-text of the firmware version looks like:</p> <p>6 3 1 _ V _ 5 . 1 0 a _</p>	 	<p>← ← ← ← request ??? ← ← ← ← ESC Beginning of the command 1 01 2 06 3 1C BCC (1B xor 01 xor 06 = 1C) → → → → response !!! → → → → Command was correctly transmitted and sends the following data byte 1 6 byte 2 3 byte 3 1 byte 4 byte 5 V byte 6 byte 7 5 byte 8 . byte 9 1 byte 10 0 byte 11 a byte 12 ACK <table border="1"> <tr><td>36</td><td>1</td></tr> <tr><td>33</td><td>2</td></tr> <tr><td>31</td><td>3</td></tr> <tr><td>20</td><td>4</td></tr> <tr><td>56</td><td>5</td></tr> <tr><td>20</td><td>6</td></tr> <tr><td>35</td><td>7</td></tr> <tr><td>2E</td><td>8</td></tr> <tr><td>31</td><td>9</td></tr> <tr><td>30</td><td>10</td></tr> <tr><td>61</td><td>11</td></tr> <tr><td>20</td><td>12</td></tr> <tr><td>BCC</td><td>13</td></tr> </table> <table border="1"> <tr><td>Command was not transmitted correctly</td><td>NAK</td></tr> <tr><td>Command was not transmitted completely</td><td>TOUT</td></tr> </table> </p>	36	1	33	2	31	3	20	4	56	5	20	6	35	7	2E	8	31	9	30	10	61	11	20	12	BCC	13	Command was not transmitted correctly	NAK	Command was not transmitted completely	TOUT	 	4 Byte 14 Byte 1 Byte	
36	1																																		
33	2																																		
31	3																																		
20	4																																		
56	5																																		
20	6																																		
35	7																																		
2E	8																																		
31	9																																		
30	10																																		
61	11																																		
20	12																																		
BCC	13																																		
Command was not transmitted correctly	NAK																																		
Command was not transmitted completely	TOUT																																		

2.8 Befehl 7: 631 Diagnoseinformationen

Command 7: 631 Diagnosis information

condition/activity	631	command 7 : read 631 diagnosis information	host	length	condition/action
This command reads out the diagnosis information of the 631. The command is allowed at any time	 <p>← ← ← ← request ??? ← ← ← ← ESC 1 01 2 07 3 1D BCC (1B xor 01 xor 07 = 1D)</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data error word; low byte⁶; high byte⁷ status word 1; low byte⁸; high byte⁹ status word 2; low byte¹⁰; high byte¹¹ operating word; lowbyte¹²;highbyte¹³ actual speed at scaling 1 input-output state¹⁴ reserve actual position at increments reserve BCC 21 Command was not transmitted correctly Command was not transmitted completely</p> <p>ACK word 1 word 3 word 5 word 7 word 9 byte 11 byte 12 lword 13 lword 17 NAK TOUT</p>	 <p>Beginning of the command axis-number command 22 Byte</p> <p>22 Byte</p> <p>1 Byte</p>			

⁶errorword; low byte

7	6	5	4	3	2	1	0
I ² t-motor	Overvoltage	Temperature of the output stage too high	Motor temperature too high	Resolver error	-	input activ befor ready	Overcurrent (Software)

⁷errorword; high byte

15	14	13	12	11	10	9	8
Watchdog-Reset	Internal stop	Overcurrent (Hardware)	-	trailing error + deactive	EEPROM-check total	Ballast power exceeded	I ² t-regulator

⁸statusword1; low byte

7	6	5	4	3	2	1	0
analog. Setpoint within setpoint zero window	Warning output stage temperature	Warning I ² t-regulator	Warning motor temperature	Warning I ² t-motor	-	Undervoltage	Output stage passive

⁹statusword1; high byte

15	14	13	12	11	10	9	8
limit switch detected	Warning	Speed controller without I-component	EEPROM-protect storage runs	EEPROM-storage runs	Warning ballast power	-	EEPROM-active

¹⁰statusword2 low byte

7	6	5	4	3	2	1	0
Position reached	-	-	X20 CAN 631 disabled	-	X20 CAN send istpos 2	X 20 CAN hostlogin	-

¹¹statusword2 high byte

15	14	13	12	11	10	9	8
Trailing distance o.K	-	initialised (move datum)	X15 631 disabled	position reached dynamic	-	X15 hostlogin	X15 active

¹²operatingword; low byte

7	6	5	4	3	2	1	0
Operating mode position control with BIAS(5)	-	-	Internal setpoint generator	Operating mode position control	Operating mode speed(0)-current(1) control	-	-

¹³operatingword; high byte

15	14	13	12	11	10	9	8
-	-	-	-	virtual axis activ	-	-	-

¹⁴input output state

7	6	5	4	3	2	1	0
input X10.10	input X10.9	input X10.8	input X10.7	-	-	output X10.6	output X10.5

2.9 Befehl 13: BIAS-Satzzeiger setzen

*Command 13:
set BIAS process pointer*

condition/activity	631	command 0D : set BIAS process pointer	host	length	condition/action					
This command sets the BIAS-process pointer. notice : operating mode 5 and running BIAS – programm is necessary!		<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <table border="1"> <tr><td>ESC</td></tr> <tr><td>1 01</td></tr> <tr><td>2 0D</td></tr> <tr><td>3 word</td></tr> <tr><td>5 hex</td></tr> </table> <p>axis-number command</p> <p>processpointer (0 – 1499)</p> <p>BCC</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and executed</p> <p>Command was not transmitted correctly</p> <p>Command was sent correctly, but the conditions are not met. (pointer > 1499)</p> <p>Command was not transmitted completely</p>	ESC	1 01	2 0D	3 word	5 hex	 	6 Byte 1 Byte	
ESC										
1 01										
2 0D										
3 word										
5 hex										

2.10 Befehl 16: 631 Diagnoseinformationen 2

*Command 16:
631 Diagnosis information 2*

condition/activity	631	command 10 : read 631 diagnosis information 2	host	length	condition/action																																						
This command reads out the diagnosis information 2 of the 631. The command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <table border="1"> <tr><td>ESC</td></tr> <tr><td>1 01</td></tr> <tr><td>2 10</td></tr> <tr><td>3 0A</td></tr> </table> <p>axis-number command</p> <p>BCC (1B xor 01 xor 10 = 0A)</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and sends the following data</p> <table border="1"> <tr><td>word</td><td>1</td></tr> <tr><td>word</td><td>3</td></tr> <tr><td>word</td><td>5</td></tr> <tr><td>word</td><td>7</td></tr> <tr><td>word</td><td>9</td></tr> <tr><td>word</td><td>11</td></tr> <tr><td>word</td><td>13</td></tr> <tr><td>word</td><td>15</td></tr> <tr><td>word</td><td>17</td></tr> <tr><td>word</td><td>19</td></tr> <tr><td>word</td><td>21</td></tr> <tr><td>word</td><td>23</td></tr> <tr><td>word</td><td>25</td></tr> <tr><td>word</td><td>27</td></tr> <tr><td>word</td><td>29</td></tr> <tr><td>lword</td><td>31</td></tr> <tr><td>lword</td><td>35</td></tr> </table> <p>error word 1; see command 7</p> <p>status word 1; see command 7</p> <p>status word 2; see command 7</p> <p>operating word; see command 7</p> <p>actual speed without scaling</p> <p>actual I² motor value</p> <p>actual current value</p> <p>actual UCC value</p> <p>actual I² drive value</p> <p>actual break resistor power</p> <p>reserve (0)</p> <p>input outputstate; see command 7</p> <p>absolut value resolver (16 Bit)</p> <p>actual analog setpoint value</p> <p>actual motor temp. value</p> <p>actual position at increments</p> <p>internal calculation time</p> <p>BCC</p> <p>Command was not transmitted correctly</p> <p>Command was not transmitted completely</p>	ESC	1 01	2 10	3 0A	word	1	word	3	word	5	word	7	word	9	word	11	word	13	word	15	word	17	word	19	word	21	word	23	word	25	word	27	word	29	lword	31	lword	35	 	4 Byte 40Byte 1 Byte	
ESC																																											
1 01																																											
2 10																																											
3 0A																																											
word	1																																										
word	3																																										
word	5																																										
word	7																																										
word	9																																										
word	11																																										
word	13																																										
word	15																																										
word	17																																										
word	19																																										
word	21																																										
word	23																																										
word	25																																										
word	27																																										
word	29																																										
lword	31																																										
lword	35																																										

2.11 Befehl 17: 631 interne Diagnoseinformationen

Command 17: 631 intern Diagnosis informations

condition/activity	631	command 11 : read 631 intern diagnosis informations	host	length	condition/action																																		
This command reads out the intern diagnosis information of the 631. The command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ← ESC 1 01 2 11 3 0B BCC (1B xor 01 xor 11 = 0B)</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data drive-type (1;2;4;6) intern serial number production-data repair-number I_nom² motor (intern units) A FULL(Ieff* 1,414 *100) I NORM (internal factor) I_nom² drive(intern units) break resistor power (in watt) UCC_NORM (internal factor) reserve CONFIG_CODE^{15,16} maximum speed (intern 32000) speed factor (intern)</p> <table border="1"> <tr><td>word</td><td>1</td></tr> <tr><td>word</td><td>3</td></tr> <tr><td>word</td><td>5</td></tr> <tr><td>word</td><td>7</td></tr> <tr><td>word</td><td>9</td></tr> <tr><td>word</td><td>11</td></tr> <tr><td>word</td><td>13</td></tr> <tr><td>word</td><td>15</td></tr> <tr><td>word</td><td>17</td></tr> <tr><td>word</td><td>19</td></tr> <tr><td>word</td><td>21</td></tr> <tr><td>word</td><td>23</td></tr> <tr><td>word</td><td>25</td></tr> <tr><td>lword</td><td>27</td></tr> <tr><td>BCC</td><td>31</td></tr> <tr><td>Command was not transmitted correctly</td><td>NAK</td></tr> <tr><td>Command was not transmitted completely</td><td>TOUT</td></tr> </table>	word	1	word	3	word	5	word	7	word	9	word	11	word	13	word	15	word	17	word	19	word	21	word	23	word	25	lword	27	BCC	31	Command was not transmitted correctly	NAK	Command was not transmitted completely	TOUT		4 Byte	
word	1																																						
word	3																																						
word	5																																						
word	7																																						
word	9																																						
word	11																																						
word	13																																						
word	15																																						
word	17																																						
word	19																																						
word	21																																						
word	23																																						
word	25																																						
lword	27																																						
BCC	31																																						
Command was not transmitted correctly	NAK																																						
Command was not transmitted completely	TOUT																																						

15

7	6	5	4	3	2	1	0
internal break resistor actic	-	-	current limiting with warning	motor temp. sensor NTC	high resolver resolution	-	-

16

15	14	13	12	11	10	9	8
count direction X40 istpos2 input		rotation direction	-	-	position control on istposition 2	-	input "active" monitoring switched on

2.12 Befehl 22: 631 EEPROM-Zeiger lesen

*Command 22:
read 631 EEPROM-pointer*

condition/activity	631	command 16 : pointer of save data	host	length	condition/action
This command reads out the status and the pointer of the EEPROM storage. The command is allowed at any time..	  	<p>← ← ← ← request ??? ← ← ← ← Beginning of the command</p> <p>ESC 1 01 2 16 3 0A BCC (1B xor 01 xor 16 = 0A)</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data</p> <p>Pointer of the EEPROM storage State of the EEPROM storage (0 = no storage active)</p> <p>byte 1 byte 2</p> <p>BCC 3</p> <p>Command was not transmitted correctly Command was not transmitted completely</p> <p>ACK NAK TOUT</p>	 	4 Byte 4 Byte 1 Byte	

2.13 Befehl 23: Positionierbefehl

Funktion:

Dieser Befehl startet eine Positionierung mit den angegebenen Parametern.

Der Befehl ist nur erlaubt, wenn die Anmeldung ausgeführt wurde, sich der 631 in der Betriebsart Lageregelung befindet und der 631 aktiv ist

*Command 23:
positioning command*

Function:

This command starts positioning with the stated parameters.

The command is only allowed when the login was executed, the 631 is in the operating mode of positioning regulation, and the 631 is active.

condition/activity	631	command 17 : 631 positioning command	host	length	condition/action
This command starts positioning with the stated parameters. The command is only allowed when the login was executed, the 631 is in the operating mode of positioning regulation, and the 631 is active!	  	<p>← ← ← ← request ??? ← ← ← ← Beginning of the command</p> <p>ESC 1 01 2 17 3 byte 4 word 6 word 8 word 10 word 12 lword 16 hex BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and executed</p> <p>Nominal speed at scaling 1 Acceleration at scaling 2 Deceleration at scaling 2 position-window at incr.</p> <p>ACK NAK CAN TOUT</p>	 	17 Byte 1 Byte	

¹⁷ siehe Befehl 69a

see command 69 a

2.14 Befehl 33: BIAS-Diagnose lesen

Funktion:

Dieser Befehl liest Informationen über den aktuellen Zustand der BIAS-Abarbeitung.
Dieser Befehl ist immer erlaubt

Command 33: read BIAS diagnosis

Function:

This command reads informations about the status of BIAS-execution.
The command is allowed at any time.

condition/activity	631	command 21 : read 631 BIAS diagnosis informations	host	length	condition/action																																	
This command reads informations about the status of BIAS-execution. The command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ← Beginning of the command axis-number command BCC (1B xor 01 xor 21 = 3B)</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data BIAS execution pointer PLC execution pointer block number at strobe BIAS stack wait time BIAS status¹⁸ PLC status¹⁹ PLC stack actual position 1 actual position 2 act. pos. 3 (canbus absolute encoder) reserve reserve</p> <table border="1"> <tr><td>word</td><td>1</td></tr> <tr><td>word</td><td>3</td></tr> <tr><td>word</td><td>5</td></tr> <tr><td>word</td><td>7</td></tr> <tr><td>word</td><td>9</td></tr> <tr><td>word</td><td>11</td></tr> <tr><td>word</td><td>13</td></tr> <tr><td>word</td><td>15</td></tr> <tr><td>lword</td><td>17</td></tr> <tr><td>lword</td><td>21</td></tr> <tr><td>lword</td><td>25</td></tr> <tr><td>word</td><td>29</td></tr> <tr><td>word</td><td>31</td></tr> <tr><td>BCC</td><td>33</td></tr> <tr><td>NAK</td><td></td></tr> <tr><td>TOUT</td><td></td></tr> </table> <p>Command was not transmitted correctly Command was not transmitted completely</p>	word	1	word	3	word	5	word	7	word	9	word	11	word	13	word	15	lword	17	lword	21	lword	25	word	29	word	31	BCC	33	NAK		TOUT			4 Byte	34Byte	1 Byte
word	1																																					
word	3																																					
word	5																																					
word	7																																					
word	9																																					
word	11																																					
word	13																																					
word	15																																					
lword	17																																					
lword	21																																					
lword	25																																					
word	29																																					
word	31																																					
BCC	33																																					
NAK																																						
TOUT																																						

¹⁸ BIAS status low-byte

7	6	5	4	3	2	1	0
-	-	Warte auf IBT-Kommunikation	IBT-Fehler	Stackfehler	Start nicht möglich	ungültiger Parameter	ungültiger BIAS Befehl
-	-	wait for IBT-communication	IBT error	stack error	Start not possible	parameter not valid	BIAS command not valid

BIAS status high-byte

15	14	13	12	11	10	9	8
-	-	-	Warte auf Position	BIAS-Programmabarbeitung aktiv	-	-	Warte auf Starteingang
-	-	-	Wait for position reached	BIAS program execution active	-	-	wait for start input

¹⁹ PLC status low-byte

7	6	5	4	3	2	1	0
-	-	-	-	stack error plc	-	parameter not valid	plc command not valid

PLC status high-byte

15	14	13	12	11	10	9	8
-	-	-	-	PLC program execution active	-	-	-

2.15 Befehl 34: Variablen / Merker lesen

Funktion:

Dieser Befehl liest den Inhalt der angegebenen Variablen- oder Merkerblöcke.

Dieser Befehl ist immer erlaubt

Command 34: read variables / flags

Function:

This command reads the content of the desired variables or flags group.

The command is allowed at any time.

condition/activity	631	command 22 : read flags or variables	host	length	condition/action
This command reads the content of the desired variables or flags group. The command is allowed at any time!.		<p>← ← ← ← request ??? ← ← ← ← Beginning of the command axis-number command variable = 0 / flag = 1 group number; variable (0 – 15) flag (0 – 3) BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data ACK</p> <p>byte 1 * 1 * 64 byte 64 64 BCC 65</p> <p>Command was not transmitted correctly NAK</p> <p>Command was sent correctly, but the conditions are not met.(groupnumber) CAN</p> <p>Command was not transmitted completely TOUT</p>		6 Byte 66 Byte 1 Byte	64 * byte or 16 * lword

2.16 Befehl 36: Positionssatz starten

Funktion:

Dieser Befehl aktiviert den angegebenen Positionssatz (0-9). Der Befehl ist nur erlaubt, wenn die Anmeldung ausgeführt wurde, sich der 631 in der Betriebsart Lageregelung befindet und der 631 aktiv ist.
Die Positionssätze müssen vorher mit dem Befehl 69 geladen werden !!

Command 36: start position set

Function:

*This command activates the position-block(0-9).
The command is only allowed when the login was executed, the 631 is in the operating mode of positioning regulation, and the 631 is active.
The position blocks must be programmed with the command 69 first !!*

condition/activity	631	command 24 : start position block 631	host	length	condition/action
This command activates the position-block(0-9). The command is only allowed when the login was executed, the 631 is in the operating mode of positioning regulation, and the 631 is active. The position blocks must be programmed with the command 69 first!! !		<p>← ← ← ← request ??? ← ← ← ← Beginning of the command</p> <p>ESC 1 01 2 24 3 byte 4 hex</p> <p>axis-number command position block number (0 – 9) BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and executed Command was not transmitted correctly Command was sent correctly, but the conditions are not met. (blocknumber > 9) Command was not transmitted completely</p>		6Byte	

2.17 Befehl 37: CAN-BUS Diagnose lesen

Funktion:

Dieser Befehl liest den Inhalt des angegebenen CAN-BUS Objektes (0-15).
Dieser Befehl ist immer erlaubt

Command 37: read CAN-BUS diagnosis

Function:

*This command reads the content of the desired CAN-BUS object (0-15).
The command is allowed at any time.*

condition/activity	631	command 25 : read CAN-BUS diagnosis	host	length	condition/action												
This command reads the content of the desired CAN-BUS object (0-15). The command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ← Beginning of the command</p> <p>ESC 1 01 2 25 3 byte 4 hex</p> <p>axis-number command object number;(0 – 15) BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data can-message counter</p> <table border="1"> <tr><td>byte 1</td><td>1</td></tr> <tr><td>*</td><td></td></tr> <tr><td>*</td><td></td></tr> <tr><td>byte 16</td><td>16</td></tr> <tr><td>word</td><td>17</td></tr> <tr><td>BCC</td><td>19</td></tr> </table> <p>Command was not transmitted correctly Command was sent correctly, but the conditions are not met. (groupnumber) Command was not transmitted completely</p>	byte 1	1	*		*		byte 16	16	word	17	BCC	19		5 Byte 20 Byte 1 Byte	
byte 1	1																
*																	
*																	
byte 16	16																
word	17																
BCC	19																

2.18 Befehl 39: Merker/Variable vorladen

Funktion:

Dieser Befehl lädt den gesendeten Wert in den angegebenen Merker bzw. die angegebene Variable. Der Befehl ist immer erlaubt.

Command 39: flag/variable preset

Function:

*This command presets the content of the desired flag or variable with the transmitted value.
The command is allowed at any time.*

condition/activity	631	command 27 : write variable / flag	host	length	condition/action
<p>This command presets the content of the desired flag or variable with the transmitted value. The command is allowed at any time.</p>		<p>← ← ← ← request ??? ← ← ← ← Beginning of the command ESC 1 01 2 27 3 byte 4 byte 5 lword 9 hex BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and executed ACK Command was not transmitted correctly NAK Command was not transmitted completely TOUT</p>		10 Byte	

2.19 Befehl 37: Power down Diagnose lesen

Funktion:

Dieser Befehl liest den Inhalt des angegebenen Power down speicherblocks (0-7).

Dieser Befehl ist immer erlaubt

Command 37: read power down memory diagnosis

Function:

*This command reads the content of the desired power down memory block (0-7).
The command is allowed at any time.*

condition/activity	631	command 29 : read power down diagnosis	host	length	condition/action
<p>This command reads the content of the desired power down memory block (0-7). The command is allowed at any time</p> <p>It is possible to get the last 8 powerdown situations.</p>		<p>← ← ← ← request ??? ← ← ← ← Beginning of the command ESC 1 01 2 29 3 byte 4 hex BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data ACK byte 1 1 * * byte 16 16 BCC 17 Command was not transmitted correctly NAK Command was sent correctly, but the conditions are not met. (blocknumber) CAN Command was not transmitted completely TOUT</p>		5 Byte	

2.20 Befehl 47: serieller Drehzahlsollwert

Funktion:

Dieser Befehl aktiviert den angegebenen Wert als Drehzahlsollwert.

Der Befehl ist nur in der Betriebsart „Drehzahlregelung ohne analogen Sollwert“ verwendbar. Siehe Befehl 48 ; Sub-Befehl 24.

Command 47: serial speed setpoint

Function:

This command activate the given value as speed setpoint.

The command is only suitable in the operating mode “speed control without analogous set point value”. see command 48; subcommand 24;

condition/activity	631	command 2F : serial speed setpoint	host	length	condition/action
<p>This command activate the given value as speed setpoint. The command is only suitable in the operating mode “speed control without analogous set point value” !</p>	 	<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command axis-number command speed with scaling 1 BCC</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and executed Command was not transmitted correctly Command was not transmitted completely</p>	 	6 Byte 1 Byte	

2.21 Befehl 48: SUCOnet K Simulation

Funktion:

Dieser Befehl erlaubt die Verwendung des SUCOnet K Protokolls über die serielle Schnittstelle.²⁰

Command 48: SUCOnet K simulation

Function:

This command permit using the SUCOnet K-protocol via the serial interface.²⁰

condition/activity	631	command 30 : bus 16 byte simulation	host	length	condition/action
<p>This command permit using the SUCOnet K-protocol via the serial interface.</p>	 	<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command axis-number command Bus command byte 1 Bus command byte 16 BCC</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and sends the following data bus-status byte 1 bus-status byte 16</p> <p>Command was not transmitted correctly Command was sent correctly, but the conditions are not met. Command was not transmitted completely</p>	 	20 Byte 18 Byte 1 Byte	

²⁰ siehe Dokumentation 7.5.2.3. „Businterface SUCOnet K“

see documentation 7.5.2.3. „bus interface SUCOnet K“

2.22 Befehl 62 a: Nennstrom Motor lesen

Funktion:

Dieser Befehl liest den Motor Nennstrom.
Das Lesen des Befehles ist immer erlaubt.

Command 62 a: read rated current of the motor

Function:

*This command reads the rated current motor.
Reading the command is allowed at any time.*

condition/activity	631	command 3E : read rated current motor	host	length	condition/action
This command reads the rated current of the motor. Reading the command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>axis-number command read-option = 0 BCC</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and sends the following data rated current * $\sqrt{2} * 100$</p> <p>word 1</p> <p>BCC 3</p> <p>Command was not transmitted correctly</p> <p>NAK</p> <p>TOUT</p>		5 Byte	

2.23 Befehl 62 b: Nennstrom Motor schreiben

Funktion:

Dieser Befehl schreibt den Motor Nennstrom.
Der Befehl ist nur erlaubt wenn die
Anmeldung ausgeführt wurde und der 631
deaktiviert wurde.

Command 62 b: write rated current of the motor

Function:

*This command writes the rated current motor.
The command is only allowed when the login
was executed and the 631 was disabled.*

condition/activity	631	command 3E : write rated current motor	host	length	condition/action
This command writes the rated current motor. The command is only allowed when the login was executed and the 631 was disabled.		<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>axis-number command write-option = 1 rated current * $\sqrt{2} * 100$ BCC</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted</p> <p>ACK</p> <p>Command was not transmitted correctly</p> <p>NAK</p> <p>Command was sent correctly, but the conditions are not met.</p> <p>CAN</p> <p>Command was not transmitted completely</p> <p>TOUT</p>		7 Byte	

2.24 Befehl 65 a: Konfigurationsparameter lesen


Funktion:

Dieser Befehl liest die Konfigurationsparameter. Das Lesen des Befehl ist immer erlaubt.

Command 65 a: read configuration parameters

Function:

This command reads the configuration parameters. Reading the command is allowed at any time.

condition/activity	631	command 41: read configuration parameters	host	length	condition/action
This command reads the configuration parameters Reading the command is allowed at any time	 	<p>← ← ← ← request ??? ← ← ← ← ESC 1 01 2 41 3 00 4 hex</p> <p>Beginning of the command axis-number command read-option = 0 BCC</p> <p>→ → → → response !!! → → → → ACK</p> <p>Command was correctly transmitted and sends the following data Network axis number (1-255;not used) Configuration word Low²¹, High²² Operating mode (0-5)²³ reserve Rated current motor *100 * $\sqrt{2}$ Pole pair number (1-6) EMC/1000 min⁻¹ at Volt Motor inductivity at $\frac{1}{10}$ mH Motor resistance at $\frac{1}{10}$ Ohm I²t-monitoring time of the motor at sec. NTC-resistance T1 at Ohm NTC-resistance T2 at Ohm PTC-resistance at Ohm Regulator-disable time value (0-3) Ucc-low threshold at Volt Ucc-ballast threshold at Volt Ballast resistance at $\frac{1}{10}$ Ohm Ballast power at Watt BCC Command was not transmitted correctly Command was not transmitted completely</p> <p>byte 1 word 2 byte 4 byte 5 word 6 word 8 word 10 word 12 word 14 word 16 word 18 word 20 word 22 word 24 word 26 word 28 word 30 word 32 NAK TOUT</p> <p>34</p>	 	5 Byte 35 Byte 1 Byte	

²¹

7	6	5	4	3	2	1	0
<i>internal ballast active</i>			<i>current limiting at warning active</i>	<i>PTC motor temperature sensor</i>	<i>high resolver resolution</i>		

²²

7	6	5	4	3	2	1	0
<i>count direction X40</i> <i>1 = positive</i>	-	<i>rotation direction</i> <i>I = positive</i>			<i>position control with 0=pos. 1 I=position 2</i>	<i>monitoring of the control voltage active</i>	<i>monitoring of the active-input activated</i>

²³

5	4	3	2	1	0
<i>position control with BIAS-execution</i>	<i>position control without BIAS-execution</i>	<i>speed control</i>	<i>current control</i>	<i>speed control</i>	<i>speed control</i>

2.25 Befehl 65 b: Konfigurationsparameter schreiben

Funktion:

Dieser Befehl schreibt die Konfigurationsparameter.

Der Befehl ist nur erlaubt wenn die Anmeldung ausgeführt wurde und der 631 deaktiviert wurde.

Command 65 b: write configuration parameters

Function:

This command writes the configuration parameters.

The command is only allowed when the login was executed and the 631 was disabled.

condition/activity	631	command 41 : write configuration parameter	host	length	condition/action
This command writes the configuration parameters. The command is only allowed when the login was executed and the 631 was disabled	    <pre> < < < < request ??? <<< Beginning of the command axis-number command write-option = 1 Network axis number (1-255;not used) Configuration word ²⁴, High ²⁵ Operating mode (0-5) ²⁶ reserve Rated current motor *100 * √2 Pole pair number (1-6) EMC/1000 min⁻¹ at Volt Motor inductivity at $\frac{1}{10}$ mH Motor resistance at $\frac{1}{10}$ Ohm I²t-monitoring time of the motor at sec. NTC-resistance T1 at Ohm NTC-resistance T2 at Ohm PTC-resistance at Ohm Regulator-disable time value (0-3) Ucc-low threshold at Volt Ucc-ballast threshold at Volt Ballast resistance at $\frac{1}{10}$ Ohm Ballast power at Watt BCC hex → → → response !!! → → → → Command was correctly transmitted Command was not transmitted correctly Command was sent correctly, but the conditions are not met. Command was not transmitted completely </pre>	   		38 Byte	

²⁴ siehe "Konfigurationsparameter lesen" auf vorheriger Seite
²⁵

see "read configuration parameter" on previous page

2.26 Befehl 66 a: Drehzahlregler-parameter lesen

Funktion:

Dieser Befehl liest die Drehzahlregler-parameter.

Der Befehl ist immer erlaubt.

Command 66 a: read parameters of the speed controller

Function:

This command reads the parameters of the speed controller.

The command is allowed at any time

condition/activity	631	command 42 : read speed loop parameters	host	length	condition/action
This command reads the parameters of the speed controller. The command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>axis-number</p> <p>command</p> <p>read-option = 0</p> <p>BCC</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and sends the following data</p> <p>ACK</p> <p>word 1</p> <p>word 3</p> <p>word 5</p> <p>word 7</p> <p>word 9</p> <p>word 11</p> <p>word 13</p> <p>word 15</p> <p>word 17</p> <p>word 19</p> <p>word 21</p> <p>BCC 23</p> <p>NAK</p> <p>TOUT</p> <p>²⁷ List place speed loop P-component List place speed loop I-component maximum current at 3.125 % steps Setpoint zero window at 1.22 mV steps Setpoint integrator at 10 rpm/s Speed setpoint norming at 0,1 rpm current setpoint norming 0,001 ampere reserve reserve reserve Setpoint offset correction value at 1.22 mV steps</p>		5 Byte 24 Byte 1 Byte	

²⁷ siehe Kapitel 3 "Anhang"

see chapter 3 "Appendix"

2.27 Befehl 66 b: Drehzahlregler-parameter schreiben

Funktion:

Dieser Befehl schreibt die Drehzahlregler-parameter.

Der Befehl ist nur nach Anmeldung erlaubt.

Command 66 b: write parameters of the speed controller

Function:

This command writes the parameters of the speed controller.

The command is only allowed after logging in.

condition/activity	631	command 42 : write speed loop parameter	host	length	condition/action																																										
This command writes the speed loop parameters. The command is only allowed when the login was executed and the 631 was disabled	   	<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>axis-number</p> <p>command</p> <p>write-option = 1</p> <table border="1"> <tr><td>1</td><td>ESC</td></tr> <tr><td>2</td><td>01</td></tr> <tr><td>2</td><td>42</td></tr> <tr><td>3</td><td>01</td></tr> <tr><td>4</td><td>word</td></tr> <tr><td>6</td><td>word</td></tr> <tr><td>8</td><td>word</td></tr> <tr><td>10</td><td>word</td></tr> <tr><td>12</td><td>word</td></tr> <tr><td>14</td><td>word</td></tr> <tr><td>16</td><td>word</td></tr> <tr><td>18</td><td>word</td></tr> <tr><td>20</td><td>word</td></tr> <tr><td>22</td><td>word</td></tr> <tr><td>24</td><td>word</td></tr> <tr><td>26</td><td>hex</td></tr> <tr><td></td><td>BCC</td></tr> </table> <p>→ → → → response !!! → → → →</p> <table border="1"> <tr><td>Command was correctly transmitted</td><td>ACK</td></tr> <tr><td>Command was not transmitted correctly</td><td>NAK</td></tr> <tr><td>Command was sent correctly, but the conditions are not met.</td><td>CAN</td></tr> <tr><td>Command was not transmitted completely</td><td>TOUT</td></tr> </table>	1	ESC	2	01	2	42	3	01	4	word	6	word	8	word	10	word	12	word	14	word	16	word	18	word	20	word	22	word	24	word	26	hex		BCC	Command was correctly transmitted	ACK	Command was not transmitted correctly	NAK	Command was sent correctly, but the conditions are not met.	CAN	Command was not transmitted completely	TOUT	   	27 Byte	1 Byte
1	ESC																																														
2	01																																														
2	42																																														
3	01																																														
4	word																																														
6	word																																														
8	word																																														
10	word																																														
12	word																																														
14	word																																														
16	word																																														
18	word																																														
20	word																																														
22	word																																														
24	word																																														
26	hex																																														
	BCC																																														
Command was correctly transmitted	ACK																																														
Command was not transmitted correctly	NAK																																														
Command was sent correctly, but the conditions are not met.	CAN																																														
Command was not transmitted completely	TOUT																																														

2.28 Befehl 67 a: Stromreglerparameter lesen

Funktion:

Dieser Befehl liest die Stromreglerparameter.
Der Befehl ist immer erlaubt.

Command 67 a: read parameters of the current controller

Function:

This command reads the parameters of the current controller. The command is allowed at any time.

condition/activity	631	command 43 : read current loop parameter	host	length	condition/action
This command reads the parameters of the current controller. The command is allowed at any time.	 ESC 1 01 2 43 3 00 4 hex → → → response !!! → → → Command was correctly transmitted and sends the following data List place P-component ²⁸ List place I-component ²⁸ reserved reserved reserve reserve Offset resolver position in 1/65536 Ucc overvoltage threshold at volt reserved word 1 word 3 word 5 word 7 word 9 word 11 word 13 word 15 word 17 BCC 19 Command was not transmitted correctly Command was not transmitted completely NAK TOUT	 	5 Byte 20 Byte 1 Byte		

²⁸ siehe Kapitel 3 "Anhang"

2.29 Befehl 67 b: Stromreglerparameter schreiben

Funktion:

Dieser Befehl schreibt die Stromreglerparameter.


Der Befehl ist nur nach Anmeldung erlaubt

Command 67 b: write parameters of the current controller

Function:

This command writes the parameters of the current controller.

The command is only allowed after logging in.

condition/activity	631	command 43 : write current loop parameter	host	length	condition/action
This command writes the parameters of the current controller. The command is only allowed after logging in.	   	<pre> < < < < request ??? <-<-< ESC 1 01 2 43 3 01 4 word 6 word 8 word 10 word 12 word 14 word 16 word 18 hex BCC → → → → response !!! → → → → Command was correctly transmitted Command was not transmitted correctly Command was sent correctly, but the conditions are not met. Command was not transmitted completely </pre> <p>Beginning of the command axis-number command write-option = 1 List place P-component (0-127) List place I-component (0-127) reserved reserved Offset resolver position Ucc overvoltage threshold reserved BCC</p> <p>ACK NAK CAN TOUT</p>	 	19 Byte 1Byte	

2.30 Befehl 68 a: Lagereglerparameter lesen

Funktion:

Dieser Befehl liest die Lagereglerparameter.



Der Befehl ist immer erlaubt.

Command 68 a: read parameters of the position controller

Function:

This command reads the parameters of the position controller.

The command is allowed at any time.

condition/activity	631	command 44 : read position loop parameter	host	length	condition/action
This command reads the parameters of the position controller. The command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p>  <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and sends the following data</p> <p>Nominal speed at scaling 1</p> <p>Acceleration at scaling 2</p> <p>Deceleration at scaling 2</p> <p>"Position reached"-window at incr.</p> <p>P-component²⁹</p> <p>I-component²⁹</p> <p>V-component (0- 255 %)</p> <p>ACK</p>  <p>BCC</p> <p>NAK</p> <p>TOUT</p>		5 Byte	

²⁹ siehe Kapitel 3 "Anhang"

see chapter 3 "Appendix"

2.31 Befehl 68 b: Lageregler-parameter schreiben

Funktion:

Dieser Befehl schreibt die Lageregler-parameter.


Der Befehl ist nur nach Anmeldung erlaubt.

Command 68 b: write parameters of the position controller

Function:

This command writes the parameters of the position controller.

The command is only allowed after logging in.

condition/activity	631	command 44 : write position loop parameter	host	length	condition/action								
This command writes the parameters of the position controller. The command is only allowed after logging in.	     	<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>axis-number</p> <p>command</p> <p>write-option = 1</p> <p>Nominal speed at scaling 1</p> <p>Acceleration at scaling 2</p> <p>Deceleration at scaling 2</p> <p>”Position reached”-window at incr.</p> <p>P-component³⁰</p> <p>I-component³⁰</p> <p>V-component (0- 255 %)</p> <p>18 hex BCC</p> <p>→ → → → response !!! → → → →</p> <table border="1"> <tr><td>Command was correctly transmitted</td><td>ACK</td></tr> <tr><td>Command was not transmitted correctly</td><td>NAK</td></tr> <tr><td>Command was sent correctly, but the conditions are not met.</td><td>CAN</td></tr> <tr><td>Command was not transmitted completely</td><td>TOUT</td></tr> </table>	Command was correctly transmitted	ACK	Command was not transmitted correctly	NAK	Command was sent correctly, but the conditions are not met.	CAN	Command was not transmitted completely	TOUT	   	19 Byte	
Command was correctly transmitted	ACK												
Command was not transmitted correctly	NAK												
Command was sent correctly, but the conditions are not met.	CAN												
Command was not transmitted completely	TOUT												

³⁰ siehe Kapitel 3, „Anhang“

see chapter 3 “Appendix“

2.32 Befehl 69 a: Positionssatz lesen

Funktion:

Dieser Befehl liest einen Positionssatz.
Der Befehl ist immer erlaubt.

Command 69 a: read position set

Function:

This command reads a position set.
The command is allowed at any time

condition/activity	631	command 45 : read position set parameter	host	length	condition/action
This command reads a position set. The command is allowed at any time	<p>Request structure:</p> <ul style="list-style-type: none"> 1 ESC 2 01 (axis-number) 3 45 (command) 4 00 (read-option = 0) 5 byte (number of position set (0-9)) BCC (Byte Count Checksum) <p>Response structure:</p> <ul style="list-style-type: none"> 1 ACK (acknowledgment) 2 byte (1) 3 word (3) 4 word (5) 5 word (7) 6 word (9) 7 lword (11) 8 BCC (15) 9 NAK (not acknowledged) 10 CAN (correctly sent, but number > 9) 11 TOUT (transmission error) 			6 Byte	

³¹ siehe Befehlsliste auf der nächsten Seite

see command list on next page

Befehl 69 a: Positionssatz lesen

Command 69 a: read position set

Befehl <i>command</i>	Name <i>name</i>	Erklärung <i>explanation</i>
1	Fahre absolut <i>Move absolute</i>	Es wird auf die angegebene Position gefahren <i>Moves to the specified position</i>
2	Fahre Kettenposition <i>Move incremental</i>	Es wird auf die Position gefahren, die sich aus der aktuellen Sollposition dem Positionsparameter ergibt <i>Moves to the position resulting from the setpoint position + the positioning parameter</i>
3	Fahre + <i>Move +</i>	Es wird mit der angegebene Geschwindigkeit positiv gefahren <i>Moves in a positive direction at the specified speed</i>
4	Fahre - <i>Move -</i>	Es wird mit der angegebene Geschwindigkeit negativ gefahren <i>Moves in a negative direction at the specified speed</i>
5	Fahre ± mit analoger Geschwindigkeit <i>Move ± with analog speed</i>	Es wird mit der sich aus dem Sollwerteing. (X10.18, X10.5) ergebenden Geschwindigkeit (Analogwert Normierung für Sollwert) gefahren. <i>Moves with speed resulting from the analog input (X10.18, X10.5)</i>
11	Fahre absolut während der Fahrt <i>Move absolute during move</i>	Es wird auf die angegebene Position gefahren, ohne zu stoppen <i>Moves to the specified position, also during move</i>
12	Fahre Kettenposition während der Fahrt <i>Move incremental during move</i>	Wie "Fahre Kettenposition" ohne zu stoppen <i>Moves to the position resulting from the setpoint position + the positioning parameter, also during move</i>
13	Fahre + während der Fahrt <i>Move + during move</i>	<i>Moves in a positive direction at the specified speed, also during move</i>
14	Fahre - während der Fahrt <i>Move - during move</i>	<i>Moves in a negative direction at the specified speed, also during move</i>
15	Fahre ± mit analoger Geschwindigkeit während der Fahrt <i>Move ± with analog speed during move</i>	Es wird mit der sich aus dem Sollwerteing. (X10.18, X10.5) ergebenden Geschwindigkeit (Analogwert Normierung für Sollwert) gefahren. <i>Moves with speed resulting from the analog input (X10.18, X10.5), also during move.</i>
20	geführter Stop <i>Stop with ramp</i>	Die Achse wird über die Bremsrampe gestoppt <i>The deceleration ramp is used to stop the axis.</i>
21	abrupter Stop <i>Stop directly</i>	Die Achse wird ohne Bremsrampe gestoppt <i>The axis is stopped directly.</i>
22	Zählerpreset <i>Counter preset</i>	Die Istposition wird auf den im Parameter Sollposition angegebenen Wert gesetzt. <i>The counter value is set to the value of the parameter position.</i>
30	Referenz 0 <i>Move datum 0,</i>	Es wird auf die Resolver-Nulllage in positiver Richtung referiert <i>Reference to the next zero point of the resolver interface in positive direction.</i>
31	Referenz 1 <i>Move datum 1</i>	Es wird auf die Resolver-Nulllage in negativer Richtung referiert <i>Reference to the next zero point of the resolver interface in negative direction.</i>
32	Referenz 2 <i>Move datum 2,</i>	Es wird auf die Low-High-Flanke des Referenzsensors in positiver Richtung referiert <i>Reference to the low-high slope of the reference switch (X10.24) in positive direction.</i>

Befehl 69 a: Positionssatz lesen

Command 69 a: read position set

Befehl <i>command</i>	Name <i>name</i>	Erklärung <i>explanation</i>
33	Referenz 3 <i>Move datum 3,</i>	Es wird auf die Low-High-Flanke des Referenzsensors in negativer Richtung referiert <i>Reference to the low-high slope of the reference switch (X10.24) in negative direction.</i>
34	Referenz 4 <i>Move datum 4,</i>	Es wird auf die der Low-High-Flanke des Referenzsensors folgenden Resolver-Nullage in positiver Richtung referiert. <i>Reference to the next zero point of the resolver interface after detecting the low-high slope of the reference switch (X10.24) in positive direction</i>
35	Referenz 5 <i>Move datum 5,</i>	Es wird auf die der Low-High-Flanke des Referenzsensors folgenden Resolver-Nullage in negativer Richtung referiert. <i>Reference to the next zero point of the resolver interface after detecting the low-high slope of the reference switch (X10.24) in negative direction</i>
36	Referenz 6 <i>Move datum 6,</i>	wie Befehl 30, mit automatischer Richtungswahl <i>same as move datum 0, with automatic direction selection</i>
37	Referenz 7 <i>Move datum 7</i>	wie Befehl 31, mit automatischer Richtungswahl <i>same as move datum 1, with automatic direction selection</i>
38	Referenz 8 <i>Move datum 8,</i>	wie Befehl 32, mit automatischer Richtungswahl <i>same as move datum 2, with automatic direction selection</i>
39	Referenz 9 <i>Move datum 9,</i>	wie Befehl 33, mit automatischer Richtungswahl <i>same as move datum 3, with automatic direction selection</i>
40	Referenz 10 <i>Move datum 10,</i>	wie Befehl 34, mit automatischer Richtungswahl <i>same as move datum 4, with automatic direction selection</i>
41	Referenz 11 <i>Move datum 11,</i>	wie Befehl 35, mit automatischer Richtungswahl <i>same as move datum 5, with automatic direction selection</i>
42	Referenz 12 <i>Move datum 12,</i>	wie Befehl 30, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 0, with reference offset, offset = target position</i>
43	Referenz 13 <i>Move datum 13,</i>	wie Befehl 31, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 1, with reference offset, offset = target position</i>
44	Referenz 14 <i>Move datum 14,</i>	wie Befehl 32, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 2, with reference offset, offset = target position</i>
45	Referenz 15 <i>Move datum 15,</i>	wie Befehl 33, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 3, with reference offset, offset = target position</i>
46	Referenz 16 <i>Move datum 16,</i>	wie Befehl 34, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 4, with reference offset, offset = target position</i>
47	Referenz 17 <i>Move datum 17,</i>	wie Befehl 35, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 5, with reference offset, offset = target position</i>
48	Referenz 18 <i>Move datum 18,</i>	wie Befehl 36, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 6, with reference offset, offset = target position</i>
49	Referenz 19 <i>Move datum 19</i>	wie Befehl 37, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 7, with reference offset, offset = target position</i>

Befehl 69 a: Positionssatz lesen***Command 69 a: read position set***

Befehl <i>command</i>	Name <i>name</i>	Erklärung <i>explanation</i>
50	Referenz 20 <i>Move datum 20,</i>	wie Befehl 38, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 8, with reference offset, offset = target position</i>
51	Referenz 21 <i>Move datum 21,</i>	wie Befehl 39, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 9, with reference offset, offset = target position</i>
52	Referenz 22 <i>Move datum 22,</i>	wie Befehl 40, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 10, with reference offset, offset = target position</i>
53	Referenz 23 <i>Move datum 23,</i>	wie Befehl 41, mit Verschiebung des Referenzpunktes um die angegebene Position <i>same as move datum 11, with reference offset, offset = target position</i>

Bei den Referenzmodi mit automatische Richtungswahl wird die Referenzfahrt in der entgegengesetzten Richtung begonnen, wenn der Referenzsensor (X10.24) beim Start der Referenzfahrt High ist.
Nachdem der Sensor auf Low-Pegel wechselt wird die Referenzfahrt in der gewählten Richtung ausgeführt.

The Reference-commands with automatic direction selection starts in the opposite direction if the reference sensor (X10.24) is already set at the start of the reference run. As soon as the reference sensor is reset the direction of turning is changed to the specified direction.

2.33 Befehl 69 b: Positionssatz schreiben

Command 69 b: write position set

Funktion:

Dieser Befehl schreibt einen Positionssatz.
Der Befehl ist nur nach Anmeldung erlaubt.

Function:

*This command writes a position set.
The command is only allowed after logging in.*

condition/activity	631	command 45 : write position set parameter	host	length	condition/action																								
This command writes a position set. The command is only allowed after logging in.	 	<p>← ← ← ← request ??? ← ← ← ← Beginning of the command</p> <table border="1"> <tr><td>ESC</td><td>axis-number</td></tr> <tr><td>01</td><td>command</td></tr> <tr><td>45</td><td>write-option = 1</td></tr> <tr><td>01</td><td>Number of the position set (0-9)</td></tr> <tr><td>byte</td><td>32</td></tr> <tr><td>byte</td><td>Command mode</td></tr> <tr><td>word</td><td>Nominal speed at scaling 1</td></tr> <tr><td>word</td><td>Acceleration at scaling 2</td></tr> <tr><td>word</td><td>Deceleration at scaling 2</td></tr> <tr><td>word</td><td>"Position reached"-window at incr.</td></tr> <tr><td>lword</td><td>Nominal position at increments</td></tr> <tr><td>hex</td><td>BCC</td></tr> </table> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted</p> <p>Command was not transmitted correctly</p> <p>Command was sent correctly, but the conditions are not met.</p> <p>Command was not transmitted completely</p>	ESC	axis-number	01	command	45	write-option = 1	01	Number of the position set (0-9)	byte	32	byte	Command mode	word	Nominal speed at scaling 1	word	Acceleration at scaling 2	word	Deceleration at scaling 2	word	"Position reached"-window at incr.	lword	Nominal position at increments	hex	BCC	 	19 Byte 1Byte	
ESC	axis-number																												
01	command																												
45	write-option = 1																												
01	Number of the position set (0-9)																												
byte	32																												
byte	Command mode																												
word	Nominal speed at scaling 1																												
word	Acceleration at scaling 2																												
word	Deceleration at scaling 2																												
word	"Position reached"-window at incr.																												
lword	Nominal position at increments																												
hex	BCC																												

³² siehe Befehl 69 a

see command 69 a

2.34 Befehl 72 a: Synchronprofil-parameterblock lesen

Funktion:

Dieser Befehl liest den angegebenen Synchronprofilparameterblock.

Der Befehl ist immer erlaubt.

Command 72 a: Read cam-profile parameter set

Function:

This command reads the desired cam-profile parameter set .

The command is allowed at any time.

condition/activity	631	command 48 : read cam-profile parameter	host	length	condition/action
This command reads the desired cam-profile parameter set . The command is allowed at any timew	<pre> <--<--<--<-- request ??? <--<--< ESC 1 01 2 48 3 00 4 byte nr. of the cam-profile parameter set (0-15) 5 hex BCC →→→→ response !!! →→→→ Command was correctly transmitted and sends the following data reserved for EASYRIDER number of corrections (always 0) number of profile points (PP) address of first profil point (STS) reserved correctionvalue 1. stage (always 0) correctionvalue 2. stage (always 0) correctionvalue 3. stage (always 0) correctionvalue 4. stage (always 0) correctionvalue 5. stage (always 0) correctionvalue 6. stage (always 0) correctionvalue 7. stage (always 0) correctionvalue 8. stage (always 0) correctionvalue 9. stage (always 0) correctionvalue 10. stage (always 0) Master stroke (MT) Slave stroke (ST) 16 byte reserved Synchronmode (identification of calculated profile; 255 for user defined) (TY) 11 byte reserved BCC NAK CAN TOUT </pre>			6 Byte 66 Byte 1 Byte	

2.35 Befehl 72 b: Synchronprofil-parameterblock schreiben

Funktion:

Dieser Befehl schreibt den angegebenen Synchronprofilparameterblock.
Der Befehl ist immer erlaubt.

Command 72 b: Write cam-profile parameter set

Function:

This command writes the desired cam-profile parameter set .
The command is allowed at any time.

condition/activity	631	command 48 : write cam profile parameter	host	length	condition/action
This command writes the desired cam-profile parameter set . The command is allowed at any time.	  	<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>axis-number</p> <p>command</p> <p>write-option = 1</p> <p>nr. of the cam-profile parameter set (0-15)</p> <p>reserved for EASYRIDER</p> <p>number of corrections (always 0)</p> <p>number of profile points (PP)</p> <p>address of first profil point (STS)</p> <p>reserved</p> <p>correctionvalue 1. stage (always 0)</p> <p>correctionvalue 2. stage (always 0)</p> <p>correctionvalue 3. stage (always 0)</p> <p>correctionvalue 4. stage (always 0)</p> <p>correctionvalue 5. stage (always 0)</p> <p>correctionvalue 6. stage (always 0)</p> <p>correctionvalue 7. stage (always 0)</p> <p>correctionvalue 8. stage (always 0)</p> <p>correctionvalue 9. stage (always 0)</p> <p>correctionvalue 10 stage (always 0)</p> <p>Master stroke (MT)</p> <p>Slave stroke (ST)</p> <p>16 byte reserved</p> <p>Synchronmode (identification of calculated profile; 255 for user defined)</p> <p>11 byte reserved</p> <p>18 hex BCC</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted</p> <p>Command was not transmitted correctly</p> <p>Command was sent correctly, but the conditions are not met.</p> <p>Command was not transmitted completely</p>	  	19 Byte	1Byte

2.36 Befehl 73 a: Stützstellenblock lesen

Funktion:

Dieser Befehl liest die Synchronstützstellen (8) mit der angegebenen Blocknummer.

Jeder Stützstellenblock (0 – 255) enthält 8 Stützstellen ($8 \times 256 = 2048$).

Der Befehl ist immer erlaubt.


Command 73 a: Read profil point block

Function:

This command reads the profile points (8) of the desired set .

Every profile point set (0...255) contains 8 profile points ($8 \times 256 = 2048$).

The command is allowed at any time.

condition/activity	631	command 49 : read cam-profile	host	length	condition/action
<p>This command reads the profile points (8) of the desired set . Every profile point set (0...255) contains 8 profile points ($8 \times 256 = 2048$). The command is allowed at any time.</p> 		<p>← ← ← ← request ??? ←←←← ESC 1 01 2 49 3 00 4 byte nr. of the cam-profile set (0-255) 5 hex BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data ACK 8 byte 1 8 byte 9 8 byte 17 8 byte 25 8 byte 33 8 byte 41 8 byte 49 8 byte 57 BCC 65 Command was not transmitted correctly Command was not transmitted completely NAK TOUT</p>	<p>← ↑ ↓ ↑ ↑</p> <p>6 Byte</p> <p>66 Byte</p> <p>1 Byte</p>		

2.37 Befehl 73 b: Stützstellenblock schreiben

Funktion:

Dieser Befehl schreibt die Synchronstützstellen (8) mit der angegebenen Blocknummer.

Jeder Stützstellenblock (0 – 255) enthält 8 Stützstellen ($8 \times 256 = 2048$).

Der Befehl ist immer erlaubt.

Command 73 b: Write profil point block

Function:

This command writes the profile points (8) of the desired set.

Every profile point set (0...255) contains 8 profile points ($8 \times 256 = 2048$).

The command is allowed at any time.

condition/activity	631	command 49 : write cam profile	host	length	condition/action																										
This command writes the profile points (8) of the desired set . Every profile point set (0...255) contains 8 profile points ($8 \times 256 = 2048$). The command is allowed at any time.	  	<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>ESC</p> <table border="1"> <tr><td>1</td><td>01</td></tr> <tr><td>2</td><td>49</td></tr> <tr><td>3</td><td>01</td></tr> <tr><td>4</td><td>byte</td></tr> <tr><td>5</td><td>8byte</td></tr> <tr><td>13</td><td>8byte</td></tr> <tr><td>21</td><td>8byte</td></tr> <tr><td>29</td><td>8byte</td></tr> <tr><td>37</td><td>8byte</td></tr> <tr><td>45</td><td>8byte</td></tr> <tr><td>53</td><td>8byte</td></tr> <tr><td>61</td><td>8byte</td></tr> <tr><td>69</td><td>byte</td></tr> </table> <p>BCC</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted</p> <p>Command was not transmitted correctly</p> <p>Command was not transmitted completely</p>	1	01	2	49	3	01	4	byte	5	8byte	13	8byte	21	8byte	29	8byte	37	8byte	45	8byte	53	8byte	61	8byte	69	byte	 	70 Byte 1Byte	
1	01																														
2	49																														
3	01																														
4	byte																														
5	8byte																														
13	8byte																														
21	8byte																														
29	8byte																														
37	8byte																														
45	8byte																														
53	8byte																														
61	8byte																														
69	byte																														

2.38 Befehl 74 a: E/A Definitionen lesen

Funktion:

Dieser Befehl liest die eingestellten E/A Definitionen.


Der Befehl ist immer erlaubt.

Command 74 a: read I/O definitions

Function:

This command reads the programmed I/O definitions.

The command is allowed at any time

condition/activity	631	command 4A : read I/O definitions	host	length	condition/action
This command reads the programmed I/O definitions. The command is allowed at any time	 	<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>1 ESC</p> <p>2 01</p> <p>3 4A</p> <p>4 00 hex</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and sends the following data</p> <p>Definition I X10.7</p> <p>Definition I X10.8</p> <p>Definition I X10.9</p> <p>Definition I X10.10</p> <p>Definition O X10.5</p> <p>Definition O X10.6</p> <p>reserved</p> <p>reserved</p> <p>reserved</p> <p>reserved</p> <p>reserved</p> <p>reserved</p> <p>BCC</p> <p>byte 1</p> <p>byte 2</p> <p>byte 3</p> <p>byte 4</p> <p>byte 5</p> <p>byte 6</p> <p>byte 7</p> <p>byte 8</p> <p>byte 9</p> <p>byte 10</p> <p>byte 11</p> <p>byte 12</p> <p>Command was not transmitted correctly</p> <p>Command was not transmitted completely</p> <p>ACK</p> <p>NAK</p> <p>TOUT</p>	 	5 Byte 14 Byte 1 Byte	

2.39 Befehl 74 b: E/A Definitionen schreiben

Funktion:

Dieser Befehl schreibt die eingestellten E/A Definitionen.

Der Befehl ist nur erlaubt wenn die Anmeldung ausgeführt und der 631 deaktiviert wurde

Command 74 b: write I/O definitions

Function:

This command writes the programmed I/O definitions.

The command is only allowed when the login was executed and the 631 was disabled.

condition/activity	631	command 4A : I/O definitions	host	length	condition/action																																				
This command writes the programmed I/O definitions. The command is only allowed when the login was executed and the 631 was disabled.	  	<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>axis-number command</p> <p>write-option = 1</p> <table border="1"> <tr><td>1</td><td>ESC</td></tr> <tr><td>2</td><td>01</td></tr> <tr><td>2</td><td>4A</td></tr> <tr><td>3</td><td>01</td></tr> <tr><td>4</td><td>byte</td></tr> <tr><td>5</td><td>byte</td></tr> <tr><td>6</td><td>byte</td></tr> <tr><td>7</td><td>byte</td></tr> <tr><td>8</td><td>byte</td></tr> <tr><td>9</td><td>byte</td></tr> <tr><td>10</td><td>byte</td></tr> <tr><td>11</td><td>byte</td></tr> <tr><td>12</td><td>byte</td></tr> <tr><td>13</td><td>byte</td></tr> <tr><td>14</td><td>byte</td></tr> <tr><td>15</td><td>byte</td></tr> <tr><td>16</td><td>byte</td></tr> <tr><td></td><td>BCC</td></tr> </table> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted</p> <p>Command was not transmitted correctly</p> <p>Command was sent correctly, but the conditions are not met.</p> <p>Command was not transmitted completely</p>	1	ESC	2	01	2	4A	3	01	4	byte	5	byte	6	byte	7	byte	8	byte	9	byte	10	byte	11	byte	12	byte	13	byte	14	byte	15	byte	16	byte		BCC	 	17 Byte	1Byte
1	ESC																																								
2	01																																								
2	4A																																								
3	01																																								
4	byte																																								
5	byte																																								
6	byte																																								
7	byte																																								
8	byte																																								
9	byte																																								
10	byte																																								
11	byte																																								
12	byte																																								
13	byte																																								
14	byte																																								
15	byte																																								
16	byte																																								
	BCC																																								

2.40 Befehl 75a: CAN-Busparameter lesen

Funktion:

Dieser Befehl liest die gewünschten Feldbusparameter.

Der Befehl ist immer erlaubt.

Command 75a: read CAN-bus parameters

Function:

This command reads the desired CAN-bus parameters.

The command is allowed at any time.

condition/activity	631	command 4B : read CAN-BUS parameters	host	length	condition/action
This command reads the desired CAN-bus parameters. The command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ←</p> <p>Beginning of the command</p> <p>axis-number</p> <p>command</p> <p>read-option = 0</p> <p>Number of the parameter set (3-7+9)</p> <p>BCC</p> <p>→ → → → response !!! → → → →</p> <p>Command was correctly transmitted and sends the following data</p> <p>parameter byte 0³³</p> <p>parameter byte 1</p> <p>parameter byte 2</p> <p>parameter byte 3</p> <p>parameter byte 4</p> <p>parameter byte 5</p> <p>parameter byte 6</p> <p>parameter byte 7</p> <p>parameter byte 8</p> <p>parameter byte 9</p> <p>parameter byte 10</p> <p>parameter byte 11</p> <p>parameter byte 12</p> <p>parameter byte 13</p> <p>parameter byte 14</p> <p>parameter byte 15</p> <p>byte 1</p> <p>byte 2</p> <p>byte 3</p> <p>byte 4</p> <p>byte 5</p> <p>byte 6</p> <p>byte 7</p> <p>byte 8</p> <p>byte 9</p> <p>byte 10</p> <p>byte 11</p> <p>byte 12</p> <p>byte 13</p> <p>byte 14</p> <p>byte 15</p> <p>byte 16</p> <p>BCC 17</p> <p>Command was not transmitted correctly</p> <p>Command was sent correctly, but the conditions are not met.</p> <p>Command was not transmitted completely</p> <p>ACK</p> <p>NAK</p> <p>CAN</p> <p>TOUT</p>		6 Byte 18 Byte 1 Byte	

³³ siehe Tabellen nächste Seite

see table on next page

Blocknummer 3 (CAN)

Byte	Parameter	parameters
0	CAL Modul Identifier (0...255)	<i>CAL module identifier (0...255)</i>
1	Unterbrechungsmodus	<i>mode</i>
2, 3	Word Verzögerung (mit Normierung 2, 1...64000)	<i>Word deceleration (with scaling 2, 1...64000)</i>
4	Baudrate (0=1 MBaud, 1=500 kBaud, 2=250 kBaud, 3=125 kB, 4=100 kB, 5=50 kB, 6=20 kB)	<i>baudrate (0=1 MBaud, 1=500 kBaud, 2=250 kBaud, 3=125 kB, 4=100 kB, 5=50 kB, 6=20 kB)</i>
5	Konfigurationsmodus (0=PC-Konfiguration, 1=PC-Konfiguration+Achsoffset, 2=Warte auf Kommunikation mit IBT)	<i>configuration mode (0=PC configuration, 1=PC configuration with axis offset, 2=waite for communication with IBT)</i>
6	erweiterte Identifier benutzen (0 = Nein, 1 = Ja)	<i>use extended identifier (0 = No, 1 = Yes)</i>
7	Status automatisch senden (0 = Nein, 1= Ja)	<i>send status automatically (0 = No, 1 = Yes)</i>
8-15	Reserviert	<i>reserved</i>

Blocknummer 4 (CAN)

Byte	Parameter	parameters
0-3	Reserviert	<i>reserved</i>
4-7	LWord Identifier Steuersatz empfangen ³⁴	<i>LWord identifier receive control block³⁴</i>
8-11	LWord Identifier Status senden ³⁴	<i>LWord identifier send status³⁴</i>
12-15	LWord Identifier Parameter empfangen ³⁴	<i>LWord identifier receive parameters³⁴</i>

Blocknummer 5 (CAN)

Byte	Parameter	parameters
0-3	LWord Identifier IBT-Kommunikation ³⁴	<i>LWord identifier IBT communication³⁴</i>
4-7	LWord Identifier Parameter senden ³⁴	<i>LWord identifier send parameters³⁴</i>
8-11	LWord Identifier High-Speed-Daten ³⁴	<i>LWord identifier high speed data³⁴</i>
12-15	Reserve	<i>reserved</i>

Blocknummer 9 (CAN)

Byte	Parameter	parameters
0	Knotennummer Absolutwertgeber	<i>node number absolute encoder</i>
2..4	Reserviert	<i>reserved</i>
5	Zählrichtung Absolutwertgeber (1 = negativ)	<i>counting direction absolute encoder (1 = negative)</i>
6/ 7	Reserviert	<i>reserved</i>
8	Knotennummer BCD-Schalter	<i>node number BCD switch</i>
9	BCD-Schaltermodus (immer 0)	<i>BCD switch mode (always 0)</i>
10/ 11	Reserviert	<i>reserved</i>
12	Knotennummer E/A-Modul	<i>node number I/O module</i>
13	E/A-Modulmodus (immer 0)	<i>I/O module mode (always 0)</i>
14/ 15	Reserviert	<i>reserved</i>

³⁴ 0..2047,

0..2047

2.41 Befehl 75b: CAN-Busparameter schreiben

Funktion:

Dieser Befehl schreibt die gewünschten Feldbusparameter.
Der Befehl ist nur nach Anmeldung erlaubt.

Command 75b: write CAN-bus parameters

Function:

*This command writes the desired CAN-bus parameters .
The command is only allowed after logging in.*

condition/activity	631	command 4B : write CAN- BUS parameters	host	length	condition/action
This command writes the desired CAN-bus parameters. The command is only allowed after logging in.	  	<p>← ← ← ← request ??? ← ← ← ← Beginning of the command</p> <p>ESC</p> <p>1 01</p> <p>2 4B</p> <p>3 01</p> <p>4 byte</p> <p>5 byte</p> <p>6 byte</p> <p>7 byte</p> <p>8 byte</p> <p>9 byte</p> <p>10 byte</p> <p>11 byte</p> <p>12 byte</p> <p>13 byte</p> <p>14 byte</p> <p>15 byte</p> <p>16 byte</p> <p>17 byte</p> <p>18 byte</p> <p>19 byte</p> <p>20 byte</p> <p>21 byte BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted</p> <p>Command was not transmitted correctly</p> <p>Command was sent correctly, but the conditions are not met.</p> <p>Command was not transmitted completely</p>		22 Byte 1Byte	

³⁵ siehe Tabellen vorherige Seite

2.42 Befehl 76 a: BIAS-Programm lesen



Funktion:

Dieser Befehl liest einen BIAS-Befehl.
Der Befehl ist immer erlaubt.

Command 76 a: read BIAS-programm

Function:

This command reads a BIAS command.
The command is allowed at any time

condition/activity	631	command 4C : read BIAS command	host	length	condition/action
This command reads a BIAS command. The command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ← Beginning of the command</p>  <p>axis-number command read-option = 0 setnumber (0-1499) BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data</p>  <p>BIAS command code³⁶ BIAS command databyte 1 BIAS command databyte 2 BIAS command databyte 3 BIAS command databyte 4 BIAS command databyte 5 BIAS command databyte 6 BIAS command databyte 7</p> <p>→ → → → Command was not transmitted correctly</p> <p>→ → → → Command was sent correctly, but the conditions are not met.</p> <p>→ → → → Command was not transmitted completely</p>	 	7 Byte 10 Byte 1 Byte	

³⁶ Die Befehlscodierung ist in der Dokumentation 10.6.5 „BIAS-Befehlsbeschreibung „ beschrieben

2.43 Befehl 76 b: BIAS-Programm schreiben

Funktion:

Dieser Befehl schreibt einen BIAS-Befehl.
Der Befehl ist nur nach Anmeldung erlaubt.

Command 76 b: write BIAS-Programm

Function:

*This command writes a BIAS command.
The command is allowed at any time.*

condition/activity	631	command 4C : write BIAS -command	host	length	condition/action
This command writes a BIAS command. The command is allowed at any time	<pre> <--<--<--<-- request ??? <--<--<--< ESC 1 01 2 4C 3 01 4 word 6 byte 7 byte 8 byte 9 byte 10 byte 11 byte 12 byte 13 byte 14 byte BCC →→→→ response !!! →→→→→ Command was correctly transmitted Command was not transmitted correctly Command was sent correctly, but the conditions are not met. Command was not transmitted completely </pre>			15 Byte	

³⁷ Die Befehlscodierung ist in der Dokumentation 10.6.5 „BIAS-Befehlsbeschreibung „ beschrieben

2.44 Befehl 78 a: Erweiterte Regelparameter lesen

Command 78 a: read extended control parameters

condition/activity	631	command 4E : read extended parameters	host	length	condition/action																										
This command reads the extended control parameters. The command is allowed at any time		<p>← ← ← ← request ??? ← ← ← ← Beginning of the command</p> <table border="1"> <tr><td>1</td><td>ESC</td></tr> <tr><td>2</td><td>01</td></tr> <tr><td>3</td><td>4E</td></tr> <tr><td>4</td><td>00 hex</td></tr> </table> <p>axis-number command read-option = 0 BCC</p> <p>→ → → → response !!! → → → → Command was correctly transmitted and sends the following data</p> <table border="1"> <tr><td>word</td><td>1</td></tr> <tr><td>byte</td><td>3</td></tr> <tr><td>byte</td><td>4</td></tr> <tr><td>word</td><td>5</td></tr> <tr><td>word</td><td>7</td></tr> <tr><td>word</td><td>9</td></tr> <tr><td>byte</td><td>11</td></tr> <tr><td>byte</td><td>12</td></tr> <tr><td>word</td><td>13</td></tr> </table> <p>BCC 15</p> <p>Command was not transmitted correctly NAK</p> <p>Command was not transmitted completely TOUT</p>	1	ESC	2	01	3	4E	4	00 hex	word	1	byte	3	byte	4	word	5	word	7	word	9	byte	11	byte	12	word	13		5 Byte	
1	ESC																														
2	01																														
3	4E																														
4	00 hex																														
word	1																														
byte	3																														
byte	4																														
word	5																														
word	7																														
word	9																														
byte	11																														
byte	12																														
word	13																														

2.45 Befehl 78 b: Erweiterte Regelparameter schreiben

Command 78 b: write extended control parameters

condition/activity	631	command 4E : write extende parameters	host	length	condition/action																												
This command writes the extended control parameters. The command is only allowed after logging in		<p>← ← ← ← request ??? ← ← ← ← Beginning of the command</p> <table border="1"> <tr><td>1</td><td>ESC</td></tr> <tr><td>2</td><td>01</td></tr> <tr><td>3</td><td>4E</td></tr> <tr><td>4</td><td>01</td></tr> <tr><td>5</td><td>word</td></tr> <tr><td>6</td><td>byte</td></tr> <tr><td>7</td><td>byte</td></tr> <tr><td>8</td><td>word</td></tr> <tr><td>10</td><td>word</td></tr> <tr><td>12</td><td>word</td></tr> <tr><td>14</td><td>byte</td></tr> <tr><td>15</td><td>byte</td></tr> <tr><td>16</td><td>word</td></tr> <tr><td>18</td><td>byte BCC</td></tr> </table> <p>V-gain low-byte (256 = 100%) X40-Mode (0...3) X40-resolution (0...3) only if “Position reached” time at 2 ms reserved trail window at increments trail fault reaction (0...3) n-filter (0...30) reserved</p> <p>→ → → → response !!! → → → → Command was correctly transmitted</p> <p>Command was not transmitted correctly NAK</p> <p>Command was sent correctly, but the conditions are not met. CAN</p> <p>Command was not transmitted completely TOUT</p>	1	ESC	2	01	3	4E	4	01	5	word	6	byte	7	byte	8	word	10	word	12	word	14	byte	15	byte	16	word	18	byte BCC		19 Byte	
1	ESC																																
2	01																																
3	4E																																
4	01																																
5	word																																
6	byte																																
7	byte																																
8	word																																
10	word																																
12	word																																
14	byte																																
15	byte																																
16	word																																
18	byte BCC																																

3 Anhang

Appendix

Zuordnung der Tabellenplätze für P- und I-Anteil im Strom- und Drehzahlregler zu den physikalischen Werten

Assignment of the table positions for P- and I-gain in the current and speed controller to the physical value

Stromregler			Drehzahlregler		
Index	P-Anteil	I-Anteil in 1/ms	Index	P-Anteil	I-Anteil in 1/ms
<i>current controller</i>			<i>speed controller</i>		
Index	P-gain	I-gain in 1/ms	Index	P-gain	I-gain in 1/ms
0	0,12	1/160,00	0	0,24	-
1	0,12	1/152,00	1	0,25	1/228,00
2	0,13	1/144,40	2	0,26	1/216,60
3	0,14	1/137,18	3	0,28	1/205,77
4	0,15	1/130,32	4	0,29	1/195,48
5	0,15	1/123,80	5	0,31	1/185,71
6	0,16	1/117,61	6	0,32	1/176,42
7	0,17	1/111,73	7	0,34	1/167,60
8	0,18	1/106,15	8	0,36	1/159,22
9	0,19	1/100,84	9	0,38	1/151,26
10	0,20	1/95,80	10	0,40	1/143,70
11	0,21	1/91,01	11	0,42	1/136,51
12	0,22	1/86,46	12	0,44	1/129,69
13	0,23	1/82,13	13	0,46	1/123,20
14	0,24	1/78,03	14	0,49	1/117,04
15	0,26	1/74,13	15	0,51	1/111,19
16	0,27	1/70,42	16	0,54	1/105,63
17	0,28	1/66,90	17	0,57	1/100,35
18	0,30	1/63,55	18	0,60	1/95,33
19	0,31	1/60,83	19	0,63	1/90,56
20	0,33	1/57,36	20	0,66	1/86,04
21	0,35	1/54,49	21	0,70	1/81,73
22	0,37	1/51,77	22	0,73	1/77,65
23	0,39	1/49,18	23	0,77	1/73,77
24	0,41	1/46,72	24	0,81	1/70,08
25	0,43	1/44,38	25	0,85	1/66,57
26	0,45	1/42,16	26	0,90	1/63,24
27	0,47	1/40,06	27	0,95	1/60,08
28	0,50	1/38,05	28	1,00	1/57,08
29	0,52	1/36,15	29	1,05	1/54,22
30	0,55	1/34,34	30	1,10	1/51,51
31	0,58	1/32,63	31	1,16	1/48,94
32	0,61	1/30,99	32	1,22	1/46,49
33	0,64	1/29,44	33	1,29	1/44,17
34	0,68	1/27,97	34	1,36	1/41,96
35	0,71	1/26,57	35	1,43	1/39,86
36	0,75	1/25,24	36	1,50	1/37,87
37	0,79	1/23,98	37	1,58	1/35,95
38	0,83	1/22,78	38	1,67	1/34,17
39	0,88	1/21,64	39	1,75	1/32,47
40	0,92	1/20,56	40	1,85	1/30,84
41	0,97	1/19,53	41	1,94	1/29,30
42	1,02	1/18,56	42	2,04	1/27,84
43	1,08	1/17,63	43	2,15	1/26,44
44	1,13	1/16,75	44	2,27	1/25,12
45	1,19	1/15,91	45	2,38	1/23,87
46	1,26	1/15,11	46	2,51	1/22,67
47	1,32	1/14,36	47	2,64	1/21,54
48	1,39	1/13,64	48	2,78	1/20,46
49	1,46	1/12,96	49	2,93	1/19,44
50	1,54	1/12,31	50	3,08	1/18,47
51	1,62	1/11,70	51	3,24	1/17,54
52	1,71	1/11,11	52	3,41	1/16,67
53	1,80	1/10,56	53	3,59	1/15,83
54	1,89	1/10,03	54	3,78	1/15,04
55	1,99	1/9,53	55	3,98	1/14,29
56	2,10	1/9,05	56	4,19	1/13,57
57	2,21	1/8,60	57	4,51	1/12,90

58	2,32	1/8,17	58	4,65	1/12,25
59	2,45	1/7,76	59	4,89	1/11,64
60	2,57	1/7,37	60	5,15	1/11,06
61	2,71	1/7,00	61	5,42	1/10,50
62	2,85	1/6,65	62	5,70	1/9,98
63	3,00	1/6,32	63	6,00	1/9,48
64	3,16	1/6,00	64	6,32	1/9,01
65	3,33	1/5,70	65	6,65	1/8,56
66	3,50	1/5,42	66	7,00	1/8,13
67	3,69	1/5,15	67	7,37	1/7,72
68	3,88	1/4,89	68	7,76	1/7,34
69	4,08	1/4,65	69	8,17	1/6,97
70	4,30	1/4,41	70	8,60	1/6,62
71	4,52	1/4,19	71	9,05	6,29/
72	4,76	1/3,98	72	9,53	1/5,97
73	5,01	1/3,78	73	10,02	1/5,68
74	5,28	1/3,59	74	10,56	1/5,39
75	5,56	1/3,41	75	11,11	1/5,12
76	5,85	1/3,24	76	11,70	1/4,87
77	6,16	1/3,08	77	12,31	1/4,62
78	6,48	1/2,93	78	12,96	1/4,39
79	6,82	1/2,78	79	13,64	1/4,17
80	7,18	1/2,64	80	14,36	1/3,96
81	7,56	1/2,51	81	15,11	1/3,77
82	7,96	1/2,38	82	15,91	1/3,58
83	8,37	1/2,27	83	16,75	1/3,40
84	8,81	1/2,15	84	17,63	1/3,23
85	9,28	1/2,04	85	18,56	1/3,07
86	9,77	1/1,94	86	19,53	1/2,91
87	10,28	1/1,85	87	20,56	1/2,77
88	10,82	1/1,75	88	21,64	1/2,63
89	11,39	1/1,67	89	22,78	1/2,50
90	11,99	1/1,58	90	23,98	1/2,37
91	12,62	1/1,50	91	25,24	1/2,25
92	13,29	1/1,43	92	26,57	1/2,14
93	13,99	1/1,36	93	27,97	1/2,03
94	14,72	1/1,29	94	29,44	1/1,93
95	15,50	1/1,22	95	30,99	1/1,84
96	16,31	1/1,16	96	32,63	1/1,74
97	17,17	1/1,10	97	34,34	1/1,66
98	18,07	1/1,05	98	36,15	1/1,57
99	19,03	1/1,00	99	38,05	1/1,50
100	20,03	1/0,95	100	40,06	1/1,42
101	21,08	1/0,90	101	42,16	1/1,35
102	22,19	1/0,85	102	44,38	1/1,28
103	23,36	1/0,81	103	46,72	1/1,22
104	24,59	1/0,77	104	49,18	1/1,16
105	25,88	1/0,73	105	51,77	1/1,10
106	27,24	1/0,70	106	54,49	1/1,04
107	28,68	1/0,66	107	57,36	1/0,99
108	30,19	1/0,63	108	60,38	1/0,94
109	31,78	1/0,60	109	63,55	1/0,90
110	33,45	1/0,57	110	66,90	1/0,85
111	35,21	1/0,54	111	70,42	1/0,81
112	37,06	1/0,51	112	74,13	1/0,77
113	39,01	1/0,49	113	78,03	1/0,73
114	41,07	1/0,46	114	82,13	1/0,69
115	43,23	1/0,44	115	86,46	1/0,66
116	45,50	1/0,42	116	91,01	1/0,63
117	47,90	1/0,40	117	95,80	1/0,59
118	50,42	1/0,38	118	100,80	1/0,56
129	53,07	1/0,36	129	106,20	1/0,54
120	55,87	1/0,34	120	111,70	1/0,51
121	58,81	1/0,32	121	117,60	1/0,48
122	61,90	1/0,31	122	123,80	1/0,46
123	65,16	1/0,29	123	130,30	1/0,44
124	68,59	1/0,28	124	137,20	1/0,41
125	72,20	1/0,26	125	144,40	1/0,39
126	76	1/0,25	126	152,00	1/0,37
127	80	1/0,24	127	160,00	1/0,36

Zuordnung der gesendeten Parameter zu den physikalischen Werten im Lageregler

P-Anteil physikalischer Wert *8
I-Anteil physikalischer Wert *150

Assignment of the transmitted parameters to the physical values

P-Gain physicalic value * 8
I-Gain physicalic value * 150

V-Anteil	Prozentwert * 2,56	<i>V-Gain</i>	<i>percentage * 2,56</i>
----------	--------------------	---------------	--------------------------

4 Änderungsliste

Modification Record

Version	Änderungsgrund	Modification	Kapitel Chapter	Datum Date	Name Name	Bemerkung Comment
V01.17SA99	initial	<i>initial</i>		26.04.1999 11.05.1999	SA TB	631 Firmware V 5.10